

# MULTI JET 5-i


## MJ5-i-150~1500

### Instruction Manual

#### **WARNING**

You must properly use your MULTI JET 5-i by thoroughly reading this manual.

Keep this manual near the MULTI JET 5-i so that it can be easily accessed whenever necessary.



# Product Warranty

---

Thank you very much for purchasing our product. Please carefully read this instruction manual for correct and safe use. In addition, this page of this instruction manual serves as the product warranty. Make sure to carefully store the instruction manual after reading it.

## 1. Warranty period

Warranty of this product warrants repair or replacement of parts free of charge if any failure occurs even when this product is normally used according to the operation procedures, etc., within the warranty period of the product warranty.

In addition, failure products shall be returned to us.

- 1) The warranty term of the product is 12 months after the initial operation, but shall not exceed 15 months after the date of shipment of the product.
- 2) The warranty period for parts replaced during repairs shall be three months from the date of repairs.

## 2. Scope of Warranty

The following items, if applicable, are not covered by the free warranty even within the warranty period.

- 1) Failure or damage caused by modifications or repairs carried out by any person other than us
- 2) Failure or damage caused by natural disasters such as earthquake, typhoon, flooding, etc., and accident or fire
- 3) Failure or damage caused by use exceeding the limit of the specifications described in this instruction manual, catalog, etc., or by installation environment
- 4) Failure or damage caused by improper use or handling
- 5) Effect on products caused by external factors  
(Paint peeling due to generated gas, malfunction due to electrical noise, etc.)
- 6) Failure or damage caused by use of parts other than genuine parts (oil, medium, filter, etc.)
- 7) Consumables (hoses, filters, packings, O-rings, electric magnet contactors, mechanical seals, etc.)
- 8) When the product is transferred or leased to third party
  - The scope of warranty includes up to repair or replacement of parts of our products, and does not include products manufactured by use of our products and damage to other products due to failure or use of our products. In addition, “transportation expenses,” “customs duties,” “travel expenses” and “commuting expenses” associated with the repair or replacement of parts shall be separately paid.
  - The product price does not include the following service expenses. They are separately charged.  
(However, this does not apply if the contract includes the following)
    - 1) Technical guidance and technical education
    - 2) Installation adjustment guidance and trial operation attendance
    - 3) Maintenance and inspection, adjustment and repair

## 3. After expiration of the warranty period

If performance can be maintained by repairs, we shall repair the equipment for a fee at your request.

## 4. Parts supply period

Functional parts for repairs can be supplied until about eight years after the end of production of the equipment. However, some parts can be supplied even after the lapse of the period. Please contact our service division for information.

## 5. Others

For technical information, refer also to the maintenance and inspection procedures, and troubleshooting on our website (<http://matsui-mfg.co.jp/troubleshooting/>).

# Contents

---



Items with this sign are particularly important. Please be sure of a sufficient comprehension before applying relevant devices.

## Product Warranty

Contents.....I~II

## Chapter 1 Safety Precautions

- 1. Hazardous level marks and their Meanings..... 1
- 2. Safety Precautions ..... 2

## Chapter 2 Equipment Explanation

- 1. Essentials of the equipment..... 4
- 2. Packing confirmation ..... 5
- 3. Name of each part ..... 6
- 4. Name and function of each controller part of touch screen ..... 7
- 5. Machine units usage regulation ..... 26
- 6. Outer dimension ..... 28

## Chapter 3 Installation

\* Only when you install the machine, can you refer to this chapter

- 1. Equipment installation ..... 29
- 2. Power supply connection..... 33

## Chapter 4 Preparation for operation

- 1. Inspecting inside of the drying hopper ..... 34
- 2. Condition affirmation of each unit ..... 35
- 3. Power supply ..... 38
- 4. To confirm the correct rotating direction of blower ..... 41
- 5. Controller of touch screen setting ..... 42
- 6. Temperature Setting up of the overheat protector ..... 48
- 7. Jet clone operation ..... 50
- 8. Outline of Aero Power Hopper ..... 51

## Chapter 5 Operating Procedures ..... 56

|                   |   |     |
|-------------------|---|-----|
| <b>Chapter 6</b>  | <b>⚠ Maintenance and inspection</b>   |     |
|                   | 1. Daily maintenance and inspection .....                                   | 60  |
|                   | 2. Weekly maintenance and inspection .....                                  | 62  |
|                   | 3. Monthly maintenance and inspection .....                                 | 69  |
|                   | 4. Every six months maintenance and inspection .....                        | 70  |
| <b>Chapter 7</b>  | <b>Alarm Function</b>   |     |
|                   | 1. Alarm cause and reset .....  | 72  |
|                   | 2. Confirmation of alarm situation .....                                    | 74  |
|                   | 3. Alarm list .....   | 75  |
| <b>Chapter 8</b>  | <b>⚠ Trouble shooting</b>   | 80  |
|                   | The thermal relay setting value of every model (A) .....                    | 87  |
| <b>Chapter 9</b>  | <b>Technical Manual</b>   |     |
|                   | 1. On influence of gas that occurs from the resin .....                     | 88  |
|                   | 2. Relation between the dry air dew point and the fresh air condition ..... | 90  |
|                   | 3. About alarm .....  | 91  |
|                   | 4. Cancel the setting of [i plas] .....                                     | 96  |
| <b>Chapter 10</b> | <b>Components parts list</b>  | 97  |
| <b>Chapter 11</b> | <b>Options</b>  |     |
|                   | 1. Alarm indicator .....  | 101 |
|                   | 2. General alarm output .....   | 101 |
|                   | 3. Weekly timer .....   | 101 |
|                   | 4. Dew point monitor .....  | 101 |
|                   | 5. Power meter .....  | 101 |
|                   | 6. Leakage breaker .....  | 101 |
|                   | 7. Secondary convey two directions .....                                    | 102 |
|                   | 8. Connecting JET SELECTOR .....  | 103 |
|                   | 9. Compatibility of different voltage .....                                 | 103 |
|                   | 10. Lower limit level alarm switch .....                                    | 104 |
|                   | 11. It installs DIGI-PECA switch .....                                      | 104 |
| <b>Chapter 12</b> | <b>Specifications</b>   | 105 |
|                   | Appendix  |     |
|                   | Attached drawing  |     |

# Chapter 1 Safety Precautions

This chapter describes the hazardous levels and their marks on the products, which calls for your particular precaution in performing the operations, maintenance, and service for the safe use of the products.



In performing the operations, maintenance, and services of the products, be sure to observe the safety precaution include in this document.

We shall take no responsibility and /or liability for any injury or accident attributable to your failure in observing such precaution.


## 1. Hazardous level marks and their meanings


This manual uses the following convention for the hazardous level marks:

| Mark | Description  |
|------|--|
|      | Improper handling might lead to your death. This mark is followed by the information provided to avoid such result.  |
|      | Improper handling might lead to your serious injury. This mark is followed by the information provided to avoid such result.                               |
|      | Improper handling might lead to your slight injury or damage on the products. This mark is followed by the information provided to avoid such result.      |
|      | This mark is followed by the information provided to call for your particular attention in the context of operation procedures and explanatory statements. |
|      | This mark is used to indicate a point to which you should pay particular attention in handling something.  |
|      | This mark is used to indicate an exceptional condition or description in figures and tables.   |

## 2. Safety Precautions

Be sure to observe the following precautions when operating this equipment:

| Precaution Item   | Description   |
|---|---|
| Surface temperature<br> Danger | <p>Since this equipment is made for drying purpose, the surface of the body reaches high temperatures. In particular, the surface of the hot air piping and the exhaust filter case reach temperatures exceeding 130°C/266°F when the dryer runs continuously with the control temperature set to its maximum (160°C/320°F). Avoid careless proximity with the body when the equipment is in operation. Even when the equipment must be handled at emergency, do not touch with bare hands or allow direct contact with skin. Before performing normal inspection and cleaning, allow the machine to cool down naturally for at least five hours after stopping operation.</p>  |
| Equipment use   | <p>This equipment is designed for drying resin pellets. Drying of any other material will cause machine breakdown or failure. Trouble resulting from use with materials other than resin pellets is not covered e warranty.</p> <p>Drying e, special type material can only be carried on with resin pellets, material with high moisture and heavy moisture Nylon material are not applicable.</p> <p>Resin material generating volatile gas, while drying, is easy to have dehumidifying rotor (absorbing material) stuck, consequently, the dehumidifying and drying ability will become worse.</p> <p>Do not use materials containing volatile component and inflammable materials; otherwise, explosion or fire will trigger. Matsui will absolutely not take any responsibilities of such accident thus aroused.</p> <p>As for the material that is possible to generate gas during drying, please refer to "Technical Manual-1".</p> |
| Using Environment   | <p>Use this equipment indoor. Operate this equipment in ambient temperature from 0°C to 40°C and humidity from 25%~85%.</p> <p>Depending on the humidity condition, there is possibility that performance may not be fully realized. As for the relation between the humidity and the dry air dew point, please refer to "Technical Manual-2".</p>  |
| Drying temperature  | <p>Please set drying temperature within maximum operating range as noted in the specifications. Do not use temperatures exceeding the maximum operating temperature. Otherwise, failure or an accident will occur.</p>  |
| Precautions during operation  | <p>Do not open the machine parts, such as cylindrical part of drying hopper, cleaning door and residue out hole, while machine is operating. Because resin or hot air will blow out. And it is extremely dangerous.</p>   |
| Opening and closing of cleaning door  | <p>Please open and close cleaning door after confirming that there is no material inside from the level window.</p>   |
| Maintenance and inspection  | <p>Before carrying out any maintenance procedures, be sure to turn the main switch on the side of the control panel to "OFF".</p>   |

| Precaution item   | Description   |
|---|---|
| Control panel<br>Temperature controller   | Do not apply strong shock to or spill water on control panel or temperature controller. Otherwise, failure or fire may result.<br>Only open the door when absolutely necessary. Otherwise, failure or accident may result.  |
| Overheat protection device<br> | This equipment has safety device (overheat protector) as its standard configuration. When the safety device is operating, the operation power is cut off, and the heater and blower stop. At this moment, the heater part would become quite high in temperature. Only after complete cooling down of the heater, should restart be carried on. Please pay full attention to temperature set up in order to avoid overheat sensor triggers again.<br>For details, please refer to “Chapter 4. Preparation for Operation”. |
| Warning labels<br>Name plate  | Keep them legible before this equipment is disposed of.   |
| Wiping clean  | Do not wipe this equipment with petroleum solvents. Benzene, paint thinner, scouring powders, etc. will damage the surface. To clean dirty equipment, wipe with soft cloth which has been soaked in water below 40°C/104°F and wrung out well.  |
| Maintenance and repair  | To avoid any danger or failure, please do not entrust anyone who don't understand machinery and electricity with this task involving dismantlement.<br>For services regarding maintenance or repair, please contact our after-sales service department that is nearest to your company.   |
| When disposing of product and parts   | When disposing of them, obeys law in the applicable use country after use in product and parts.   |

# Chapter 2 . Equipment Explanation

---

## 1. Essentials of the equipment

This equipment is used for drying resin particles.


This device can make dry air with sorbent to remove water in air.

Then send the dry air into hopper where resin is after the air being heated up.

As water in external air has been removed with sorbent, stable conditions for dryness can be obtained.

In addition, because of low dew point and little water in the air, the water can be evaporated very quickly.


As the device recycles the exhaust from drying hopper to get dry air, and the exhaust is not discharged out of the device; thus, there will be no strong odour and plenty hot air emitted, besides, power consumption is very low.

This machine has the intelligent drying ability to decrease or increase wind volume to optimum; consequently, realizing the optimal use of electric energy. (  )



**Refers to:**

General names for commodities that have been developed by Matsui featuring automatic control and intelligent capacity

As to those equipped with , customers' operation is monitored and controlled in a consecutive row, and automatically adjusted to a mode optimizing energy and resource saving.

It shall carry on control according to different operating status, such as in full load production, a small amount production, or production under temporarily stop. Compared with the former one, it saves both energy and resource to the larger extent.




## 2. Packing confirmation

Make sure if the whole machine you purchased from us is in complete set or not.

- Main machine (purchase status)
- Hopper on the molding machine (purchase status)  
(AERO Power Hopper)

For secondary convey 2 directions: 2pcs  
Model differs according to the specification




### ○Appendix


| Attachment   | MJ5-i-150~650 | QTY. | MJ5-i-1500 | QTY. |
|--|---------------|------|------------|------|
| Hopper on the molding machine<br>(Aero Power Hopper) | APH-3         | 1    | APH-9      | 1    |
| PVC hose(for primary convey)                         | φ38×10m       | 1    | φ50×10m    | 1    |
| PVC hose(for secondary convey)                       | φ38×5m        | 1    | φ50×10m    | 1    |
| Suction nozzle(aluminum)                             | φ38           | 1    | φ50        | 1    |
| Hose band ( For PVC hose)                            | AK-1045       | 4    | AK-1058    | 4    |
| GL hose(white, for suction)                          | φ38×5m        | 1    | φ65×10m    | 1    |
| Pipe joint(white rubber)                             | φ38           | 2    | φ60        | 2    |
| Hose band (For GL hose)                              | AK-1045       | 2    | AK-1073    | 2    |

\* Appendix differs by attached option and special specification.
























### 3. Name of each part (illustrated by below picture)











※Before operation, it's necessary to refer to the item No.4 to confirm the correct rotating direction of blower, which is in Chapter 4 Preparation for operation (P41). Please check whether the inhaling port A of the primary conveyance in the above picture is breathing in.

















4. Name and function of each controller part of touch screen




| Display  | Operating method / Function and operation description   |   |                                    |   |  |   |   |          |                                      |          |                                      |   |   |   |   |   |  |
|--|---|---|------------------------------------|---|--|---|---|----------|--------------------------------------|----------|--------------------------------------|---|---|---|---|---|--|
| <p>Initial display</p>  | <p>It will show soon after machined connected to power supply.</p> <p>In a few seconds, it goes to 「Home」 .</p>   |   |                                    |   |  |   |   |          |                                      |          |                                      |   |   |   |   |   |  |
| <p>Home</p>            | <p>Press [  ] in various display to go to main menu.</p> <p><u>Windows switching operation</u></p> <ul style="list-style-type: none"><li>• Press  to go to 「AlarmList」 window.</li><li>• Press  to go to 「DryingSetting」 window.</li></ul> <p>(1) Indicating part</p> <table><tbody><tr><td></td><td>..... • Lights on in drying heater</td></tr><tr><td></td><td>..... • Lights on in regeneration heater</td></tr><tr><td></td><td>..... • Lights on in drying hopper material level</td></tr><tr><td>PV .....</td><td>• for present temperature indication</td></tr><tr><td>SV .....</td><td>• for setting temperature indication</td></tr><tr><td></td><td>• for timer setup for the start up • flickers</td></tr><tr><td></td><td>• for timer setup for the stop • flickers</td></tr><tr><td></td><td>• for timer set up for drying completion •</td></tr></tbody></table> <p>Flickers</p> <p>Time display • • to show remaining time after drying finished (Secondary side convey start to put off).</p> <p>※The above, due to not been set up, will not show for the first time, when machine is shipping out of factory.</p> <p>※Each timer setup can be done through 「Timer Operation」 window.</p> |  | ..... • Lights on in drying heater |  | ..... • Lights on in regeneration heater |  | ..... • Lights on in drying hopper material level | PV ..... | • for present temperature indication | SV ..... | • for setting temperature indication |  | • for timer setup for the start up • flickers |  | • for timer setup for the stop • flickers |  | • for timer set up for drying completion • |
|                       | ..... • Lights on in drying heater  |   |                                    |   |  |   |   |          |                                      |          |                                      |   |   |   |   |   |  |
|                       | ..... • Lights on in regeneration heater  |   |                                    |   |  |   |   |          |                                      |          |                                      |   |   |   |   |   |  |
|                       | ..... • Lights on in drying hopper material level   |   |                                    |   |  |   |   |          |                                      |          |                                      |   |   |   |   |   |  |
| PV .....   | • for present temperature indication  |   |                                    |   |  |   |   |          |                                      |          |                                      |   |   |   |   |   |  |
| SV .....   | • for setting temperature indication  |   |                                    |   |  |   |   |          |                                      |          |                                      |   |   |   |   |   |  |
|                       | • for timer setup for the start up • flickers   |   |                                    |   |  |   |   |          |                                      |          |                                      |   |   |   |   |   |  |
|                       | • for timer setup for the stop • flickers   |   |                                    |   |  |   |   |          |                                      |          |                                      |   |   |   |   |   |  |
|                       | • for timer set up for drying completion •  |   |                                    |   |  |   |   |          |                                      |          |                                      |   |   |   |   |   |  |

| Display   | Operating method / Function and operation description   |
|---|---|
| <p>Home</p>  <p>(1) →</p> <p>(2) →</p> | <p>(2) Operation part</p> <p>Feed to  .....Secondary convey No.1 direction start/stop switch, indication</p> <p>Feed to  .....Secondary convey No.2 direction start/stop switch, indication</p> <p>Feed to  .....Primary convey to drying hopper start/stop key, indication</p> <p> .....drying run/stop key, indication</p> <p> .....key for alarm and buzzer reset</p> |





| Display  | Operating method / Function and operation description  |
|--|--|
| <p>Home</p>   | <p><u>Start-up operation</u></p> <ul style="list-style-type: none"><li>• Hold press [RUN/STOP] to turn on indicator until drying operation started. Repeat hold press until indicator flickers to stop drying operation cycle.</li><li>• Press [Drying Hopper] to turn on the indicator to start primary convey. Repeat press to stop the conveying cycle (This operation will stop the conveyance standby mode at once.)</li><li>• Press [No.1] to turn on the indicator and start secondary convey No.1 direction operation. Repeat press to stop the convey cycle (This operation will stop the conveyance standby mode at once).</li></ul> |
| <p>Home</p>  | <p><u>Operation under emergency</u></p> <ul style="list-style-type: none"><li>• <b>ALARM</b> which flickers to alarm abnormality. Press this key to show 「AlarmList」 for abnormality confirmation.</li><li>• Press <b>ALARM</b> to stop buzzer.</li><li>• Press [RESET] to clear all alarms, but it will not be cleared until the cause be identified and problem repaired.</li></ul>  |





| Display   | Operating method / Function and operation description  |
|---|--|
| <p>Home</p>  <p>↓</p>  | <p>Touch set-up value of drying temperature to reach numeric key.</p> <p>↓</p> <p>Set up the value by input number [0]~[9].</p> <ul style="list-style-type: none"><li>※ Press [BS] to delete one character; press [CLR] to cancel.</li><li>※ Press [ESC] to remove numeric key board and exit from the numeric input mode.</li></ul> <p>↓</p> <p>Please press [ENT] to input the number.</p> <p>NOTE</p> <p>Value allowed to set up in the home screen refers to drying SV value in  「DryingSetting」 menu, besides, only when SV2 is valid can it be changed.</p> |












| Display   | Operating method / Function and operation description  |
|---|--|
| <p data-bbox="371 353 531 387">Temp setting</p>  | <p data-bbox="767 304 1422 338">Operating method / Function and operation description</p> <p data-bbox="767 349 1422 427">Press  on home or  in various windows to go to 「DryingSetting」 window.</p> <hr/> <p data-bbox="767 443 1134 477"><u>Windows switching operation:</u></p> <ul data-bbox="767 488 1422 880" style="list-style-type: none"> <li>• Press  to go to 「Home」 window.</li> <li>• Press  to go to last window.</li> <li>• Press  to go to 「AlarmList」 window.</li> <li>• Press  to go to 「FeedSetting」 window.</li> <li>• Press  to go to 「TimerOperation」 window.</li> <li>• Press  to go to 「DryingStatus」</li> <li>• Press  to go to 「Frequency」</li> <li>• Press  to go to 「Language」 window.</li> </ul> <hr/> <p data-bbox="767 925 927 958"><u>Set up items:</u></p> <ul data-bbox="767 969 1422 1339" style="list-style-type: none"> <li>• Drying SV : to set up drying temperature for applicable material.</li> <li>• Dry Air Exhaust : to set up monitoring drying hot air temperature at exhaust port of drying hopper.</li> <li>• Dry Upper Deflection Limit : to set up deviation value of alarm for upper limits temperature.</li> <li>• Dry Lower Deflection Limit : to set up deviation value of alarm for lower limits temperature.</li> </ul> <p data-bbox="767 1395 1422 1473">※you can set up drying temperature SV in 「Home」 window.</p> |



| Display  | Operating method / Function and operation description   |
|--|---|
| <p>Temp setting</p>   | <p><u>Set up operation:</u></p> <p>If press value set up part, 「numeric keyboard」 will show in the left window.</p> <p>Press [0]～[9] to input a numeric value, and then press [ENT].</p> <p>※Press [CLR] to delete the value input.</p> <p>※set up of drying exhaust temperature must be certified by ENG setting up security level. Please operate to change security level.</p>   |
| <p>Temp setting</p>  <div data-bbox="237 1263 641 1348">[ENG setting] Password: D000</div> | <p><u>Security level change operation</u></p> <p>Press  in DryingSetting window to go to dialogue box for code input of security level change.</p> <p>Input code through the alphabet and number shown in the left photo. If press[ENT] and the code accepted, then switching key 「ENG Setting」 appear.</p> <p>During inputing, press [CLR] to delete all character at once by one time.</p> |




























| Display   | Operating method / Function and operation description  |
|---|--|
| <p>Temp setting</p>  | <p>Setting up essentials of Dry Upper Deflection Limit</p> <p>Eg. Set drying temperature upper limit above “10°C/18°F” as its alarming range, then drying upper limit deviation is “10°C/18°F”.</p>  <p><u>Take above into consideration and change drying temperature set value, then the upper limit alarming range shall adapt accordingly as it is shown below.</u></p>  <p><u>Take above into consideration and change set value of dry upper deflection limit, then the upper limit alarming range will adapt accordingly as it is shown below.</u></p>  |














| Display   | Operating method / Function and operation description  |
|---|--|
| <p>Temp setting</p>  | <p>Operating method / Function and operation description</p> <p><u>Setting up essentials of Dry Lower Deflection Limit</u></p> <p>Eg. Set drying temperature Lower limit below “10°C/18°F” as its alarming range, then drying lower limit deviation is “10°C/18°F”.</p>  <p><u>Take above into consideration and change set value of drying temperature, then the lower limit alarming range will adapt accordingly as it is shown below.</u></p>  <p><u>Take above into consideration and change set value of dry lower deflection limit, then the lower limit alarming range will adapt accordingly as it is shown below.</u></p>  |


















| Display  | Operating method / Function and operation description   |
|--|---|
| <p>Feed setting</p>   | <p>Press   in DryingSetting window or various windows to go to 「FeedSetting」 window.</p> <p><u>Windows switching operation:</u></p> <ul style="list-style-type: none"><li>• Press[  ] to go to 「Home」 window.</li><li>• Press[  ] to go to last window.</li><li>• Press   to go to 「AlarmList」 window.</li><li>• Press  to go to 「DryingSetting」 window.</li><li>• Press  to go to 「TimerOperation」 window.</li><li>• Press [  ] to go to 「BatchSetting」 window.</li></ul> <p>※Due to different specification, there will be unshown key・item.</p> |

| Display   | Operating method / Function and operation description  |
|---|--|
| <p style="text-align: center;">Feed setting</p> <br> | <p><u>Set up items:</u></p> <ul style="list-style-type: none"> <li>• Demand :<br/>Feed level confirm time starting from when feed in the drying hopper reaches to the required level to when conveyance starts.</li> <li>• Batch :<br/>Time needed for the material cut off from the discharge valve of the lower part of the drying hopper in the 1 primary convey. (discharge valve open time). To set up timer for the quoted amount in the No.1 little hopper to be completed discharged from the convey side.</li> <li>• Feed/Blow :<br/><u>drying hopper</u><br/>to set up timer for material conveyed to little hopper on the dryer.<br/><u>secondary convey No.1 direction</u><br/>timer for air blowing inside of convey piping starts from when cut off timer due (discharge valve close) to when conveyance stops.<br/>to set up timer for cut off material completely conveyed to No.1 little hopper side.</li> <li>• Discharge :<br/>Material discharge timer of each little hopper starting from when conveyance stops to when the next conveyance starts.</li> <li>• Gate Open and Gate Close :<br/>To set up valve open and close repeat time in cut off movement respectively.</li> </ul><br><p><u>Set up operation</u></p> <p>Press value set up part to go to 「Numeric keyboar」 window on the left part.</p> <p>Press [0]~[9] [.] to input a numeric value and then press [ENT].</p> <p>※Press [CLR] to delete the numeric value input.</p> |




| Display  | Operating method / Function and operation description   |
|--|---|
| <p>Run/Stop timer</p>   | <p>Operating method / Function and operation description</p> <p>Press   in DryingSetting or various windows to go to 「TimerOperation」 window.</p> <p><u>Windows switching operation</u></p> <ul style="list-style-type: none"><li>• Press [  ] to go to 「Home」 window.</li><li>• Press [  ] to go to last window.</li><li>• Press  to go to 「AlarmList」 window.</li><li>• Press  to go to 「DryingSetting」 window.</li><li>• Press  to go to 「FeedSetting」 window.</li><li>• Press [  ] to go to the next page.</li></ul>  |
| <p>Run/Stop timer</p>  | <p><u>No.1 run/stop timer set up operation is same with that of No.2.</u></p> <p>1) mode of timer set up</p> <p> shows, when it used for run timer set up.<br/> shows, when it used for stop timer set up.<br/>Each press on  or  to alternate.</p> <p>2) repeat function set up</p> <p>With timer set up, you can repeat use start/stop function,  or  shows.</p> <p>For each press on  ,  or  to alternate.</p> <p>3) to repeat week set up</p> <p>You can set up week, if the repeat function is to be set  . Press a week needed to be repeat to reverse.   </p> <p>Press it again to reverse to where it was.</p> |



















| Display   | Operating method / Function and operation description  |
|---|--|
| <p>Run/Stop timer</p> <p>(4)</p> <p>(5)</p>  | <p>4) date and time set up</p> <p>Press value set up part needed to be changed to show 「numeric keyboard」 on the left window.</p> <p>Press [0]~[9] to enter numeric value and press [ENT].</p> <p>※Press [CLR] to delete a numeric value.</p> <p>5) Press timer set up being used to reverse, this timer is effected, press it again, reverse to where it was to dismiss this function.</p>  |

















| Display   | Operating method / Function and operation description   |
|---|---|
| <p>Drying timer</p>    | <p>Press[  ] in run/stop timer set up window to go to 「DryingTimer」 window.</p> <p><u>Windows switching operation</u></p> <ul style="list-style-type: none"><li>• Press [  ] to go to 「Home」 window.</li><li>• Press [  ] to go to last window.</li><li>• Press  to go to 「AlarmList」 window.</li><li>• Press  to go to 「DryingSetting」 window.</li><li>• Press  to go to 「FeedSetting」 window.</li><li>• Press [  ] to go to 「TimerOperation」 window.</li></ul>  |
| <p>Drying timer</p> <br> | <p><u>Set up operation for Drying timer</u></p> <ol style="list-style-type: none"><li>1) Drying timer set up<br/>Press Drying timer value set up part to show the window 「numeric key」 window as on the left. press[0]～[9][.] to enter numeric value and press [ENT].<br/>※press [CLR] to delete numeric value input.</li><li>2) When temperature rising for drying andregenerative heating confirmed, and drying timer is activated, press [TEMP. rising confirm] to switch to  <b>TEMP. rising confirm</b> .</li><li>3) When drying alarm occurred, secondary side convey stop. Press [Restrain feeder while alarm is on] to switch to  <b>Restrain feeder while alarm is on</b> .</li><li>4) Hold press [DryingTimer] to reverse it, then, set up timer is in effect. Again press it to reverse to where it was and dismiss this set up.<br/><br/>When [Drying timer ON] is shown, the timer will indicate remaining time.</li></ol> |
















| Display   | Operating method / Function and operation description   |
|---|---|
| <p>ENG setting</p>    | <p>Press   in DryingSetting window or various windows to go to 「ENG Setting」 window.</p> <p>※to go to ENG Setting window must be certified by ENG Setting grade. Please operate to change security level.</p> <p><u>Windows switching operation</u></p> <ul style="list-style-type: none"><li>• Press  to go to 「Home」 window.</li><li>• Press  to go to last window.</li><li>• Press   to go to 「AlarmList」 for confirmation.</li><li>• Press  to go to 「DryingSetting」 window.</li><li>• Press  to go to 「FeedSetting」 window.</li><li>• Press  to go to 「TimerOperation」 window.</li><li>• Press  to go to 「ENG Function」 window.</li><li>• Press  to go to 「ClockSetting」 window.</li><li>• press  to go to the next page.</li><li>• press  to go the last page.</li></ul> |
| <p>ENG setting</p>   | <p><u>Set up content</u></p> <p>Please refer to the ENG setting in 「Chapter 4 controller of touch screen setting」</p> <p><u>Set up operation</u></p> <p>Press value set up part to go to 「numeric value key」 window.</p> <p>Press [0]～[9] to have numeric value input, and then press [ENT].</p> <p>※Press[CLR] to delete numeric value input.</p>  |










| Display  | Operating method / Function and operation description  |
|--|--|
| <p>ENG setting</p>  <p>(1) → Disable External Start</p> <p>(2) → Disable Operation Panel Switch</p> <p>↓</p>    | <p><u>External start up setting:</u></p> <p>1) Press [Disable External Start] to turn on the light, and external start up is in effect.</p> <p>※After the external start up is set up in effect, please set contact input of external start up ON.</p> <p>2) To combine external start up input state, in case of setting ON/OFF in operation panel in effect, please press [Disable Operation Panel Switch] to turn on the indicator.</p>   |
| <p>Clock setting</p>  | <p><u>Time setting</u></p> <p>1) Press [Clock Setting] in [ENG Function] window to go to 「ClockSetting」 window.</p> <p>2) If press value set up part to change date and time, then 「numeric value」 window shows, press [0]~[9] to have numeric value input, and press [ENT] key.</p> <p>※Press [CLR] key to remove numeric value input.</p> <p>3) for each press on value set up part, week changes, please select a appropriate week.</p> <p>4) after finishing this setting, please hold press [SET]</p> |

| Display   | Operating method / Function and operation description  |
|---|--|
| <p>Drying Status</p>  <p>① working indicator</p> <p>When [  ] flickers</p>  <p>⑤ stop working indicator</p> <p>Feeding Status</p>  | <p>Operating method / Function and operation description</p> <p>Press  <b>Status</b> in DryingSetting window or various windows to go to 「DryingStatus」 window.</p> <p><u>Window switching operation</u></p> <ul style="list-style-type: none"><li>• Press [  ] to go to 「Home」 window.</li><li>• Press [  ] to go to last window.</li><li>• Press   to go to 「AlarmList」 window.</li><li>• Press  to go to 「DryingSetting」 window.</li><li>• Press  to go to 「Frequency」 window.</li><li>• Press  to go to 「Language」 window.</li><li>• Press [  ] to go to FeedingStatus window.</li><li>• Press [  ] to go to DryingStatus window.</li></ul> <p><u>Windows display content</u></p> <ul style="list-style-type: none"><li>① present temperature of drying hot air.<br/>(hot air inlet of drying hopper)</li><li>② present temperature of drying hopper exhaust</li><li>③ present average temperature of drying hopper exhaust.</li><li>④ present status temperature of dehumidifying absorbents regenerative hot air</li><li>※ When [  ] is flickering, the present value is switched to [   ] .</li><li>⑤ the indicator turns on the each machine lit up means it is working, and it is stop working if the indicator turned off.</li></ul> <p>Feeding Status</p> <p>indicator of different function item of various convey side turned on / flickering represents the present working status.</p>  <p>Empty Batch Blow Full Error</p> |

| Display   | Operating method / Function and operation description  |
|---|--|
| <p data-bbox="343 353 560 383">Frequency select</p>  | <p data-bbox="767 309 1422 338">Press  in DryingSetting window or various windows to go to 「Frequency」 window.</p> <hr/> <p data-bbox="767 450 1126 479"><u>Windows switching operation</u></p> <ul data-bbox="767 495 1422 748" style="list-style-type: none"> <li>• Press [  ] to go to 「Home」 window.</li> <li>• Press [  ] to go to last window.</li> <li>• Press  to go to 「AlarmList」 window.</li> <li>• Press  to go to 「DryingSetting」 window.</li> <li>• Press  to go to 「DryingStatus」 window.</li> <li>• Press  to go to 「Language」 window.</li> </ul> <hr/> <p data-bbox="767 770 948 799"><u>Set up content</u></p> <ul data-bbox="767 815 1422 987" style="list-style-type: none"> <li>• Please press power supply frequency to light up the indicator.</li> <li>※Power supply frequency has already been set up since the machine shipped out of the factory.</li> </ul> |
| <p data-bbox="387 1131 512 1160">Language</p>      | <p data-bbox="767 1131 1366 1205">Press  in DryingSetting window or various windows to go to 「Language」 window.</p> <hr/> <p data-bbox="767 1227 1126 1256"><u>Windows switching operation</u></p> <ul data-bbox="767 1272 1414 1525" style="list-style-type: none"> <li>• Press [  ] to go to 「Home」 window.</li> <li>• Press [  ] to go to last window.</li> <li>• Press  to go to 「AlarmList」 window.</li> <li>• Press  to go to 「DryingSetting」 window.</li> <li>• Press  to go to 「DryingStatus」 window.</li> <li>• Press  to go to 「Frequency」 window.</li> </ul> <hr/> <p data-bbox="767 1547 991 1576"><u>Setting up content</u></p> <ul data-bbox="767 1592 1414 1621" style="list-style-type: none"> <li>• Select a proper language and set the indicator on.</li> </ul>  |

| Display  | Operating method / Function and operation description  |
|--|--|
| <p>Alarm list</p>       | <p>Press windows names of various window to go to 「AlarmList」 window.</p> <p>In case of abnormality being occurred,  flickers, press it to confirm present abnormality.</p> <p><u>Windows switching operation</u></p> <ul style="list-style-type: none"> <li>• Press [] to go to 「Home」 window.</li> <li>• Press [] to go to last window.</li> <li>• Press [] to go to 「Help」 window.</li> <li>• Press [] to go to 「AlarmHist.」 window.</li> </ul> <p><u>Abnormality confirm</u></p> <ul style="list-style-type: none"> <li>• to confirm abnormality being occurred by checking the number of abnormality.</li> <li>• In case of multi-abnormalities, please press [] [] to confirm other abnormalities.</li> <li>• Press [] to eliminate abnormality item which is been fixed</li> </ul> |
| <p>Alarm history</p>  | <p>Press [] in 「AlarmList」 window to go to 「AlarmHist.」 window.</p> <p>To confirm the windows that has abnormality occurred in the past.</p> <p><u>Windows switching operation</u></p> <ul style="list-style-type: none"> <li>• Press [] to go to 「Home」 window.</li> <li>• Press [] to go to 「AlarmList」 window.</li> </ul> <p><u>Abnormality history confirm</u></p> <ul style="list-style-type: none"> <li>• Press [][] to confirm other abnormality history list when multi-abnormalities occur.</li> </ul>   |

| Display  | Operating method / Function and operation description   |
|--|---|
| <p>Help</p>   | <p>Press [  ] in 「AlarmList」 window to go to 「Help」 window, which is able to show various helps content.</p> <p><u>Windows switching operation</u></p> <ul style="list-style-type: none"><li>• Press [  ] to go to 「Home」 window.</li><li>• Press [  ] to go to last window.</li><li>• Press item label to go to its help ontent.</li><li>• Press[  ] [  ] to go between pages.</li></ul> |

## 5. Machine unit usage regulation

The handling explanation of each unit equipment built in this device (Especially, about notes) is described.


Please observe notes described in this manual when you use this device and unit equipment.

### [Model: Branch Damper](Item no.: PD3-φ38 (φ50))

#### 1. Usage regulation




|                          |  |
|--------------------------|--|
| ●Notice the finger       | While connecting the power supply and supplying the compressed air, please do not stretch the finger or hands into the damper box. Take care to avoid lacerations to fingers or hands and danger of getting hurt.  |
| ●Maintenance and repair  | Never ask unqualified personnel who do not have a sufficient knowledge of this equipment to maintain and repair in order to avoid accident and danger.   |
| ●Maintain and inspection | <p>Before inspection and cleaning, please cut off power supply of electric box that controls the branch damper. Set 3-directional manual valve installed to PD3 OFF, and remove remaining pressure inside of cylinder. (Please refer to Name of each components and method of cylinder disassembly on item 2).</p> <p>(For further information about electric-controlled box controlling PD3, please refer to relevant part in this manual.)</p> <p>After inspection and cleaning, please make sure to have cylinder components mounting bolts and all bolts firmly fastened.</p> <p>In case of maintenance and repair, please contact your nearest Matsui after-sales office.</p> |




|                 |   |
|-----------------|---|
| ●Warning labels | Please keep the label legible until you dispose of this unit. |
|-----------------|---|

\* While switching the valve, material overflow may occur by different material. However, this is normal, not device abnormality.

2. Names of all components and cylinder components disassembly method



6. Outer dimension (mm)







|                   |      |      |      |       |
|-------------------|------|------|------|-------|
| Model             | -150 | -350 | -650 | -1500 |
| W (mm)            | 1125 | 1191 | 1486 | 1910  |
| D (mm)            | 618  | 618  | 638  | 914   |
| H (mm)            | 2117 | 2203 | 2509 | 2689  |
| Gross weight (kg) | 270  | 290  | 400  | 690   |





# Chapter 3. Installation

## 1. Equipment installation

| Step | Item                   | Operation Content  |
|------|------------------------|--|
| 1    | Installation of Device | <p>Please install it on the smooth ground.</p> <p>The installation site is shown in the following drawing. Please set aside some room for maintenance and item-by-item checking.</p>  |
| 2    | Caster brake           | <p>As it is shown in below picture, step on the brake of the caster with brake.</p>    |

| Step | Item               | Operation Content   |
|------|--------------------|---|
| 3    | Movement of Device | <p>Please confirm if the eye bolts, which are used to trice the device to move on the top of the device, are reliably tightened up. Then hang the rope that has hook at each end and use your company's crane to trice the device to move. In addition, the stuff in the hopper must be cleared up before the device is triced.</p>  <p style="text-align: center;">  <b>Caution</b> </p> <p>Be sure to use a hoisting rope (with hook) which can withstand the mass of the unit.</p> |

| Step | Item   | Operation Content  |
|------|--|--|
| 4    | Installation of the Small hopper on the Molding Machine and Connection of the Hose | <ul style="list-style-type: none"> <li>- Install a hopper on the molding machine.<br/>Install surely with the gasket and the bolt for without the air leakage.</li> <li>- Please connect PVC hose and the suction nozzle for primary convey.<br/>Fasten up the connection part surely by the hose band.</li> <li>- Connect PVC hose for the secondary convey.<br/>Fasten up the connection part surely by the hose band.</li> <li>- Connect white GL hose for the suction of secondary convey.<br/>Fasten up the connection part surely by the cuff and hose band.</li> </ul> <p>[Standard specification (Secondary convey No.1 direction)]</p> <p>Hopper on the molding Machine of secondary convey No.1 direction</p> <p>White GL hose for the suction of secondary convey</p> <p>PVC hose for the primary convey</p> <p>White GL hose for suction of primary convey</p> <p>Signal line</p> <p>PVC hose for secondary convey</p> <p>Suction nozzle</p> |



| Step | Item   | Operation Content   |
|------|--|---|
| 5    | Installation of the Small Hopper on the Molding Machine and Connection of the Hose | <p>[Option specifications( Secondary convey 2 directions)]</p> <p>Hopper on the molding machine of secondary convey No.2 direction</p>  <p>Hopper on the molding machine secondary convey No.1 direction</p> |
| 6    | Connection of compressed air   | <p>Please connect compressed air piping to supply port of primary convey of filter regulator.</p>  <p>Compressed air supply port: <math>\phi 6</math> (for air hose)</p>                                    |

2. Power supply connection



| Step       | Item                            | Operation Content  |           |             |     |  |                       |     |           |             |     |  |                       |     |           |             |     |  |                       |     |            |               |            |  |                         |          |
|------------|---------------------------------|--|-----------|-------------|-----|--|-----------------------|-----|-----------|-------------|-----|--|-----------------------|-----|-----------|-------------|-----|--|-----------------------|-----|------------|---------------|------------|--|-------------------------|----------|
| 1          | Connection of power supply wire | <p>Please open the item-by-item checking door of the electric-controlled box and connect the power supply wire from the electric-controlled box to the 3-Phase AC power supply of protective device of your company.</p> <table><tr><td>MJ5-i-150</td><td>200, 220VAC</td><td>30A</td></tr><tr><td></td><td>380, 400, 415, 440VAC</td><td>15A</td></tr><tr><td>MJ5-i-350</td><td>200, 220VAC</td><td>30A</td></tr><tr><td></td><td>380, 400, 415, 440VAC</td><td>15A</td></tr><tr><td>MJ5-i-650</td><td>200, 220VAC</td><td>50A</td></tr><tr><td></td><td>380, 400, 415, 440VAC</td><td>30A</td></tr><tr><td>MJ5-i-1500</td><td>200, (220)VAC</td><td>100A(125A)</td></tr><tr><td></td><td>380, 400, 415, (440)VAC</td><td>63A(50A)</td></tr></table> <p>●Protective device: circuit breaker, leakage breaker, fuse, etc</p> <p>* If the power supply wire is not attached, please connect power supply wire from equipment protective device to primary side of main switch QS1 inside of electric-controlled box.</p> <p>[Electric-controlled box]</p> <div><div><p>Main switch QS1</p><p>MJ5-i-150~650</p></div><div><p>Main switch QS1</p><p>MJ5-i-1500</p></div></div> <div><p>Caution</p><ul style="list-style-type: none"><li>- Be sure to turn the power supply switch to “OFF” before connecting the power supply wire.</li><li>- Connect the power supply correctly and ensure that the joint isn’t loose.</li><li>- The earth wire must be tightly connected.</li></ul></div> | MJ5-i-150 | 200, 220VAC | 30A |  | 380, 400, 415, 440VAC | 15A | MJ5-i-350 | 200, 220VAC | 30A |  | 380, 400, 415, 440VAC | 15A | MJ5-i-650 | 200, 220VAC | 50A |  | 380, 400, 415, 440VAC | 30A | MJ5-i-1500 | 200, (220)VAC | 100A(125A) |  | 380, 400, 415, (440)VAC | 63A(50A) |
| MJ5-i-150  | 200, 220VAC                     | 30A  |           |             |     |  |                       |     |           |             |     |  |                       |     |           |             |     |  |                       |     |            |               |            |  |                         |          |
|            | 380, 400, 415, 440VAC           | 15A  |           |             |     |  |                       |     |           |             |     |  |                       |     |           |             |     |  |                       |     |            |               |            |  |                         |          |
| MJ5-i-350  | 200, 220VAC                     | 30A  |           |             |     |  |                       |     |           |             |     |  |                       |     |           |             |     |  |                       |     |            |               |            |  |                         |          |
|            | 380, 400, 415, 440VAC           | 15A  |           |             |     |  |                       |     |           |             |     |  |                       |     |           |             |     |  |                       |     |            |               |            |  |                         |          |
| MJ5-i-650  | 200, 220VAC                     | 50A  |           |             |     |  |                       |     |           |             |     |  |                       |     |           |             |     |  |                       |     |            |               |            |  |                         |          |
|            | 380, 400, 415, 440VAC           | 30A  |           |             |     |  |                       |     |           |             |     |  |                       |     |           |             |     |  |                       |     |            |               |            |  |                         |          |
| MJ5-i-1500 | 200, (220)VAC                   | 100A(125A)   |           |             |     |  |                       |     |           |             |     |  |                       |     |           |             |     |  |                       |     |            |               |            |  |                         |          |
|            | 380, 400, 415, (440)VAC         | 63A(50A)   |           |             |     |  |                       |     |           |             |     |  |                       |     |           |             |     |  |                       |     |            |               |            |  |                         |          |



# Chapter 4. Preparation for Operation

## 1. Inspecting inside of the drying hopper


| Step | Operation Content   |
|------|---|
| 1    | Please open drying hopper cover and confirm that there is no resin in it, then open the item-by-item checking drying hopper door and confirm that there is no impurity in the hopper.   |
| 2    | <p>Please check diffuser installation and see if the pin is in the hole or not.</p>  <p style="text-align: center;">MJ5-i-150~650                      MJ5-i-1500</p>  |
| 3    | <p>Please confirm if the damper and residue discharge port at the bottom of the drying hopper is closed or not.</p> <p>Damper: push→close , pull→open</p>  <p style="text-align: right;">Air regulating filter of secondary side<br/>This device is not existed while dehumidifying air is cycling.</p> |

## 2. Condition affirmation of each unit

| Part Name                      | Confirmation Content   |
|--------------------------------|--|
| Drying Filter<br>Convey Filter | <p data-bbox="547 443 1445 618">Please loosen the knob to detach filter lid and confirm if gasket and filter are properly installed inside the filter box.<br/>Please use the knob handle to screw down the cover so as to prevent the air from leaking out.</p> <p data-bbox="866 683 986 712">[Filter box]</p>  |
| Regeneration Filter            | <p data-bbox="547 1317 1445 1397">Please confirm that the filter is connected to the suction inlet of blower fan as the following drawing shows.</p>   |


| Part Name                                      | Confirmation Content   |
|--|--|
| Jet Clone<br>Hoppers on the<br>molding machine | <p data-bbox="485 353 1166 387">Please install the filter properly and the gasket as well.</p>  <p data-bbox="772 465 799 488">Lid</p> <p data-bbox="746 539 799 562">Filter</p> <p data-bbox="746 613 820 636">Gasket</p> <p data-bbox="715 712 783 734">hasp</p>   |
| Hose   | <p data-bbox="485 913 1414 1037">Please confirm if each hose tube is correctly connected according to the installation item, especially confirm if the larynx-hoop is reliably tightened up to avoid air leakage.</p>  |
| Pressure Setting of the Filter Regulator       | <p data-bbox="485 1059 1414 1137">Please open slide valve and use regulator to set the pressure. The setting pressure is 0.39~0.59MPa</p>  <p data-bbox="555 1234 804 1294">Slick valve (stop valve)<br/>close⇌open</p> <p data-bbox="1091 1234 1251 1256">Filter regulator</p> <div data-bbox="847 1682 970 1749" style="border: 1px solid black; padding: 5px; text-align: center;"> <b>Note</b> </div> <p data-bbox="478 1760 1414 1839">If slick valve (stop valve) moves to close side, air from top of the filter regulator comes off the slick valve.</p> |














| Part name                         | Confirmation Content   |
|-----------------------------------|--|
| Hopper on molding machine         | Please confirm sensor installing position if it is proper and the feed level sensor is surely fastened.  |
| Install part of feed level sensor | <div>Please keep the observing window surface clean.</div> <div><p>The diagram shows a vertical hopper assembly. At the top is a rectangular hopper with a circular opening on its side. Below it is a conical section leading to a horizontal pipe. Further down is another rectangular section with a vertical pipe on its side. A feed level sensor is mounted on the side of this section, with a label 'Feed level sensor' and an arrow pointing to it. Below the sensor is an observing window, with a label 'Observing window' and an arrow pointing to it. The bottom of the assembly is a conical section leading to a rectangular base.</p></div> |

### 3. Power supply







Please follow below steps to provide power to electric-controlled box.

| Step | Operation Item                                     | Operation Content   |
|------|--|---|
| 1    | ON operation inside of the electric-controlled box | <p>Please open the door of electric-controlled box on the right side and set all devices inside "ON".</p> <p><b>【Inside of electric-controlled box】</b></p>  <p>The diagram illustrates the internal components of the electric-controlled box for two models: MJ5-i-150~650 and MJ5-i-1500. The components are arranged in a rack with terminals labeled TA1, TA2, OP5-2, XT1, and KA 0. The components include:</p> <ul style="list-style-type: none"><li>QM1: Main switch</li><li>FS1...4: Fuses</li><li>FS5: Fuse</li><li>FS6,7: Fuses</li><li>FS3...5: Fuses</li><li>FS1: Fuse</li><li>FS6: Fuse</li><li>FS7,8: Fuses</li></ul> <p>The diagram also shows the internal wiring and the position of the components within the rack.</p> |

| Step | Operation Item                                      | Operation Content  |
|------|---|--|
| 2    | ON operation inside of the electric -controlled box | <p>●Please set below miniature circuit-breakers and molded-case circuit-breakers “ON”</p> <ul style="list-style-type: none"> <li>- FS1: for drying, regenerative blowers and heating tube power supply use</li> <li>- FS3: for drying heating tube power supply use</li> <li>- FS4: for regenerative heating tube power supply use</li> <li>- FS5: for operating power supply[MJ5-i-150~650]<br/>for conveying blower power supply use[MJ5-i-1500]</li> <li>- FS6: for operating power supply</li> <li>- FS7: for operating power supply</li> </ul> <div style="display: flex; align-items: center; justify-content: center;"> <div style="text-align: center;"> <p>[OFF state]</p>  </div> <div style="margin: 0 20px;"> <p>Pull up the black knob as the arrow shows</p>  </div> <div style="text-align: center;"> <p>[ON state]</p>  <p>Green change to red</p> </div> </div> <p>●Please set motor starter “ON”</p> <ul style="list-style-type: none"> <li>- QM1: for conveying blower power supply use[MJ5-i-150~650]</li> </ul> <div style="display: flex; align-items: center; justify-content: center;"> <div style="text-align: center;"> <p>[OFF state]</p>  </div> <div style="margin: 0 20px;">  </div> <div style="text-align: center;"> <p>[ON state]</p>  </div> </div> <p>Please turn the black knob from “o” position to “I”</p> <div style="border: 1px solid black; padding: 5px; text-align: center; margin: 10px auto; width: fit-content;"> <p>Note</p> </div> <p>Please make sure to close the door of electric-controlled box after finishes this work.</p> |


| Step | Operating Item            | Operation Content   |
|------|---------------------------|---|
| 3    | Power source supply       | <p>Please turn main switch knob to the right side of the control panel to “I”</p> <p>The touch screen of the operating panel shows “Initial Display”, then in a few seconds, it goes to “Main menu”.</p> <p>[Right Side of Electric-Controlled Box]</p> <p>Turn main switch knob to “I” position</p>  <p>[Control Panel]</p> <p>Touch screen</p> <p>Stand-by Switch</p>  <p>Initial display</p>  <p>Home</p>  |
| 4    | Preparation for operation | <p>Please press [⏻] of Stand-by switch on the operating panel to light up the indicator.</p>  <p><b>Caution</b></p> <p>If the lamp is not lit, please check the power cord and power supply connection.</p>  |



## 4. To confirm the correct rotating direction of blower



| Step | Operating Item        | Operation Content  |
|------|-----------------------|--|
| 1    | Take off the hose     | <p>When the hose of inhaling port of dryer hopper is taken off that is connected in Chapter 3 Installation.</p>    |
| 2    | No-load conveyance    | <p>Press [⏻] of Stand-by button on operation panel, then press “” on main menu and run no-load conveying.</p> <p>[Control Panel]</p>     |
| 3    | Inhaling confirmation | To make sure that air is being taken in from the inhaling port of dryer hopper.  |
| 4    | Convey stopped        | <p>After confirmed inhaling, please press the “” on main menu again to stop conveying.</p> <div style="text-align: center;">  <b>Caution</b> </div> <p>If you find air exhaust from inhaling port of dryer hopper, it means the electrical cable was connected with wrong phases.</p> <p>Please interchange 2 of 3 electrical cables to correct the phase.</p> <p>Having corrected the phase, please go back to Step 2, repeat the operation and confirm the inhaling.</p> |
| 5    | Re-connect hose       | Having confirmed inhaling, please re-connect the hose which was taken off before.  |

## 5. Controller of touch screen setting


For all detailed information about windows alternating operation and set up operation, please refer to “Chapter 2. Equipment Explanation - 4 Name and Function of each controller part of touch screen”.



| Display  | Set up Content   |           |                          |  |  |          |           |           |       |                            |  |  |       |      |      |      |
|--|--|-----------|--------------------------|--|--|----------|-----------|-----------|-------|----------------------------|--|--|-------|------|------|------|
| <p>Temperature setting</p>  | <p><u>Drying SV</u> (Initial value: 80°C/176°F)<br/>To set up material drying temperature</p> <p><u>Dry Air Exhaust</u> (Initial value: 50°C/122°F)<br/>To set up monitoring temperature for hot-air at the port of drying hopper exhaust.</p> <p><b>Note</b><br/>Please refer to below table to set up drying exhaust temperature.<br/>In addition, when material temperature (Resin temperature before drying) reaches to above 35°C , please set the drying exhaust temperature +10°C above that of the applicable material.</p> <p>Below shows the standard set up value of drying exhaust temperature on general applicable material, such as ABS (drying temperature 80°C), PBT(drying temperature 130°C) and PET(drying temperature 160°C). And in particular for those material requiring moisture control below 0.01%(100ppm) for molding, please set their standard drying exhaust temperature above 50°C</p> <table><tr><th rowspan="2">Item</th><th colspan="3">Resin drying temperature</th></tr><tr><th>ABS 80°C</th><th>PBT 130°C</th><th>PET 160°C</th></tr><tr><th>Model</th><th colspan="3">Drying exhaust temperature</th></tr><tr><td>MJ5-i</td><td>40°C</td><td>40°C</td><td>50°C</td></tr></table> <p>Condition: Suction air 30°C, rh75% (dp+25°C)<br/>Drying hour: 3 h (ABS/PBT), 4 h (PET)<br/>Applicable material temperature 20~30°C<br/><b>* As for those material that are not applicable here, please pay particular attention to that, and consult Matsui in advance</b></p> | Item      | Resin drying temperature |  |  | ABS 80°C | PBT 130°C | PET 160°C | Model | Drying exhaust temperature |  |  | MJ5-i | 40°C | 40°C | 50°C |
| Item   | Resin drying temperature   |           |                          |  |  |          |           |           |       |                            |  |  |       |      |      |      |
|  | ABS 80°C   | PBT 130°C | PET 160°C                |  |  |          |           |           |       |                            |  |  |       |      |      |      |
| Model  | Drying exhaust temperature   |           |                          |  |  |          |           |           |       |                            |  |  |       |      |      |      |
| MJ5-i  | 40°C   | 40°C      | 50°C                     |  |  |          |           |           |       |                            |  |  |       |      |      |      |


| Display  | Set up Content  |
|--|---|
| <p style="text-align: center;">Temperature setting</p>  | <p><u>Dry Upper Deflection Limit</u> (Initial value: 10°C/18°F)<br/>To set up upper limit alarm range on drying temperature set value.<br/>* Matsui's recommended initial value 10°C/18°F. If it is set too low, machine will stop operation due to sensing abnormality caused by drying.</p> <p><u>Dry Lower Deflection Limit</u> (Initial value: 10°C/18°F)<br/>To set up lower limit alarm range on drying temperature set value.<br/>Sense abnormality and give out emergency signal, machine will keep working. And, if abnormality avoided, machine will reset automatically.</p>   |
| <p style="text-align: center;">Feed setting</p>        | <p><u>Drying Hopper Feed Setting</u><br/><u>Demand</u> (Initial value: 5s)<br/>Set feed level confirm time needed for feed inside of drying hopper reaching set feed level until it goes to convey mode.</p> <p><u>Feed/Blow</u>(Initial value:[-150/350] 6s, [-650]23s, [-1500]16s)<br/>Time needed for feed to be conveyed to receiving hopper on the dryer.<br/>Timer set up for feed to be conveyed by 8 times to the receiving hopper on the dryer. The amount of feed to be conveyed will differ by different material, so make sure to adjust the time at actual conveyance.</p> <p><u>Discharge</u> (Initial value: 10s)<br/>Timer set up for receiving hopper discharge of primary convey, from when feed-in convey stops to the next feed-in convey starts.</p> |

| Display   | Set up Content   |
|---|--|
| <p>Feed setting</p> <br> | <p>No.1 Direction Feed Setting</p> <p><u>Demand</u> (initial value: 5s)<br/> Timer set up for feed level confirm of receiving hopper secondary convey No.1 direction, from when required level reaches to the moment when feed-out convey starts.</p> <p><u>Batch</u> (initial value: [-150~650] 11s, [-1500] 35s)<br/> Timer set up for material cut off from discharge valve on lower part of drying hopper of primary convey (discharge valve open time). Set up timer for secondary convey No.1 direction receiving hopper required amount to be completely discharged from drying hopper.</p> <p><u>Feed/Blow</u> (initial value: 10s)<br/> Timer set up for blowing and cleaning inside of convey piping, from when cut off timer is due --- discharge valve closes to when convey stops.<br/> Set up timer for material cut-off to be completely conveyed to No.1 receiving hopper.</p> <p><u>Discharge</u> (Initial value: 10s)<br/> Timer set up for material discharge of No.1 direction receiving hopper, from when convey stops to the next convey starts.</p> <p><u>Gate Open and Close</u> (initial value: open: 2.0s, close: 3.5s)<br/> <br/> Timer set up for cut off valve's repeat open and close within set material cut off time.<br/> If extend damper open time and shorten its close time, amount conveyed will increase.<br/> <br/> Damper opens and closes within material cut-off timer; therefore, when alter cut off time, please adjust the total time of damper open and close to make sure it is in consistency with cut off timer.</p> |





| Display   | Set up Content  |
|---|---|
| <p>Run/Stop timer</p>  | <p>To set up for using “Run / Stop timer”</p> <p> <u>Run mode</u> (initial value: no value set up)<br/>Set up specific date and time or time for repeat for start up operation.</p> <p> <u>Stop mode</u> (initial value: no value set up)<br/>Set up specific date and time or time for repeat for Stop operation.</p>  |
| <p>Drying timer</p>   | <p>To set up timer for secondary convey starts to delay</p> <p> <u>Drying time</u> (initial value: no value set up)<br/>Set up timer that amounts to initial drying time.<br/>(planned drying time)<br/>Secondary convey only starts when set up timer is due.</p> <p> <u>TEMP. rising confirm</u> (initial value: no value set up)<br/>When temperature rising for drying and regenerative heating confirmed, drying timer is activated.</p> <p> <u>Restrain feeder while alarm is on</u> (initial value: no value set up)<br/>When drying alarm occurred, secondary side convey stop.</p> <p><b>Note</b><br/>When drying timer ON, you can not Conveying in spite of the start / stop of the drying. Either stop the drying timer, or drying is complete and the conveying will be possible.</p> |


| Display  | Set up Content  |
|--|---|
| <p style="text-align: center;">ENG Setting</p>    | <p>Drying Hopper Feed Alarm Time setting</p> <p><u>Feed Alarm Time</u> (Initial value: 30min)</p> <p>Set up timer from when drying hopper convey in starting up to until when it alarms for continuing level empty.</p> <p>Monitor drying hopper convey abnormality.</p><br><p><u>Count Alarm</u> (Initial Value: 50 times)</p> <p>Set up over full-level frequency during drying hopper conveying</p> <p>Monitor drying hopper convey decrease abnormality.</p><br><p><u>Level Alarm</u> (Initial value: 10 times)</p> <p>Set up No.1 or No.2 convey frequency from when drying hopper reaches full level to when its empty level tested.</p> <p>Monitor discharge abnormality inside of drying hopper.</p><br><p>No.1 Direction Feed Alarm Time setting</p> <p><u>Feed Alarm Time</u> (Initial value: 180s)</p> <p>Set up timer from when No.1 convey in starting up to until when its receiving hopper alarms for continuing level empty.</p><br><p>Monitor No.1 convey abnormality.</p> |
| <p style="text-align: center;">ENG Setting</p>  | <p><u>Dust Box Cleaning</u> (Initial value: No set)</p> <p>Set up convey frequency by using alarms to notify dust collecting bin cleaning time.</p> <p>In case of conveying more dust, please set up frequency before dust collecting bin reaches full level.</p> <p>You can waive this function by setting value "0"</p>   |

| Display  | Set up Content  |
|--|---|
| <p>ENG Setting</p>  | <p><u>External Start</u> (Initial value: Disable)<br/>You can set external start up ON, when using external start up signal input or weekly timer option.</p> <p><u>Operation Panel Switch</u> (Initial value: Disable)<br/>Please set up remote status when using external start up signal input or weekly timer option.</p> |

## 6. Temperature setting up of the overheat protector

For safety, this unit has an overheat protector, that serves as a safety device for drying and regenerating heat tube, as its standard equipment. If the sensor (temperature detector) reaches a temperature higher than the temperature setting of the overheat protection device, the power supply to the heater is cut off. In this situation, heating tube and blower (drying, regenerating, conveyance) also stops. In addition, the set up device of overheat protector is installed in the electric control box to regulate the overheat test temperature.

| Step | Operating Content   |
|------|---|
| 1    | <p>Set the temperature setting of the overheat protector to a value 20°C/36°F higher than the drying temperature (SV temperature setting). When temperature set up revision is needed, rotate dial to 220°C/428°F firstly, then to needed temperature. For the standard specifications, please use the temperature setting of the overheat protector under 180°C/356°F</p> <div><div><p>Drying temperature<br/>overheat protector</p><p>Setting temperature<br/>Dry temperature +20°C (36°F)</p></div><div><p>[ Mark ]</p></div></div> <p>The temperature controller has upper and low limit alarm settings. When the upper limit alarm occurs, turn the heater OFF and, after the cooling time has elapsed, the blower is turned OFF, operation stops.<br/>(Both the upper and low limits are set to 10°C/18°F at the factory before shipping.)</p> |

|   |   |
|---|---|
| 2 | <p>Regeneration overheat protector unit (Bimetal thermostat)</p>  <p>Regeneration overheat protector unit<br/>A-255 255°C setting</p>  |
| 2 | <p>When a sensor (measurement temperature part) is heated exceeding the setting temperature of overheat protector, the operation power is cut off, the heater, blower stops. <b>ALARM</b> which flickers to alarm abnormality, and the buzzer rings. After cooling the heating part sufficiently, identify the cause and fix the trouble, you can restart the unit. (Please refer to Chapter 5. Operating Procedures) . Besides, if the sensing temperature is still above the set temperature, the operating power supply shall not be connected even preparation switch is pressed.</p> |
| 3 | <p>If the sensor (temperature detector) reaches a temperature higher than the temperature setting of the overheat protector, the unit is automatically shut off, and the heater overheated alarm is triggered.</p> <p style="text-align: center;"><b>CAUTION</b></p> <p>When the heater overheated alarm is triggered, perform the recovery operation according to "Chapter 7 Alarm Function" and "Heater Overheated."</p>  |

**NOTE**

When the overheat protector is tripped, the unit requires one hour or longer to cool.

The overheat protector will not reset while the unit is still insufficiently cooled. As the recovery operation cannot be performed in this state, please allow the heater to cool sufficiently before recovery.

## 7. Jet Clone Operation

Start up the feed convey to drying hopper, set up the timer for discharge, and the timer for the blower to start operation. When the blower starts operating, the baffle will be closed.



Feed will be conveyed to Jet clone according to timer for conveyance.



The blower will stop when the timer for conveyance used up.

If suction pressure is low, baffle of the Jet clone opens, and feed will be discharged to drying hopper on the lower part within the discharge timer.



Repeat above steps.



When drying hopper is full, Jet clone stops convey according to the signal by limit switch installed on the Jet clone.






After that, even though the stuff decreases and the limit switch gives the require signal, the blower will not start until secondary convey completely finished, and delayed, in this way, the damper may not occlude.

### Damper operations

(1) Natural state

(2) Close condition (suction type)

(3) Material full condition  
(Limit switch operates,  
Material convey stops)



## 8. Outline of Aero Power Hopper

This is a material conveyance hopper installed onto the molding machine.

This has the following features by flowing conveying material in hopper.


- ① Fine powders and particles are separated and removed.
- ② If crushed material is compounded, natural pellets and crushed material are mixed.

### 1. Inspection before use

- ① Check that there is no unnecessary material in the hopper.
- ② Check that the filter and packing are correctly installed with reference to the attached drawings at end.

### 2. Installation to molding machine

#### Overview



Refer to the overview

(Referential example APH-3)

- ① Install this hopper onto molding machine via the mating base with bolts.
- ② Connect the suction piping and material piping. Securely fix the piping using hose bands so as to prevent air leakage.
- ③ Connect electric wires to the sensor.

### 3. Test run adjustment

#### 1. Sensor sensitivity adjustment (Proximity switch E2K type)

If the presence or absence of the material is not correctly detected, adjust the sensitivity of the proximity switch by the following procedure.


- (1) Remove the material in the hopper.

Turn “ON” the power for the conveying origin unit.

- (2) Check whether there is clearance of 1mm or more between the end of the sensor and hopper peep hole.

In the case of clearance, loosen the tightening screws (two pieces) for the proximity switch fixing bracket, and adjust the distance between the end of the sensor and hopper peep hole to about 1mm and fix them.


- (3) Remove the rubber cap on the back of the proximity switch.



- (4) Adjust the sensitivity adjust screw with the included screw driver and perform operations in the following ①, ② and ③.

- ① Adjust the screw to a point where the sensor turns OFF from ON with no material (Detection indicator lights off).
- ② Adjust the screw to a point where the sensor turns ON from OFF with material being loaded (Detection indicator lights up).
- ③ Set the sensitivity adjust screw to a middle point between ① of turning OFF from ON with no material and ② of turning ON from OFF with material being loaded.

Note: Adjust with material to be actually used. Also, in the case of various materials, perform the operations of ①, ② and ③ with material whose apparent specific gravity is lightest.



- (5) Install the rubber cap removed in procedure (3).


Convey material to check that the presence or absence of material is correctly detected.



## 2. Adjustment of sensor installing position (Not applicable to APH-1 type)

The sensor can be moved up and down by slightly loosening the M5 screws (two pieces) fixing the sensor bracket and plastic bracket.

Securely tighten the M5 screws (two pieces) after adjustment.



### (1) When conveying material from one conveying origin unit to one molding machine (One-by-one conveyance)

Adjust the sensor position so that conveyance starts at any material amount according to the material consumption of the molding machine.

For dried material, quality of the molded product is generally improved with a shorter dwelling time on the molding machine.

<Material conveying amount for one time can be adjusted by the conveying origin unit. Adjust it to a conveying amount equal to or less than the maximum conveying amount of the applicable model. For the maximum conveying amount, refer to 7. Specifications.>

### (2) When conveying material from one conveying origin unit to two molding machines (One-by-two conveyance)

Adjust the sensor position so that the entire conveying material amount is reliably loaded into the lower hopper and conveyance starts.

<Material conveying amount for one time can be adjusted by the conveying origin unit. Adjust it to a conveying amount equal to or less than the maximum conveying amount of the applicable model. For the maximum conveying amount, refer to 7. Specifications.>

#### Note

A damper is provided between the upper hopper and the lower hopper. When conveying material remains in the damper part, conveyance failure result.

## 4. Maintenance and check

### 1. Cleaning of filter

A filter (porous plate made of stainless steel) is provided in the upper hopper. As it is clogged with fragments of crushed material, regularly remove them.

### 2. Damper


A damper is incorporated in the upper hopper discharge part. This damper is suspended by two stainless steel wires of 0.5mm.

These wires have sufficient strength and will not be cut during normal use, however, regularly check them when cleaning.

The conveyed material flows in the upper hopper in a normal state, however, if the above wires are cut, the conveyed material directly falls into the lower hopper. If such a state is observed, also check the wires.


## 5. Precautions

### 1. Lock for catch clip



A lock mechanism is provided to prevent catch clips (6 locations) from being released due to vibration of molding machine or unintended operation. Be sure to lock when using the clips.

### 2. Grating



A grating is attached to APH-9 and APH-18. This is for preventing the damper from falling into the hopper opening of the molding machine even if the wires are cut. Be sure to install the grating to the hopper opening of the molding machine, and attach it even when relocating.

## 6. Specifications

|   |          |     |                   |     |                   |     |     |
|---|----------|-----|-------------------|-----|-------------------|-----|-----|
| Model APH-  | 1        | 3   | 3W                | 6   | 6W                | 9   | 18  |
| Conveying pipe caliber (mm)                         | 38       | 38  | 38                | 50  | 50                | 50  | 50  |
| Suction pipe caliber (mm)                           | 38       | 38  | 38                | 65  | 65                | 65  | 65  |
| Maximum conveying amount (kg)                       | 1        | 1   | 1                 | 2   | 2                 | 3   | 6   |
| Conveying hopper capacity (L)                       | 4        | 4   | 4                 | 8   | 8                 | 12  | 24  |
| Conveying hopper diameter (mm)                      | 140      | 140 | 140               | 200 | 200               | 245 | 300 |
| Charge hopper capacity (L)<br>(Demand level switch) | 0.8      | 3   | 3<br>+allowance 2 | 6   | 6<br>+allowance 4 | 9   | 18  |
| Charge hopper diameter (mm)                         | 50A pipe | 140 | 200               | 200 | 245               | 245 | 300 |







Applicable unit model / MJ3 MGD(\*1) These are general guidelines and it is absolutely necessary to calculate from the molding cycle time and weight per one shot. Selected on the assumption that the drying time is three hours.







|                                     |       |        |         |         |     |         |   |
|-------------------------------------|-------|--------|---------|---------|-----|---------|---|
| Secondary conveyance one direction  | 15/25 | 15~150 | —       | 200/300 | —   | 200/300 | — |
| Secondary conveyance two directions | —     | 15~75  | 100/150 | 200     | 300 | 200/300 | — |







Applicable unit model/ DMD4 (\*1)(\*2) When applied to DMD4, it is necessary to be compatible with optical specifications.








|                                     |   |        |         |   |   |   |   |
|-------------------------------------|---|--------|---------|---|---|---|---|
| Secondary conveyance one direction  | — | 25~200 | —       | — | — | — | — |
| Secondary conveyance two directions | — | 25/50  | 100/200 | — | — | — | — |

# Chapter 5. Operating Procedure

| Steps | Operating Item                      | Operation Content   |
|-------|-------------------------------------|---|
| 1     | Preparation for operation           | <p>Please press [  ] of ready switch on the operating panel to lighten up the indicator.</p> <p>【Operating panel】</p>  <p>Touch screen</p> <p>Stand-by switch [  ]</p>   |
| 2     | Material conveyed to drying hopper. | <p>Please press [  ] in the main menu to set the indicator up, at this moment, material started to be conveyed to drying hopper.</p> <p>Besides, please make sure to confirm if material convey is over or not.</p>  <p>【Use stuff-absorbed lance to regulate the secondary air suction quantity】</p> <p>Please insert the stuff-absorbed lance into the conveying side, then rotate the secondary air regulation ring to regulate so as to successfully convey the stuff.</p> <p>Secondary Air Regulating Ring</p>  <p>If the secondary air regulation ring is over-rotated, it may cause the stuff jammed in the conveying hose.</p> |

| Steps | Operating Item           | Operation Content  |
|-------|--------------------------|--|
| 3     | Drying started           | <p>Please hold press [  ] in main menu to lighten up the indicator.<br/>Drying starts.</p> <p>In case of setting up timer for machine start up, dry operation begins after the timer is due.</p>    |
| 4     | Secondary convey starts  | <p>Please press [  ] in main menu to set indicator on.<br/>Secondary convey No.1 direction starts.</p>  <p> Caution</p> <p>Material shall be conveyed to the molding machine, only when they are sufficiently dried for the initial stage. If material are not sufficiently dried, molding defects shall occur.</p> |
| 5     | Operating status confirm | <p>With [DryingStatus] window, you can confirm temperature status of each part during drying operation and machine working status.</p>   |

| Steps | Operating Item   | Operation Content  |
|-------|--|--|
| 6     | Operating status confirm   | <p>Press [  ] in [DryingStatus] window to go to 「FeedStatus」 window and confirm each stuff convey status.</p>  <p>Press [  ] to go to 「DryingStatus」 window.</p>   |
| 7     |  Operating status confirm | <p>When [  ] in main menu flickers, this machine is in lasting drying working condition.</p> <p>This machine seems to stop working from the outlook, but actually, it is still in normal working operation.</p> <p>Besides, present value of drying temperature also goes lower than that of the set up value, but that is not abnormal.</p>  |





| Steps | Operating Item                              | Operation Content   |
|-------|---|---|
| 8     | Operations stop                             | <p>Please follow below steps to stop operation:</p> <p>(1) Please press [  ] on the main menu to stop material convey to the drying hopper. When this operation is applied during material convey, the convey cycle stops. ( [  ] flickering→off )</p> <p>(2) Please hold press [  ] on the main menu, then heater goes to off and switch to cooling with only blower starting up. When the timer set up for cooling is due, blower stops and drying stops. ( [  ] flickering→off)</p> <p>(3) Press [  ] on the main menu to stop secondary convey No.1 direction. (When this operation is applied during conveying, the cycle stops. ( [  ] lamp from flickering→off.)</p> |
| 9     | Power supply OFF                            | <p>Please turn the knob of disconnecting switch on the right side of the electric-control box to 「○」 , then the touch screen turns to OFF.</p> <div style="text-align: center;">  Caution </div> <p>Please don't turn power supply to OFF during cooling process when drying operation stops.</p> <p>If blower stops at once, remaining heat from the heating part may cause trouble or problems related to material agglomeration.</p>  |
| 10    | About reset after electricity out of supply | <p>When electricity out of supply for more than 70 ~ 190ms, operation stops at once. At this moment, remaining heat from the heating part may cause device trouble or problems related to material agglomeration; therefore, in case of resetting, please check the device sufficiently to make sure there is no starting problems, then, machine can be restarted.</p> <p>Especially, when overheat obnormity is inspected, machine cannot be restarted. In this case, machine is to cool down naturally for about 1~2 hours before restart.</p>   |

# Chapter 6. Maintenance and Inspection


## High Temperature Attention:

Please perform maintenance and item-by-item checking after the device completely cools down (natural cooling normally takes five hours), for the device may continue to keep high temperature after it has stopped operating for some time. Furthermore, pay attention that even though the exterior part of the device has cooled down, the inner part of it and some dry stuff may still keep high temperature.

## 1. Daily maintenance and inspection



| Maintenance and Item-by-Item checking item | Operation Content   |
|--|---|
| Temperature confirmation                   | <p>Please confirm if drying temperature and regeneration temperature are controlled by the setting temperature of the touch screen.</p> <p><b>【Drying temperature confirm】</b></p> <p>Please refer to the present value and setting value on the main menu.<br/>Normal drying temperature is among setting value <math>\pm 2 \sim 3^{\circ}\text{C}</math> (<math>\pm 3.6 \sim 5.4^{\circ}\text{F}</math>)</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Present Value</p>  </div> <div style="text-align: center;"> <p>When [i plas] flickers</p>  </div> </div> <p>※ When [i plas] is flickering, this machine is in lasting drying working condition. The present value is switched to [i plas] .</p> <p><b>【regeneration temperature confirmation】</b></p> <p>Please refer to 「temperature monitor」 for confirming.<br/>Normal regeneration temperature is between <math>210^{\circ}\text{C} \sim 220^{\circ}\text{C}</math> (<math>410 \sim 428^{\circ}\text{F}</math>). (It is normal that regeneration temperature changes with the ambient temperature.)</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;">   </div> <p>※ When [i plas] is flickering, this machine is in lasting drying working condition. The present value is switched to [i plas] .</p> |




| Maintenance and Item-by-Item checking item | Operating Content  |
|--|--|
| Confirming rotation of blower              | <p>【For the drying blower】<br/>Remove the hose from the exhaust port of the drying hopper and confirm that air flows swiftly.</p> <p>【For the Regeneration blower】<br/>Confirm that air swiftly comes out from the recycle exhaust port.</p> <div> <b>WARNING</b></div> <p>As powder and fragments of material may scatter at this time, please exercise caution and wear protective glasses and gloves when making confirmation.</p> |


## 2. Weekly maintenance and inspection

| Maintenance and Item-by-Item checking item           | Operation Content  |
|--|--|
| Clearing of the Filter                               | <div data-bbox="884 499 1118 577" data-label="Image"> </div> <ol style="list-style-type: none"> <li>1. Please wear respirator to prevent dust when clearing the dry filter, for the impurity attached on the filter may fly in the air.</li> <li>2. Pay attention that the jamming of the filter may make its operation temperature and air rate unstable, and then cause fire hazard.</li> </ol> <ul style="list-style-type: none"> <li>* If the filter is jammed, take it off and use clean dry air to blow off the attachment.</li> <li>* Different surrounding may cause different polluted condition, be sure to carefully check regularly and clear the pollutant carefully.</li> <li>* After complete checking, put the filter back and fix it.</li> </ul> <p><b>* If the mesh is badly jammed, or surface attached with oil film, filter undergoing severe color change and component quality deteriorating or shape distorting, please replace it with a new one.</b></p> |
| Clearing of Feeding Filter<br>Clearing of Dry Filter | <p>Please take off the filter and check if it is jammed and clean it up.</p> <p>[Disassembling and Clearing of the Filter]</p>   |



| Maintenance and Item-by-item checking item | Operation Content   |
|--|---|
| Clearing of the Regeneration Filter        | <p data-bbox="555 389 1439 425">Please take off filter and check if it is got jammed or not and clear it up.</p>    |
| Dust Collecting Bin of air source unit     | <p data-bbox="555 904 1439 985">Please take off dust collecting bin and remove the fine particles that is stagnant inside.</p>  <p data-bbox="542 1489 1452 1568">* Please replace gaskets with new ones when being degraded, transformed, discolored or become hardened.</p> |

| Maintenance and Item-by-Item checking item | Operation Content  |
|--|--|
| Method of discharging drain of air kit     | <p data-bbox="539 394 1085 427">Discharge drain that is stagnant in the bowl.</p> <p data-bbox="539 472 1436 584">If pressing drain valve on lower part of the bowl, air and drain will be discharged at the same time under the condition of compressed air being supplied (slick valve switched [on] side) .</p> <p data-bbox="539 629 922 663">Receive the drain with the can.</p> <div data-bbox="722 689 1361 1137"><p data-bbox="730 701 874 779">Slick valve<br/>(Stop valve)<br/>Close⇔Open</p><p data-bbox="1257 1037 1313 1059">Bowl</p><p data-bbox="1233 1115 1361 1137">Drain valve</p><p>The diagram illustrates the components of an air kit. A 'Slick valve (Stop valve)' is shown on the left, with a label indicating it can be switched 'Close⇔Open'. This valve is connected to a central assembly. This assembly includes a circular gauge or pressure indicator. Below the gauge is a cylindrical 'Bowl'. At the bottom of the bowl is a 'Drain valve'. Arrows point from the text labels to their respective parts in the diagram.</p></div> |

| Maintenance and Item-by-Item checking item                          | Operation Content  |
|---|--|
| Filter cleaning<br>Jet Clone<br>Receiving hopper on molding machine | <p data-bbox="550 392 1453 470">Please open the top cover of the sucking hopper and then remove the filter to check clogging up or not.</p> <p data-bbox="550 477 1453 555">If clogging up, puff it away with dry and clean air. Get rid of the adhering material.</p> <div data-bbox="719 616 1278 1030"> </div> <p data-bbox="550 1075 1453 1153">* If the adhering material can't be puffed away with dry air, get rid of it with spiky head of iron wire, etc.</p> <p data-bbox="550 1160 1453 1238">* Please replace a new gasket when the old one is seriously aging, distorted, color changed or hardened.</p> <div data-bbox="884 1261 1118 1339"> </div> <ul data-bbox="550 1361 1453 1848" style="list-style-type: none"> <li>○ Air leakage will occur if the filter is distorted, which will result in feeding can't continue; therefore, please pay more attention to the using manner.<br/>Once the filter is distorted, hammer it to stretch with soft objects such as wood hammer or rubber hammer, etc. If it can't be repaired in any way, please replace a new one.</li> <li>○ The dirt adhering on the filter will fly in the atmosphere while cleaning the drying filter. Please wear a respirator to prevent the dust.</li> <li>○ The conveying blower running with overload or with low conveying efficiency is always resulted from the clogging up to the meshes of the filter. Therefore, you should pay enough attention to it.</li> </ul> |

| Maintenance and Item-by-Item Checking Item   | Operation Content  |
|--|--|
| <p>Sensitivity adjustment of the paddle type level switch<br/>(Using the paddle type level switch)</p> | <p>When the level switch doesn't sense correctly by the kind of material, the sensitivity adjustment is necessary.</p> <p>[Adjusting method]</p> <p>Adjust sensitivity at the specific gravity of convey material.</p> <ol style="list-style-type: none"> <li>① Turn the lid of the level switch to remove.</li> <li>② Change the position of spring installation hole.</li> </ol> <p>When moving a spring to the low position, the sensitivity up.<br/>And, when moving a spring to the high position the sensitivity down.</p>  |


| Maintenance and Item-by-Item Checking Item | Operation Content  |
|--|--|
| Sensitivity Adjustment of the Level Sensor | <p>Receiving hopper on molding machine install the level sensor.<br/>Sensitivity adjustment is done before goods shipped out of factory; However, if malfunction occurred, please follow below steps to adjust.</p> <div data-bbox="560 566 1444 909"> <p>The diagram shows a side view of a receiving hopper assembly. On the left, there is a vertical panel with two buttons: the top one is labeled 'OUT OFF Program design button' and the bottom one is labeled 'OUT ON program design button'. Between these buttons is an orange lamp labeled 'Function lamp (orange)'. To the right of the buttons is a large cylindrical hopper. On the far right of the hopper, there is a vertical slot labeled 'Monitoring phase' with an arrow pointing to it.</p> </div> <p>Adjust sensitivity when material is empty(Function lamp turns off)</p> <ol style="list-style-type: none"> <li>1) Please set receiving hopper material empty.</li> <li>2) Prepare round stick with flat or round head at both ends, diameter <math>\phi 3</math>.</li> <li>3) Please observe function lamp while hold pressing OUT OFF program design button (for standard 4 seconds). When function lamp become slow flickering, please move your finger away and make sure the function lamp is turned off.</li> <li>4) Please set receiving hopper level state full (with material), and when the function lamp becomes lit, adjustment finishes.</li> </ol> <div data-bbox="874 1422 1003 1487" style="border: 1px solid black; padding: 5px; text-align: center;"> <b>NOTE</b> </div> <p>Please never touch the program design button with sharp or keen kit to avoid damage.</p> |

| Maintenance and Item-by-Item Checking Item                            | Operation Content  |  |
|---|--|--|
| Adjustment of Jet Clone damper cam on upper part of the drying hopper | <p>When the damper doesn't open until the full signal appears on, adjust a damper cam by following procedures.</p>    |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
| Adjustment of Jet Clone balancer on upper part of the drying hopper   | <p>Due to static electricity, occasionally, material will attached to the damper as it is shown in the photo besides, when this happens, please loosen the 2 set screws on the balancer and move backward at 5mm each time until the damper finally reach level line. When adjustment is over, please fix the set screws.</p>  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |






### 3. Monthly maintenance and inspection


| Maintenance and Item-by-Item Checking Item | Operation Content   |
|--|---|
| Screwing Down of Terminal                  | <p>Please confirm if the wiring connection of the electrical apparatuses inside the electric-controlled box and the device is loose, screw down if it is loose.</p> <div data-bbox="882 629 1123 705" data-label="Image"> </div> <p>Be sure to perform item-by-item checking after stopping the device and cutting off the power supply.</p>  |
| Jet Clone inspecting                       | <p>A: Please check upper and lower brake (M6) for its firmness.<br/>       * If any loose be found, please refer to “Brake Adjustment Photo” on next page for re-fasten.</p> <p>B: Please take off blind flange and check socket head cap screw of damper cam for its firmness. Meanwhile, shut up damper and check limit switch condition.<br/>       * If any loose be found, please refer to “Brake Adjustment Photo” on next page for re-fasten.</p> <p>C: Please check socket head cap screw that set the balancer for its firmness.<br/>       * If any loose be found, please tighten it up.</p> <p>D: Please check spring, bolt, nut and split pin condition.<br/>       * If any abnormalities found, please replace them with a new one.</p> <div data-bbox="587 1400 1401 1881" data-label="Image"> </div> |

| Maintenance and Item-by-Item checking Item | Operation Content  |
|--|--|
| Jet Clone Inspecting                       |  <p>Brake Adjustment Photo</p>   |
| Dropping and air-leaking of hose           | <p>Please check if hose removes or leaks or not.</p> <p>* In case of the air-leak, replace them with a new.</p> <p>[Example of the checking method of the air leak]</p> <p>In the checking method, hang a string or a thread near the hose. In the shaking condition of a string or a thread, the air leak can be confirmed.</p> |

## 4. Every six months maintenance and inspection

| Maintenance and Item-by-Item Checking Item      | Operation Content  |
|---|--|
| Bolts and Screw Caps of Each Part of the Device | Please check if each bolt or screw cap is loose or not, screw down it if it is loose.  |
| The Honeycomb Rotor                             | If remove destructive and non-regenerated adhering matters of high boiling point and improper object by outside force, the honeycomb rotor shall not undergo chronicle worsening in function due to use, so long as dehumidifying air dew point keeps stable and works properly, there is no need for replacing. |

| Maintenance and Item-By-Item Checking Item | Operation Content  |
|--|--|
| The honeycomb rotor air gasket             | <p>Air gasket on both upper and lower part of the honeycomb rotor are cylindrical type slide gasket. Please check both slide sides of the honeycomb rotor. If any air leak or abnormalities occurred, we recommend that you replace the cylindrical type slide gasket.</p> <p> <b>Warning</b></p> <p>The honeycomb usually rotates at a low speed, therefore, situation is likely to happen when it reaches to seemed stopping, please pay sufficient attention to this.</p> <p>Carry on inspection while honeycomb rotor is operating, please pay sufficient attention, do not draw clothing and finger, etc. into drive belt and belt pulley as well as into clearance between the honeycomb rotor and other parts.</p> |
| Drive motor                                | <p>Check driving motor, if any abnormalities such as heat, noise, vibration, etc. occurred, please make sure to replace it with a new one.</p> <p> <b>Warning</b></p> <p>The honeycomb usually rotate at a low speed in ON/OFF. Situation is likely to happen when it reaches to seemed stopping; therefore, please pay sufficient attention to this.</p> <p>Carry on inspection while the honeycomb rotor is operating, please pay enough attention, do not draw clothing and finger into belt and belt pulleys as well as clearance between honeycomb rotor and other parts.</p>  |
| Drive belt                                 | <p>Check drive belt, if any crack or gear wear, please make sure to replace it.</p> <p> <b>Warning</b></p> <p>Before approaching drive belt, please make sure to stop operation and cut off power supply.</p>   |



Note: Only personnels with professional knowledge and skill can perform replacement and repairing work.  
If inspecting result shows abnormalities, please contact Matsui's after-sales department.

# Chapter 7. Alarm Function



This chapter mainly explains alarm function and its cause as well as how to reset and fix in this machine.






Please refer to [Chapter 2 Equipment Explanation-4.Name and function of each controller part of touch screen] concerning controller operations in different windows.

## 1. On alarm cause and reset

If abnormality occurs, buzzer on the operating panel rings. Meanwhile, **ALARM** flickers.






When alarm occurs, please follow below steps to confirm abnormality and identify the cause to eliminate them.

| Steps | Operating Item              | Operation Content / Operation Description  |
|-------|-----------------------------|--|
| 1     | Buzzer stopping             | <p>Please press <b>ALARM</b> in various windows.<br/>Buzzer stops working.</p>   |
| 2     | Confirm abnormality content | <p>Please press <b>ALARM</b> in various windows to go to [Alarm List] window.<br/>Please confirm abnormality content being occurred • quantity.</p> <p>AlarmList window</p>  <p>※If heater overheated, above window shows.</p> |

| Steps | Operating Item                  | Operation Content / Operation Description  |
|-------|---------------------------------|--|
| 3     | Identifying the cause and reset | <p>(1) Please press  on [AlarmList] window to go to [Help] window.</p>  <p>(2) To identify abnormality cause and the fix method by alternating between window labels and refer to its related help window.</p>   |
| 4     | Eliminate the alarm             | <p>When the cause is identified and fixed up, please press  on the main menu.</p>  <p>※Under [Inverter alarm], please set the disconnecting switch in the electric-control box OFF and eliminate the alarms.</p> <div data-bbox="928 1684 1098 1738" data-label="Image"> </div> <p>Please make sure to turn disconnecting switch in electric-controlled box OFF before carrying any inspection and fixing task. To avoid any danger or accident, please do not perform any operation on this machine when the disconnecting switch is set ON.</p> |

## 2 . Confirmation of alarm situation

If you want to confirm alarm situation happened in the past, please follow below steps to go to 「Alarm Hist.」 window.

| Steps          | Operating Item                 | Operation Content / Operation Description   |              |               |         |                |  |                        |                |  |                       |                |                |                |                |                |                      |                |  |                            |                |  |                   |                |                |                  |                |                |                 |
|----------------|--------------------------------|---|--------------|---------------|---------|----------------|--|------------------------|----------------|--|-----------------------|----------------|----------------|----------------|----------------|----------------|----------------------|----------------|--|----------------------------|----------------|--|-------------------|----------------|----------------|------------------|----------------|----------------|-----------------|
| 1              | How to go to AlarmList window. | <p>You can press various windows name to go to [AlarmList] window.</p>    |              |               |         |                |  |                        |                |  |                       |                |                |                |                |                |                      |                |  |                            |                |  |                   |                |                |                  |                |                |                 |
| 2              | Confirm alarm history          | <p>Please press [  AlarmHist. ] on [AlarmList] window to go to [Alarm Hist.] window and see past alarms and their date and time occurred.</p>  <table border="1"> <thead> <tr> <th>Occured Time</th><th>Recovery Time</th><th>Message</th></tr> </thead> <tbody> <tr> <td>10/24 16:38:54</td><td></td><td>Drying blower Overload</td></tr> <tr> <td>10/24 16:38:54</td><td></td><td>Regen blower Overload</td></tr> <tr> <td>10/24 16:38:54</td><td>10/24 16:38:54</td><td>Inverter Alarm</td></tr> <tr> <td>10/24 16:38:54</td><td>10/24 16:38:54</td><td>Feed blower Overload</td></tr> <tr> <td>10/24 16:38:54</td><td></td><td>Reverse-phase/single-phase</td></tr> <tr> <td>10/24 16:38:54</td><td></td><td>Heater Overheated</td></tr> <tr> <td>10/24 16:38:54</td><td>10/24 16:38:54</td><td>Drying High temp</td></tr> <tr> <td>10/24 16:38:54</td><td>10/24 16:38:54</td><td>Drying Low temp</td></tr> </tbody> </table> <p>When alarm history reaches to more than 8 items, please press [  ] [  ] to confirm alarm history which is not shown on this window.</p> | Occured Time | Recovery Time | Message | 10/24 16:38:54 |  | Drying blower Overload | 10/24 16:38:54 |  | Regen blower Overload | 10/24 16:38:54 | 10/24 16:38:54 | Inverter Alarm | 10/24 16:38:54 | 10/24 16:38:54 | Feed blower Overload | 10/24 16:38:54 |  | Reverse-phase/single-phase | 10/24 16:38:54 |  | Heater Overheated | 10/24 16:38:54 | 10/24 16:38:54 | Drying High temp | 10/24 16:38:54 | 10/24 16:38:54 | Drying Low temp |
| Occured Time   | Recovery Time                  | Message   |              |               |         |                |  |                        |                |  |                       |                |                |                |                |                |                      |                |  |                            |                |  |                   |                |                |                  |                |                |                 |
| 10/24 16:38:54 |                                | Drying blower Overload  |              |               |         |                |  |                        |                |  |                       |                |                |                |                |                |                      |                |  |                            |                |  |                   |                |                |                  |                |                |                 |
| 10/24 16:38:54 |                                | Regen blower Overload   |              |               |         |                |  |                        |                |  |                       |                |                |                |                |                |                      |                |  |                            |                |  |                   |                |                |                  |                |                |                 |
| 10/24 16:38:54 | 10/24 16:38:54                 | Inverter Alarm  |              |               |         |                |  |                        |                |  |                       |                |                |                |                |                |                      |                |  |                            |                |  |                   |                |                |                  |                |                |                 |
| 10/24 16:38:54 | 10/24 16:38:54                 | Feed blower Overload  |              |               |         |                |  |                        |                |  |                       |                |                |                |                |                |                      |                |  |                            |                |  |                   |                |                |                  |                |                |                 |
| 10/24 16:38:54 |                                | Reverse-phase/single-phase  |              |               |         |                |  |                        |                |  |                       |                |                |                |                |                |                      |                |  |                            |                |  |                   |                |                |                  |                |                |                 |
| 10/24 16:38:54 |                                | Heater Overheated   |              |               |         |                |  |                        |                |  |                       |                |                |                |                |                |                      |                |  |                            |                |  |                   |                |                |                  |                |                |                 |
| 10/24 16:38:54 | 10/24 16:38:54                 | Drying High temp  |              |               |         |                |  |                        |                |  |                       |                |                |                |                |                |                      |                |  |                            |                |  |                   |                |                |                  |                |                |                 |
| 10/24 16:38:54 | 10/24 16:38:54                 | Drying Low temp   |              |               |         |                |  |                        |                |  |                       |                |                |                |                |                |                      |                |  |                            |                |  |                   |                |                |                  |                |                |                 |




### 3. Alarm list

Please follow below steps to see alarm contents, perform reset and confirm solution.




When alarm couldn't be reset, that may result in malfunction, please contact with Matsui.


| Alarm display          | Content  | Reset / Solution  | Reference            |
|------------------------|--|---|----------------------|
| Drying blower overload | Thermal relay FR1A used with drying blower M1A tripped.<br><br>Device stops operating automatically.   | Please set main switch QS1 OFF (○) and cut off electricity power supply.<br><br>Please clean filter blocking.<br><br>Please press thermal relay reset button inside the electric-controlled box to reset the tripping.  | Prepare supply power |
| Regen blower overload  | Thermal relay FR1B used with regeneration blower M1B tripped.<br><br>Device stops operating automatically.   |   |                      |
| Inverter alarm         | Inverter U1 is not working normally.<br><br>Device stops operating automatically.  | Please set main switch QS1 to OFF (○), in no less than 20 seconds, please set QS1 to ON (I), and connect power supply again.  | Prepare Supply power |
| Feed blower overload   | [MJ5-i-150~650]<br>Motor-protective circuit-breaker QM1 used with feed blower M2 tripped.<br>[MJ5-i-1500]<br>Inverter U2 is not working normally.<br>Device stops operating automatically. | Please set main switch QS1 OFF (○) and cut off electricity power supply.<br>Please clean filter blocking.<br>Please clean blocking inside convey piping.<br>[MJ5-i-150~650]<br>Please open electric-controlled box, rotate motor-protective circuit-breaker QM1 handle to ON (   ). | Prepare Supply power |

| Alarm display     | Content  | Reset / Solution  | Reference  |
|-------------------|--|---|--|
| Heater overheated | <p>Thermostat ST1, ST2 attached to dry heater EH1[EH10/EH11] or regeneration heater EH2 is inspected overheat.<br/>Device stops operating automatically.</p> <p>Occurs when the drying heater and regeneration heater reaches an abnormally high temperature.</p> <p>The unit is automatically shut off.</p> <p> <b>DANGER</b></p> <p>The heater overheated alarm is an important alarm that detects abnormally high temperatures and automatically shuts the unit off.</p> <p>If improper measures such as modifying the unit to prevent the heater overheated alarm from being triggered are taken, the unit will continue to operate in a state of abnormally high temperature for a long period of time, which is extremely dangerous.</p> <p>Be sure to follow the correct measures as described in the column at the right.</p> <p>Replacement of parts should be conducted by a certified electrical engineer after turning off the power breaker.</p> | <p>Please operate main switch and cut off power supply.</p> <p>Please rotate graduated disc inside of electric-controlled box, and set thermostat ST1 a proper value.</p> <p>After cooling for one hour or longer, press the  switch.</p> <p>If the heater overheated alarm triggers again, the overheat protector is defective.<br/>Replace the regeneration overheat protector.</p> <p>If the heater overheated alarm triggers again even after the regeneration overheat protector is replaced, replace the drying overheat protector.</p> <p>Press the  key to operate the unit.</p> <p>Inspect the drying blower and replace the blower if it does not rotate.</p> <p>Inspect the regeneration blower and replace the blower if it does not rotate.</p> <p>If the cause is not identified and the heater overheated alarm triggers again, an inspection by a service engineer is necessary.</p> <p>Contact our Service Division to request an inspection.</p> | <p>Prepare for operation</p> <p>Set overheat preventor temperature</p> |
| Drying high temp  | <p>Dry temperature exceeds upper limit set value.</p> <p>Device stops operating automatically after cooling.</p>   | <p>Please set upper limit of drying temperature deviation value to a proper one (initial value: 10°C/18°F)</p> <p>Please clean filter blocking.</p>   | <p>Prepare for operation</p> <p>Set controller</p>                     |




| Alarm display   | Content  | Reset / Solution   | Reference  |
|---|--|--|--|
| Drying low temp   | Drying temperature lower than the lower limit set up value.<br><br>Device keeps operating.                         | Please set lower limit of drying temperature deviation value to a proper one (initial value: 10°C/18°F)<br><br>Please clean filter blocking. | Prepare for operation<br>Controller setting<br>Prepare for operation<br>Supply power |
| Regen high temp   | Regeneration temperature exceeds the upper limit set value.<br>Device stops operating automatically after cooling. | Please clean filter blocking.  |  |
| Regen low temp  | Regeneration temperature lower than the lower limit set value.<br><br>Device keeps operating.                      | Please clean filter blocking.  |  |
| Drying temp sensor alarm<br>Dry exhaust sensor alarm<br>Regen temp sensor alarm | Temperature sensor is inspected abnormal.<br><br>Device stops operating automatically.                             | Please contact Matsui.   |  |

| Alarm Display             | Content   | Reset / solution   | Reference |
|---------------------------|---|--|-----------|
| Dry setting error         | Drying temperature set up value can not be written in normally.   | Please contact Matsui.   |           |
| Dry exhaust setting error | Dry exhaust temperature set up value can not be written in normally.  |  |           |
| Regen setting error       | Regeneration temperature set up value can not be written in normally.   |  |           |
| Honeycomb rotating alarm  | The absorbing cylinder to dehumidifying unit is not rotating normally.  | Please contact Matsui.   |           |
| Drying hopper feed alarm  | Even though feed-in convey to the drying hopper is continued, it still can not reach full level.<br><br>Even though feed-out convey is continued, the level switch not yet to give out feed signal. | Please make up feed to convey side.<br><br>Please repair cracked convey piping or hose, or replace them with a new one.<br><br>Please fix improper connection between pipes and hoses.<br><br>Please remove convey pipe and hose blocking. |           |
| No.1 feed alarm           | Even though convey to No.1 direction is continued, receiving hopper not yet to reach full level.  |  |           |
| No.2 feed alarm           | Even though convey to No.2 direction is continued, receiving hopper not yet to reach full level.  |  |           |
| * Optional mechanism      |   | Please adjust receiving hopper level switch.<br><br>Please set the value of convey abnormality to a proper one.  |           |
| Dust cleaning             | Convey frequency has amounted to that of dust collecting bin cleaned set.   | Please clean dust collecting bin.<br><br>Release alarm by operating  on "Home".   |           |

| Alarm Display                 | Content  | Reset / Solution  | Reference |
|-------------------------------|--|---|-----------|
| Temp control unit alarm       | Temperature adjust not function normally                           | Set main switch QS1 OFF (○), in no less than 20 seconds, please set QS1 ON (  ) and connect power supply again.   |           |
| PLC alarm                     | Device is not functioning normally.                                | Cut off main switch QS1 (○), in no less than 20 seconds, please set QS1 ON (I), and connect power supply again.   |           |
| PLC battery alarm             | PLC inlaid battery power voltage is very low.                      | <p>Make sure power supply has been connected for more than 5 minutes and set main switch QS1 OFF (○).</p> <p>Make sure contact and inlaid condition of the battery plug-in unit inside of the blind flange of CPU component D12 of PLC inside of the electric-controlled box is ok, if any problem, please reconnect.</p> <p>If necessary, please replace battery plug-in unit and replace a new battery in 5 minutes.</p>      |           |
| Touch panel battery alarm     | Inlaid battery of touch screen (Programmable display) is very low. | <p>Make sure power supply connected for more than 1 minute, and set main switch OFF (○).</p> <p>Please make sure the contact and inlaid condition of battery plug-in unit in inner-side of blind flange of electric-controlled box that is of touch screen D2 on operating panel is ok. If any problem, please reconnect.</p> <p>If necessary, please replace battery plug-in unit and replace a new battery in one minute.</p> |           |
| Main power supply is shut off | Main power supply is shut off during a drying operation.           | Release alarm by operating [  ] on "Home".   |           |

# Chapter 8 Trouble Shooting



Do not perform any inspection work until machine totally stops and set main switch QS1 OFF (○) that controls the right side of the electric-controlled box. Do not carry on any inspection until heating part temperature decreases to some extent enough not to get heat injury.

Below abnormality is recorded as below.

Since next page, reference related to mal-function part and disposal method is recorded. Please identify abnormality cause before entrust any one with repairing.



Beside, please refer to Chapter 6 “Maintenance and inspection” for filter disassembly.

| Malfunction part                               | Contents   | Note page |
|--|--|-----------|
| Convey blower                                  | The blower does not rotate.  | 81        |
|  | The blower does overloaded operation and the thermal relay trips.  | 83        |
|  | A little air flow rate of the blower.  | 84        |
| Dry blower                                     | The blower does not rotate.  | 82        |
|  | The blower does overloaded operation and the thermal relay trips.  | 83        |
|  | A little air flow rate of the blower.  | 84        |
| Regeneration blower                            | The blower does not rotate.  | 82        |
|  | The blower does overloaded operation and the thermal relay trips.  | 83        |
|  | A little air flow rate of the blower.  | 84        |
| Drying temperature                             | The change of the temperature is large.  | 84        |
|  | The drying temperature doesn't go up or go down.   | 85        |
| Inferior drying                                | The resin moisture content does not go down.   | 85        |
| Touch screen controller                        | Even though set primary side electricity power supply “ON”, touch screen controller still does not show. | 86        |
| Primary side power supply protector<br>Breaker | Equipment power supply protector or breaker trips.   | 86        |
| Overheat                                       | The overheat alarm occurs.   | 86        |
| The set value of every thermal relay model     |  | 87        |

## The convey blower does not rotate

| Searching for Abnormity  | Solution   | Notes   |
|--|--|---|
| Please check that indication light HL1 is on or not.   | Please turn primary power supply and main switch to ON<br><br>(I). Please press preparatory switch to turn it on.                    | Please refer to “Chapter 4. Preparation for operation -3. Power supply”   |
| [MJ5-i-150~650]<br><br>Please open the gear of electric-controlled box and check if motor-protective circuit-breaker QM1 is ON (I) or not. Besides, please check if magnetic connection point of electromagnetism switch is fused or consumed. | If it is fused or consumed, or abnormal in make and break, please change a new contactor.  | <u>The total number of repeated make and break is 2 million times.</u>  |
| [MJ5-i-150~650]<br><br>Please check if blower overload occurs or not.  | After fixing, please open the gear of electric-controlled box and turn black knob of motor-protective circuit-breaker QM1 to ON (I). | Please refer to this chapter “Blower is overloading, thermal relay trips” to identify the cause.  |
| [MJ5-i-1500]<br><br>Please check if frequency convertor alarm occurs or not.   | Please set main switch QS1 OFF (○) to remove alarm.  | When inverter U2 inside of electric-controlled box does not work normally, please fix or replace it.  |
| Please check if the limit switch of Jet Clone is on or not in the condition of discontented stuff.   | When the limit switch is turned ON, please refer to “Chapter 6 Maintenance- <i>Jet Clone</i> inspecting” to adjust the limit switch. | If limit switch is not proper adjusted, though in the condition of contented stuff in Jet clone, feed-in convey yet not to stop, please pay enough attention to that. |
| Please check level switch and level sensor sensibility of feed-in convey side Jet Clone  | Please refer to “Chapter 6. Maintenance-Sensitivity adjustment of level switch or level sensor” to adjust.                           | If limit switch is not proper adjusted, though in the condition of contented stuff in Jet clone, feed-in convey yet not to stop, please pay enough attention to that. |

### Dry blower does not rotate

| Searching for Abnormity  | Solution   | Notes  |
|--|--|--|
| Please check preparatory switch is on or not.  | Please set primary side power and main switch QS1 to on (I). Please press preparatory switch and indicator turns on.     | Please refer to “Chapter 4. Preparation for operation-3. Power supply”                               |
| Please check if [  ] on “Home” is pressed and indicator turned on or not. | Please press [  ] if it's light is off. | Drying can be triggered in the condition of setting start timer after the set time is due.           |
| Please make sure if blower overload alarms occurred or not.  | After fixing, please open the gear of electric-controlled box and press reset button of thermal relay FR1A.              | For its cause, please refer to “Blower undergoing overload, Thermal relay trips” on this chapter.    |
| Please check if frequency convertor alarm occurs or not.   | Please set main switch QS1 OFF (○) to remove alarm.  | When inverter U1 inside of electric-controlled box does not work normally, please fix or replace it. |

### Regeneration blower does not rotate

| Searching for Abnormity                                | Solution  | Notes  |
|--|---|--|
| Please check if blower overload alarm occurred or not. | After fixing, please open the gear of electric-controlled box and press reset button of thermal relay FR1B. | For its cause, please refer to this chapter “The blower does overloaded operation and the thermal relay trips” |
| Please check if inverter alarm occurred or not.        | Please set main switch when QS1 OFF (○) to eliminate the alarm.   | When inverter U1 inside of electric-controlled box does not work normally, please fix and replace it.          |

### The blower does overloaded operation and the thermal relay trips

| Searching for Abnormity   | Solution  | Notes  |
|---|---|--|
| Please take out the filter pot in the convey filter cover to check if there is blockage.                  | If there is blockage, please blow adherents on the inner side of filter pot away by clean dry air.        | If the filter pot is too aging to remove the adherents, please change a new one. |
| Please take out the filter pot in the drying filter cover to check if there is blockage.                  | If there is blockage, please blow adherent on the inner side of filter pot away by clean dry air.         | If the filter pot is too aging to remove the adherents, please change a new one. |
| Please take off regeneratin filter and check if there is any blockage.                                    | If there is blockage, please blow adherent on the inner side of filter away by clean dry air.             | If the filter is too aging to remove the adherent, please change a new one.      |
| Please check if connection point of contactor KM2 inside of electric-controlled box is fused or consumed. | If it does not work properly, please replace it with a new one.   | <u>The total number of repeated make and break is 2 million times.</u>           |
| Please check if thermal relay inside of electric-controlled box is set nominal value or not.              | Please refer to “The thermal relay setting value of every model” and set thermal relay the nominal value. | Please set primary side power “OFF”, before perform any operation.               |
| Please check if inverter U1 or U2 works normally or not.  | Please repair or replace it with a new one.   |  |


### A little air flow rate of the blower

| Searching for Abnormity   | Solution  | Notes   |
|---|---|---|
| Please take out the filter pot in the convey filter cover to check if there is blockage.  | If there is blockage, please blow adherent on the inner side of filter pot away by clean dry air.   | If the filter pot is too aging to remove the adherent, please change a new one.   |
| Please take out the filter pot in the drying filter cover to check if there is blockage.  | If there is blockage, please blow adherent on the inner side of filter pot away by clean dry air.   | If the filter pot is too aging to remove the adherent, please change a new one.   |
| Please take off regeneration filter to check if there is blockage.  | If there is blockage, please blow adherent on the filter away by clean dry air.                     | If the filter is too aging to remove the adherent, please change a new one.   |
| Please check if the connecting tube inside the dehumidifying device, the dehumidifying device, and the connecting tube of drying hopper are broken or not, and if there are looses on connection. | If tubes are broken, please change new tubes. If there are looses on connection, please tighten up. | If being sure of air leakage, please stop the device. Start operation again after sufficient cooling down of temperature of the heating part. |

\* This machine is equipped with wind volume optimization, as you can check it through [Power] on the “Home “.

### The change of the dry temperature is large


| Searching for Abnormity  | Solution  | Notes   |
|--|---|---|
| Please take out the filter pot in the drying filter cover to check if there is blockage. | If there is blockage, please blow adherent on the inner side of filter pot away by clean dry air. | If the filter pot is too aging to remove the adherent, please change a new one. |
| Please take off regeneration filter to check if there is blockage.                       | If there is blockage, please blow adherent on the filter away by clean dry air.                   | If the filter is too aging to remove the adherent, please change a new one.     |

When [  ] on the “Home” flickers, temperature drops, but this is normal.



### The drying temperature doesn't go up or go down

| Searching for Abnormity   | Solution  | Notes   |
|---|---|---|
| Please check if the connect tube inside the dehumidifying device, the dehumidifying deice, and the connecting tube of drying hopper are broken or not, and if there are looses on connection. | If tubes are broken, please change new tubes, If there are looses on connection, please tighten up. | If being sure of air leakage, please stop the device. Start operation again after sufficient cooling down of the heating part.              |
| Please check if circuit-breaker FS3 used by drying heater power inside of the electric-controlled box is cut off or not.  | Please connect the power supply of circuit-breaker FS3.   | Please set primary side power "OFF" before performing any operations.   |
| Please check if wire to dry heater is broken or not.  | If wire is fused or consumed, please replace it with a new one.                                     | Please set primary side power supply "OFF" after machine stop operation. Start operation again after sufficient cooling down of the heater. |

\* When [  ] on the "Home" flickers, temperature drops, but that is normal.

### The resin moisture content does not go down

| Searching for Abnormity   | Solution  | Notes  |
|---|---|--|
| Please check if circuit-breaker FS3 used by drying heater power inside of the electric-controlled box is cut off or not.  | Please connect power supply of circuit-breaker FS3.   | Please set primary side power "OFF" before performing any operation.   |
| Please check if circuit-breaker FS4 used by regeneration heater power inside of the electric-controlled box is cut off or not.  | Please connect power supply of No.1 feed alarm No.1 feed alarm circuit-breaker FS4.                 | Please set primary side power "OFF" before performing any operation.   |
| Please take out the filter pot in the drying filter cover to check if there is blockage.  | If there is blockage, please blow adherent on the inner side of filter pot away by clean dry air.   | If the filter pot is too aging to remove the adherents, please change a new one.   |
| Please take off regeneration filter to check if there is blockage.  | If there is blockage, please blow adherent on the inner side of filter away by clean dry air.       | If the filter is too aging to remove the adherent, please change a new one.  |
| Please check if the connect tube inside the dehumidifying device, the dehumidifying deice, and the connecting tube of drying hopper are broken or not, and if there are looses on connection. | If tubes are broken, please change new tubes, If there are looses on connection, please tighten up. | If being sure of air leakage, please stop the device. Start operation again after sufficient cooling down of the heating part. |
| Please check if wire to regeneration heater is broken or not.   | If wire is fused or consumed, please replace it with a new one.                                     | Please set main switch "OFF" after machine stops operation. Start operation again after sufficient cooling down of the heater. |

Even though set primary side electricity power supply "ON", touch screen controller still does not show anything.

| Searching for Abnormity  | Solution  | Notes   |
|--|---|---|
| Please check main switch QS1 on side of the electric-controlled box is ON (   ) or not.                    | Please set it "ON"  | The total number of repeated make and break is 10 thousands times.<br>Please replace main switch when the opening and shutting function doesn't operate normally. |
| Please check if every miniature circuit-breaker FS5~8 inside of the electric-controlled box is OFF or not. | Please check conductor configuration and components inside of electric-controlled box and set them ON after that. | Please set primary side power supply "OFF" before performing any inspection.  |

### Equipment power supply protector or breaker trips.

| Searching for Abnormity                                     | Solution                         | Notes   |
|---|----------------------------------|---|
| Please check if there is short cut in the electric circuit. | Please get rid of the short cut. | To avoid any danger or accident, please do not ask anyone who do not have the sufficient electricity knowledge, therefore , please entrust Matsui with this task. |

### The overheat alarm occurs

| Searching for Abnormity   | Solution  | Notes  |
|---|---|--|
| Please check if there is deviation on the set value of drying overheat preventor in the electric-controlled box. Set value of drying overheat preventor: drying temperature +20°C(36°F) | Please make correction if deviation exists.   | To avoid electricity shock, please set primary side power supply "OFF" before inspection.  |
| Please take out filter pot in the dry filter cover to check if there is blockage.   | If there is blockage, please blow adherent on the inner side of filter pot away by clean dry air.                     | If the filter pot is too aging to remove the adherent, please change a new one.  |
| Please take off regeneration filter to check if there is blockage.  | If there is blockage, please blow adherent on the filter away by clean dry air.                                       | If the filter is too aging to remove the adherent, please change a new filter pot.   |
| Solid state socket connector V1[V10,V11] inside of the electric-controlled box has been conditioned to OUTPUT.  | Solid state socket connector may not function properly.<br><br>Please check and replace it with a new one if need to. | To avoid any danger or accident, please do not ask anyone who don't have a sufficient knowledge of electricity, therefore, please entrust us with this task. |

## The thermal relay setting value of every model (A)

| Model<br>Power    | MJ5-i-150             |                             |                      | MJ5-i-350             |                             |                      |
|-------------------|-----------------------|-----------------------------|----------------------|-----------------------|-----------------------------|----------------------|
|                   | Drying blower<br>FR1A | Regeneration blower<br>FR1B | Convey blower<br>QM1 | Drying blower<br>FR1A | Regeneration blower<br>FR1B | Convey blower<br>QM1 |
| AC200V<br>50/60Hz | 1.0A                  | 1.0A                        | 4.8/6.2A             | 1.9A                  | 1.0A                        | 4.8/6.2A             |
| AC220V<br>60Hz    | 0.9A                  | 0.9A                        | 5.8A                 | 1.9A                  | 0.9A                        | 5.8A                 |
| AC380V<br>50Hz    | 0.5A                  | 0.5A                        | 2.8A                 | 1.1A                  | 0.5A                        | 2.8A                 |
| AC400V<br>50Hz    |                       |                             | 2.9A                 |                       |                             | 2.9A                 |
| AC415V<br>50Hz    |                       |                             | 3.1A                 |                       |                             | 3.1A                 |
| AC440V<br>60Hz    | 0.5A                  | 0.5A                        | 3.1A                 | 1.2A                  | 0.5A                        | 3.1A                 |

| Model<br>Power    | MJ5-i-650             |                             |                      | MJ5-i-1500            |                             |                     |
|-------------------|-----------------------|-----------------------------|----------------------|-----------------------|-----------------------------|---------------------|
|                   | Drying blower<br>FR1A | Regeneration blower<br>FR1B | Convey blower<br>QM1 | Drying blower<br>FR1A | Regeneration blower<br>FR1B | Convey blower<br>U2 |
| AC200V<br>50/60Hz | 5.0A                  | 1.9A                        | 4.8/6.2A             | 11.7A                 | 5.0A                        | 10.0A               |
| AC220V<br>60Hz    | 4.6A                  | 1.9A                        | 5.8A                 | 10.9A                 | 4.6A                        | 9.2A                |
| AC380V<br>50Hz    | 2.6A                  | 1.1A                        | 2.8A                 | 6.4A                  | 2.6A                        | 5.3A                |
| AC400V<br>50Hz    |                       |                             | 2.9A                 | 6.2A                  | 2.6A                        | 5.1A                |
| AC415V<br>50Hz    |                       |                             | 3.1A                 | 6.1A                  | 2.5A                        | 5.0A                |
| AC440V<br>60Hz    | 2.5A                  | 1.2A                        | 3.1A                 | 6.0A                  | 2.5A                        | 4.8A                |

# Chapter 9. Technical Manual

---

## 1. On influence of gas that occurs from the resin

The information on influence of gas that occurs from the resin

This machine sometimes can not function normally with influence of gas that occurs from the resin.

As for the resin that has this possibility, the compatible measures to suppress influence of gas becomes necessary.

There are one-pass methods and methods of installing the gas gathering unit etc. in compatible method. However, the method must be chosen according to different dry materials.

Besides, there has not yet a completely safe plan to all resins. Therefore, regular maintenance of this machine and replacement of the consumptive parts and components are necessary by various resins used.

If following situation occurs during operation, please contact us in time, because device may get the influence from gas.

- 1) The liquid of oily oozes from the filter box, the pipe connection part and the drying hopper.
- 2) There are change of color inside of filter box, or, adheres to oil substances.
- 3) The thin smoke occurs from the regeneration exhaust port.
- 4) Oil dirties the whole unit.
- 5) Oil adheres to the floor.

As for the resin that may involve the influence of gas, please refer to the list on next page.

- Considering the influence brought about by gas, the following table lists the resins that this machine may need to take preventive measures. (Resin with ○ marked in corresponding columns indicates that machine needs to take gas preventive measure. Resin with × mark says no measure is needed, however, possible measures may be taken according to the kind of substances mixed.)

(Survey made in 2002)


| Resin Name      | Necessity of using the gass compatibles | Resin Name       | Necessity of the gass compatibles | Resin Name          | Necessity of of using the gass compatibles |
|-----------------|---|------------------|-----------------------------------|---------------------|--|
| ABS             | ×                                       | PAR              |                                   | PPO                 | ×  |
| ABS+PBT         |   | PBT              | ○                                 | PPS                 | ○  |
| APEL            |   | PBT+PC           |                                   | PSF                 |  |
| A-PET           |   | PBT+PET          |                                   | PTFE                |  |
| AS              | ×                                       | PC               | ×                                 | PU                  | ○  |
| BTP             |   | PC+ABS           |                                   | PUR                 |  |
| CA              |   | PC+PET           |                                   | PVC Special grade   | ○  |
| CAB             |   | PCT+PET          |                                   | SPS                 |  |
| CAP             |   | PCTFE            |                                   | TPE                 |  |
| CN              |   | PC Optical grade | ×                                 | TPO                 |  |
| COP             |   | PDAP             |                                   | TPX                 |  |
| CP              |   | PEEK             |                                   | Reinforcement PET   | ○  |
| DL              |   | PEI              |                                   | Flame resisting ABS | ○  |
| EC              |   | PES              |                                   |                     |  |
| EVA             |   | PETG             |                                   |                     |  |
| EVOH            |   | PET Bottle grade | ×                                 |                     |  |
| LCP             |   | PET Fiber grade  | ×                                 |                     |  |
| MTPA            |   | PFA              |                                   |                     |  |
| PA+POM          |   | PMMA             | ×                                 |                     |  |
| PA+Carbon fiber |   | PMMA Optical     | ×                                 |                     |  |
| PA6,66          | ×                                       | POAM             |                                   |                     |  |
| PA6,66+G        | ○                                       | POLYSUL          |                                   |                     |  |
| PA612           |   | POM              | ×                                 |                     |  |
| PAMXD6          |   | PP+Fiber yarn    | ○                                 |                     |  |
| PAN             |   | PPE              |                                   |                     |  |

## 2. Relation between the dry air dew point and the fresh air condition

Below graphs indicate the relation between fresh air and drying air dew point (temperature).

Dry air dew point is conditioned to that of fresh air (dew point).

Please pay enough attention to worsening situation of dry air dew point resulted from the change of fresh air. The following graphs take the example of our DMZ, DMS model, demonstrating how dry air dew point is changing with that of fresh air (dew point).



### 3. About alarm

This chapter mainly describes how to check and test the alarms and inspection when it occurs.

To avoid any danger or accident, please do not ask anyone who are not familiar with construction and not have sufficient knowledge of electricit, please entrust us with inspection and replacement task.

| Alarm                  | Check and Test Item  | Inspecting part  | Confirming Item  |
|------------------------|--|--|--|
| Drying blower overload | Thermal relay of drying blower trips.  | Check thermal relay (FR1A) set up value.                                       | Adjust to nominal current value equals to that of power supply being used.                           |
|                        |  | Drying blower (M1A)  | To check if there is a breakdown.  |
|                        |  | Suction and exhaust of drying blower(M1A)                                      | To keep a certain wind blow passage.   |
| Regen blower overload  | Thermal relay of regeneration blower trips.  | Check thermal relay (FR1B) set up value.                                       | Adjust to nominal current value equals to that of power supply being used.                           |
|                        |  | Regeneration blower (M1B)  | To check if there is a failure.  |
|                        |  | Suction and exhaust of regeneration blower (M1B)                               | To keep a certain wind blow passage.   |
| Inverter alarm         | While PIC is sending out Run signal to inverter, the latter can not return signal under operation to PLC, and this lasted for more than 5 seconds. | Operation method   | Power supply connected and disconnected within a short period of time. Working power supply stopped. |
|                        |  | Improper power supply to inverter  | Provide 3 phase power supply to inverter   |
|                        |  | Wire connection to inverter load   | Wire correctly connected to drying blower or regeneration blower.                                    |
|                        |  | Connection of signal wire to inverter  | Wire properly connected  |
|                        |  | Set up of inverter   | Set a proper value   |
| Feed blower overload   | Motor-protective circuit-breaker or inverter of convey blower trips (overload or overvoltage.)   | Check set up value of motor-protective circuit-breaker (QM1) of convey blower. | Adjust to nominal current value equals to that of power supply being used.                           |
|                        |  | Feed blower (M2)   | To check if there is a breakdown.  |
|                        |  | Suction and exhaust of feed blower (M2)  | To keep a certain wind blow passage  |

| Alarm            | Check and Test Item  | Inspecting part   | Confirming Item   |
|------------------|--|---|---|
|                  |  | Improper power supply to inverter                                     | Provide 3 phase power supply to inverter                          |
|                  |  | Wire connection to inverter load                                      | Wire correctly connected to drying blower or regeneration blower. |
|                  |  | Connection of signal wire to inverter                                 | Wire properly connected   |
|                  |  | Set up of inverter  | Set a proper value  |
| Heater overheat  | Normal temperature signal sent out by thermostat installed in drying and regenerative heater not being checked and tested. | Temperature set up of thermostat (ST1) used by drying heater          | Drying temperature +20°C below 180°C                              |
|                  |  | “Normal temperature” circuit (thermostat: ST1, ST2 and relay KA1,KA2) | Normal conductor configuration connection                         |
|                  |  | Thermostat (ST1,ST2)  | Normal operation  |
|                  |  | Relay (KA1)   | Normal operation  |
|                  |  | SSC (V1[V10,V11],V2)  | Normal operation (Failure remove under ON mode)                   |
|                  |  | Drying blower (M1A), regenerative blower (M1B) and wind blow pipping  | Normal wind blow (To remove piping fall off and air leakage)      |
| Drying high temp | Drying temperature standby mode with program upper limit checking and testing upper limits.                                | SSC (V1[V10,V11],V2)  | Normal operation (To remove failure under ON mode )               |
|                  |  | Drying blower (M1A) and wind blow pipping                             | Normal wind blow (To remove piping fall off and air leakage )     |
| Drying low temp  | Drying temperature standby mode with program lower limit checking and testing of lower limits.                             | Drying heater (EH1[EH10,EH11])  | Normal operation  |
|                  |  | Relevant conductor configuration to drying heater                     | Normal conductor configuration connection                         |
|                  |  | Circuit-breaker (FS3)   | Normal power supply (remove of tripping and disconnection)        |
|                  |  | Drying blower (M1A) and wind blow pipping                             | Normal wind blow (remove of piping fall off and air leakage)      |
| Regen high temp  | Regenerative temperature standby mode with program upper limit checking and testing  | SSC (V1[V10,V11],V2)  | Normal operation (To remove failure under ON mode )               |
|                  |  | Regenerative blower and wind blow pipping                             | Normal wind blow (To remove piping fall off and air leakage)      |




| Alarm                     | Check and Test Item   | Inspecting part  | Confirming Item  |
|---------------------------|---|--|--|
| Regen low temp            | Regenerative temperature standby mode with program lower limit checking and testing               | Regenerative heater (EH2)  | Normal operation   |
|                           |   | Relevant conductor configuration to regenerative heater                                  | Normal conductor configuration connection                                  |
|                           |   | Circuit-breaker (FS4)  | Normal power supply (To remove tripping and disconnection )                |
|                           |   | Regenerative blower (M1B) and wind blow piping   | Normal wind blow (Remove of pipe fall off and air leakage)                 |
| Drying temp sensor alarm  | Thermocouple disconnected, improper connection, temperature check and test out of measuring range | Thermocouple (BT1, BT2, BT3)   | Thermocouple is conducted.<br>Normal connection<br>Insulating to the earth |
| Exhaust temp sensor alarm |   |  |  |
| Regen temp sensor alarm   |   |  |  |
| Dry setting error         | Information exchange abnormality between devices  | PLC  | Normal operation   |
| Exhaust setting error     |   |  |  |
| Regen setting error       |   |  |  |
| Honeycomb rotating alarm  | Stopping mode by specific timer   | The honeycomb rotor driving belt   | Damage, fall off, loose  |
|                           |   | Rotating motor (M3), driving sector  | Damage, fall off, loose, breakdown.  |
|                           |   | Limit switch for rotation check and test (SR1)   | Damage, fall off, loose, breakdown.  |
|                           |   | Connection of conductor configuration of limit switch (SR1) for rotation check and test. | Normal connection  |
|                           |   | PLC input component (D13)  | Normal operation   |

| Alarm                       | Check and Test Item  | Inspecting part   | Confirming Item  |
|-----------------------------|--|---|--|
| Drying hopper feed alarm    | Level empty remaining even after the set up convey frequency is done.<br>Timer set up for level empty continuance.<br><br>Level switch can not check and test material decrease. | Level switch, JC Limit switch<br>Level switch conductor configuration<br>Convey side<br>Convey piping | Normal operation<br>Normal connection<br>Material amount, bridge building falling off, air leakage |
| No.1 feed alarm             | Timer set up for level empty continuance.  |   |  |
| No.2 feed alarm<br>* Option |  |   |  |
| Dust cleaning               | The set up cleaning frequency is due   | Dust collecting bin   | Clean up<br>Alarm reset  |

| Alarm                      | Check and Examine Item                                   | Inspecting Part  | Confirming Item  |
|----------------------------|--|--|--|
| Temp controller alarm      | Cold junction compensator is abnormal                    | Cold junction compensator of temperature adjust component (D14)                                    | Connection confirm or replacement  |
|                            | CPU component WDT check and test                         | CPU component (D12) display part of PLC  | Proper component set up<br>Reset operation on electric-controlled box or power supply reconnection<br>↓ nonfixable<br>PLC component replacement                              |
| PLC alarm                  | I/O construction confirmed improper                      | Touch screen of the controller on the operating panel.<br>CPU component (D12) display part of PLC. | Proper component set up<br>Reset operation on electric-controlled box or power reconnection<br>↓ nonfixable<br>PLC component replacement                                     |
|                            | Cycling time redundant                                   |  |  |
|                            | Order operating error                                    |  |  |
| PLC battery alarm          | PLC battery is not connected.                            | Battery socket connector inside of the cover of CPU component (D12) of PLC                         | Proper connection and inlaid   |
|                            | PLC battery voltage is very low.                         | Battery voltage inside of the cover of CPU component (D12) of PLC                                  | Battery replacement under low voltage<br>(Replace the battery with a new one within one minute after machine power supply has been connected for more than 1 minute.)        |
| Touch screen battery alarm | Battery of program monitor not connected.                | Battery socket connector inside of opposite side of the program monitor.                           | Proper connection and inlaid.  |
|                            | Battery voltage of program monitor is very low.          | Battery voltage inside of opposite side of program monitor   | Battery replacement under low voltage<br>(Please replace the battery with a new one within one minute after machine power supply has been connected for more than 1 minute.) |
| Power supply is shut off   | Main power supply is shut off during a drying operation. | Operation method   | Working power supply stopped.  |

## 4. Cancel the setting of [i plas]

When [  ] on the “Home” flickers, temperature drops. The resin effect of temperature change is large, it is necessary to cancel the setting of [i plas].

| Display  | Operating method / Function and operation description  |
|--|--|
| <p>Temp setting</p>                                       | <p>Press  on home or  in various windows to go to 「DryingSetting」 window.</p>  |
| <p>Temp setting</p>  <p>[ENG setting] Password: D000</p> | <p><u>Security level change operation</u></p> <p>Press  in DryingSetting window to go to dialogue box for code input of security level change.</p> <p>Input code through the alphabet and number shown in the left photo. If press[ENT] and the code accepted, then switching key 「ENG Setting」 appear.</p> <p>During inputing, press [CLR] to delete all character at once by one time.</p>  |
| <p>ENG Function</p>                                     | <p>Press  on “DryingSetting” window to go to its window setup.</p> <p>Press [  ] to go to 「ENG Function」 window.</p> <p>Hold press  until it reverses to cancel the setting of [i plas]. Repeat hold press  until it reverses to be enable the setting of [i plas]</p> |

# Chapter 10. Components parts list

## 1. MJ5-i-150 Components parts list

| No,        | Parts code/<br>Drawing number-<br>Item No. | Parts name                         | Qty | Recommended<br>replacement cycle |
|------------|--|------------------------------------|-----|----------------------------------|
| Machine    |  |                                    |     |                                  |
| 1          | CODE:19154                                 | Drying filter                      | 1   | 1year                            |
| 2          | CODE:19154                                 | Convey filter                      | 1   | 1year                            |
| 3          | CODE:17736                                 | Regenerative filter                | 1   | 1year                            |
| 4          | CODE:20857                                 | U type packing                     | 2   | 1year                            |
| 5          | CODE:00427                                 | PVC Hose W38×5m                    | 1   | 1year                            |
| 6          | CODE:00427                                 | PVC Hose W38×10m                   | 1   | 1year                            |
| 7          | CODE:21276                                 | Honeycomb Timing belt              | 1   | 1year                            |
| 8          | CODE:09617                                 | Regeneration overheat setting unit | 1   | 2year                            |
| 9          | CODE:15265                                 | Dry overheat setting unit          | 1   | 3year                            |
| Electrical |  |                                    |     |                                  |
| 10         | No,B19004<br>Item No.12                    | Contactor                          | 1   | 1year                            |
| 11         | No,B19004<br>Item No.31                    | Battery                            | 1   | 1year                            |
| 12         |  | CR2032 Lithium battery             | 1   | 3year                            |

|             |
|-------------|
| <b>NOTE</b> |
|-------------|

1. The recommended replacement cycle is use environment, it will vary depending on usage.
2. Item 8, 9 if that is the exchange of over-temperature prevention instrument, will be the safety device parts always nearest because Please contact the Corporation Matsui SDI (back cover).

## 2. MJ5-i-350 Components parts list

| No,        | Parts code/<br>Drawing number-<br>Item No. | Parts name                         | Qty | Recommended<br>replacement cycle |
|------------|--|------------------------------------|-----|----------------------------------|
| Machine    |  |                                    |     |                                  |
| 1          | CODE:19154                                 | Drying filter                      | 1   | 1year                            |
| 2          | CODE:19154                                 | Convey filter                      | 1   | 1year                            |
| 3          | CODE:17736                                 | Regenerative filter                | 1   | 1year                            |
| 4          | CODE:20857                                 | U type packing                     | 2   | 1year                            |
| 5          | CODE:00427                                 | PVC Hose W38×5m                    | 1   | 1year                            |
| 6          | CODE:00427                                 | PVC Hose W38×10m                   | 1   | 1year                            |
| 7          | CODE:21276                                 | Honeycomb Timing belt              | 1   | 1year                            |
| 8          | CODE:09617                                 | Regeneration overheat setting unit | 1   | 2year                            |
| 9          | CODE:15265                                 | Dry overheat setting unit          | 1   | 3year                            |
| Electrical |  |                                    |     |                                  |
| 10         | No,B19004<br>Item No.12                    | Contactor                          | 1   | 1year                            |
| 11         | No,B19004<br>Item No.31                    | Battery                            | 1   | 1year                            |
| 12         |  | CR2032 Lithium battery             | 1   | 3year                            |

### NOTE

1. The recommended replacement cycle is use environment, it will vary depending on usage.
2. Item 8, 9 if that is the exchange of over-temperature prevention instrument, will be the safety device parts always nearest because Please contact the Corporation Matsui SDI (back cover).

### 3. MJ5-i-650 Components parts list

| No,               | Parts code/<br>Drawing number-<br>Item No. | Parts name                         | Qty | Recommended<br>replacement cycle |
|-------------------|--|------------------------------------|-----|----------------------------------|
| <b>Machine</b>    |  |                                    |     |                                  |
| 1                 | CODE:19154                                 | Drying filter                      | 1   | 1year                            |
| 2                 | CODE:19154                                 | Convey filter                      | 1   | 1year                            |
| 3                 | CODE:00612                                 | Regenerative filter                | 1   | 1year                            |
| 4                 | CODE:20857                                 | U type packing                     | 2   | 1year                            |
| 5                 | CODE:00427                                 | PVC Hose W38×5m                    | 1   | 1year                            |
| 6                 | CODE:00427                                 | PVC Hose W38×10m                   | 1   | 1year                            |
| 7                 | CODE:21276                                 | Honeycomb Timing belt              | 1   | 1year                            |
| 8                 | CODE:09617                                 | Regeneration overheat setting unit | 1   | 2year                            |
| 9                 | CODE:15265                                 | Dry overheat setting unit          | 1   | 3year                            |
| <b>Electrical</b> |  |                                    |     |                                  |
| 10                | No,B19004<br>Item No.12                    | Contactor                          | 1   | 1year                            |
| 11                | No,B19004<br>Item No.31                    | Battery                            | 1   | 1year                            |
| 12                |  | CR2032 Lithium battery             | 1   | 3year                            |

|             |
|-------------|
| <b>NOTE</b> |
|-------------|

1. The recommended replacement cycle is use environment, it will vary depending on usage.
2. Item 8, 9 if that is the exchange of over-temperature prevention instrument, will be the safety device parts always nearest because Please contact the Corporation Matsui SDI (back cover).

#### 4. MJ5-i-1500 Components parts list

| No,               | Parts code/<br>Drawing number-<br>Item No. | Parts name                         | Qty | Recommended<br>replacement cycle |
|-------------------|--|------------------------------------|-----|----------------------------------|
| <b>Machine</b>    |  |                                    |     |                                  |
| 1                 | CODE:19154                                 | Drying filter                      | 1   | 1year                            |
| 2                 | CODE:19154                                 | Convey filter                      | 1   | 1year                            |
| 3                 | CODE:00612                                 | Regenerative filter                | 1   | 1year                            |
| 4                 | CODE:20857                                 | U type packing                     | 2   | 1year                            |
| 5                 | CODE:00428                                 | PVC Hose W50×10m                   | 1   | 1year                            |
| 6                 | CODE:25135                                 | Honeycomb Timing belt              | 1   | 1year                            |
| 7                 | CODE:09617                                 | Regeneration overheat setting unit | 1   | 2year                            |
| 8                 | CODE:15265                                 | Dry overheat setting unit          | 1   | 3year                            |
| <b>Electrical</b> |  |                                    |     |                                  |
| 9                 | No,B51171<br>Item No.12<br>(B51172)        | Contactor                          | 1   | 1year                            |
| 10                | No, B51171<br>Item No.31                   | Battery                            | 1   | 1year                            |
| 11                |  | CR2032 Lithium battery             | 1   | 3year                            |

|             |
|-------------|
| <b>NOTE</b> |
|-------------|

1. The recommended replacement cycle is use environment, it will vary depending on usage.
2. Item 8, 9 if that is the exchange of over-temperature prevention instrument, will be the safety device parts always nearest because Please contact the Corporation Matsui SDI (back cover).



# Chapter 11. Options

---

## 1. Alarm indicator

It will light up when alarm occurs.

All alarms can be confirmed in a comparative broad range.

## 2. General alarm output

General alarm output is through terminal block in the electric-controlled box (line no.: EX1, EX2).

When the alarm output is given, joint point is "ON". (No voltage relay output, resistance load 250V 3A Max)

## 3. Weekly timer

Through the weekly timer set up, this dryer can carry out Automatic Start Up or Automatic Stop. You can do this by switching "ENG Setting" to "ENG Function". If "ext start" is "On", machine will operate according to the setting of weekly timer.

Please refer to manual for this usage.

**Note**

When not use external start signal of weekly timer, etc (line no.: N1, 205), please set "External Start up" on ENG Function window "OFF"

## 4. Dew point monitor

To show dehumidifying dew point temperature

Dew point monitor does not show anything when drying wind blow stops in energy-saving operation.

## 5. Power meter

It is used to measure device power.

Please refer to operation instruction book for this usage.


## 6. Leakage breaker

When electricity leakage breaker is installed, ground protection is effected.

## 7. Secondary convey two directions

This machine can feed two molding machines.

Please connect hoses in the way as they are shown in below drawing.




| NO | Name                            | Factory        | Model   | QTY         |
|----|---------------------------------|----------------|---|-------------|
| 1  | 2 direction branch unit         | Matsui MFG     | —   | 1<br>Set    |
| 2  | 3 direction select valve        | Matsui MFG     | 3VN-φ38(MJ5-i-150~650)<br>3VN-φ63(MJ5-i-1500)   | 1<br>Set    |
| 3  | Manifold electromagnetism valve | Matsui MFG     | For 3VN   | 1           |
| 4  | Piping bracket                  | Matsui MFG     | —   | 1           |
| 5  | PVC hose                        | Tigers polymer | W-38×1m(MJ5-i-150~650)<br>W-50×1m(MJ5-i-1500)   | 1           |
| 6  | PVC hose                        | Tigers polymer | W-38×5m(MJ5-i-150~650)<br>W-50×5m(MJ5-i-1500)   | 1           |
| 7  | GL hose                         | Tigers polymer | GL-φ38×5m(MJ5-i-150~650)<br>GL-φ65×5m (MJ5-i-1500)                                      | 1           |
| 8  | Hose band                       | General parts  | AK-1045(MJ5-i-150~650)<br>AK-1058(MJ5-i-1500)[PVC hose]<br>AK-1073(MJ5-i-1500)[GL hose] | 4<br>4<br>2 |

\* Hose length differs by specifications

## 8. Connecting JET SELECTOR

Primary and secondary feeding can be carried out with JET SELECTOR (Option for sale) to make simple mixture of master material and grinding material.



| NO | Parts Name   | Factory        | Model   | Qty      |
|----|--------------|----------------|---|----------|
| 1  | JET SELECTOR | Matsui MFG     | JSV-38(MJ5-i-150~650)<br>JSV-50(MJ5-i-1500)   | 1<br>Set |
| 2  | JSV bracket  | Matsui MFG     | —   | 1        |
| 3  | PVC hose     | Tigers polymer | W-38(MJ5-i-150~650)<br>W-50(MJ5-i-1500)       | 1        |
| 4  | Hose band    | On market      | AK-1045(MJ5-i-150~650)<br>AK-1058(MJ5-i-1500) | 2        |
| 5  | Metal socket | Nanaboshi      | NJC-204                                       | 1        |

## 9. Compatibility of different voltage


This dryer can be compatible with different voltage in the option.

(You can contact us for further advice about voltage compatibility, when purchasing or altering the goods.)

## 10. Lower limit level alarm switch

With lower limit level alarm switch to be installing in the hopper, we report material low level.


Use with the option of alarm indicator light(Rotating lamp, Laminating lamp).



|            | Referential remnant |
|------------|---------------------|
| MJ5-i-150  | 7.5L                |
| MJ5-i-350  | 16L                 |
| MJ5-i-650  | 30L                 |
| MJ5-i-1500 | 105L                |

## 11. It installs DIGI-PECA switch

By installing DIGI-PECA switch (sold separately), when not using secondary conveying of visceral, too, opening and shutting control of push damper can be done.



# Chapter 12. Specifications

| Item NAME                  |   |              | MJ5-i-150  | MJ5-i-350         | MJ5-i-650         | MJ5-i-1500        |
|----------------------------|---|--------------|--|-------------------|-------------------|-------------------|
| Drying hopper              | L   |              | 50   | 100               | 200               | 500               |
|                            | Heat preservation   |              | Glass wool   |                   |                   |                   |
| Drying fresh air dew point | *<br>Fresh air condition:<br>Temperature 30°C<br>Relative humidity: 75%<br>DP+25°C<br>Presumed fresh air mixture: 10% |              | * -40 ~ -60°C (Minimum)<br>(Drying fresh air dew point differs by working condition) |                   |                   |                   |
| Drying temperature         | °C  |              | 60~160   |                   |                   | 70~160            |
|                            |   |              | [When fresh air reaching 10°C~35°C]  |                   |                   |                   |
| Drying blower              | Model   |              | RB20-520   | RB30-520          | RB40-520          | RB60-520          |
|                            | Motor output: kW  |              | 0.28   | 0.42              | 1.15              | 2.55              |
| Drying heater              | Capacity :kW  | 200V 50/60Hz | 2.1  | 2.4               | 5.4               | 10.8              |
|                            |   | 220V 60Hz    | 2.54   | 2.9               | 6.53              | 13.1              |
|                            |   | 380V 50/60Hz | 2.1  | 2.4               | 5.4               | 10.8              |
|                            |   | 400V 50/60Hz | 2.32   | 2.66              | 5.97              | 12.0              |
|                            |   | 415V 50/60Hz | 2.5  | 2.86              | 6.43              | 12.9              |
|                            |   | 440V 50/60Hz | 2.56   | 2.93              | 5.4               | 10.8              |
| Regenerative blower        | Model   |              | RB20-520   |                   | RB30-520          | RB40-520          |
|                            | Motor output: kW  |              | 0.28   |                   | 0.42              | 1.15              |
| Regenerative heater        | Capacity :kW  | 200V 50/60Hz | 1  | 2.1               | 3.1               | 5.8               |
|                            |   | 220V 60Hz    | 1.21   | 2.54              | 3.75              | 7.02              |
|                            |   | 380V 50/60Hz | 1  | 2.1               | 3.1               | 5.8               |
|                            |   | 400V 50/60Hz | 1.11   | 2.32              | 3.43              | 6.43              |
|                            |   | 415V 50/60Hz | 1.2  | 2.5               | 3.69              | 6.9               |
|                            |   | 440V 50/60Hz | 1.23   | 2.56              | 3.1               | 5.8               |
| Absorption tower           | Name  |              | The honeycomb rotor  |                   |                   |                   |
|                            | Model   |              | MZC-200H20 slow-S  | MZC-200H30 slow-S | MZC-250H30 slow-S | MZC-300H30 slow-S |
| Absorption tower motor     | Motor output: kW  |              | 25   |                   |                   |                   |
|                            | Reduction gear ratio  |              | 1/3600   |                   |                   | 1/1200            |
| Drying filter              | Item name   |              | MXF-16SP-G1  |                   |                   |                   |
|                            | Filter area (m <sup>2</sup> )   |              | 0.5  |                   |                   | 0.5 x 2           |
| Convey filter              | Item name   |              | MXF-16SP-G1  |                   |                   |                   |
|                            | Filter area (m <sup>2</sup> )   |              | 0.5  |                   |                   |                   |
| Regenerative filter        | Item name   |              | FILEDON  |                   |                   |                   |
|                            | Filter area (m <sup>2</sup> )   |              | 0.015  |                   | 0.028             |                   |

\*There also can obtained the minimum dew point (-60°C) if the conditions below.

| Item Name         |                                     | MJ5-i-150  | MJ5-i-350  | MJ5-i-650 | MJ5-i-1500   |      |
|-------------------|-------------------------------------|--|--|-----------|--------------|------|
| Compressed air    | Pressure   MPa                      | 0.5  |  |           |              |      |
|                   | Flow rate   L/h                     | 10   |  |           | 20           |      |
|                   | Joint size   mm                     | φ6   |  |           |              |      |
| Convey            | Primary convey   m                  | 10   |  |           |              |      |
|                   | Secondary convey   m                | 5  |  |           | 10           |      |
| Convey piping     |                                     | φ38 PVC hose   |  |           | φ50 PVC hose |      |
| Convey blower     | Model                               | RB40-620   |  |           | RB50-620     |      |
|                   | Motor output kW (50/60Hz)           | 1.1/1.5  |  |           | 2.55         |      |
| Dimension         | W (mm)                              | 1125   | 1191   | 1486      | 1910         |      |
|                   | D (mm)                              | 618  | 618  | 638       | 914          |      |
|                   | H (mm)                              | 2117   | 2203   | 2509      | 2689         |      |
| Gross weight (kg) |                                     | 270  | 290  | 400       | 690          |      |
| Optional function |                                     | (1)Alarm indicator (2)General alarm output (3)Weekly timer(4)Dew point monitor (5)Power meter (6)Electricity leakage switch (7)The honeycomb rotor rotate check and test (8) Secondary convey 2 directions (9)Feeding selector JSV-38[50] (10)Compatibility of different voltage (UL/CE excluded) (11) Signal line extension (12)Power supply line extension (13) Convey hose length alteration (14)Specified color (only for outer casing) (15) Moment power failure (1Sec) |  |           |              |      |
| Control           | Drying temperature adjustment       |  | PID, Heater driven by non-contact relay  |           |              |      |
|                   | Regenerative temperature adjustment |  | PID, Heater driven by non-contact relay  |           |              |      |
|                   | Alarm or Protect circuit            |  | Drying and Regenerative overheat protection, Blower overload, Protection from Dry and Regeneration blower's reversal, Protection from Convey blower's reversal[MJ5-i-1500] |           |              |      |
|                   | External start up input             |  | External non-voltage contact<br>[Standard electricity: 4.1mA (DC24V)]  |           |              |      |
|                   | Operating circuit voltage           |  | AC100V , DC24V   |           |              |      |
|                   | Power supply capacity               | 200V 50/60Hz   | 6.8  | 8.5       | 13.9         | 27.2 |
|                   |                                     | 220V 60Hz  | 7.6  | 9.6       | 15.8         | 31.0 |
|                   |                                     | 380V 50/60Hz   | 6.9  | 8.6       | 14.0         | 28.6 |
|                   |                                     | 400V 50/60Hz   | 7.2  | 9.2       | 15.1         | 30.8 |
| 415V 50/60Hz      |                                     | 7.6  | 9.7  | 15.8      | 32.5         |      |
| 440V 50/60Hz      |                                     | 7.6  | 9.5  | 15.0      | 29.8         |      |