

Mass Blender
JCW2-10·20
INSTRUCTION MANUAL



Thank you very much for purchasing our product.
Please carefully read this instruction manual for correct use.
During operation, keep this manual close at hand so that it can be referred to whenever necessary.

Product Warranty

Thank you very much for purchasing our product. Please carefully read this instruction manual for correct and safe use. In addition, this page of this instruction manual serves as the product warranty. Make sure to carefully store the instruction manual after reading it.

1. Warranty period

Warranty of this product warrants repair or replacement of parts free of charge if any failure occurs even when this product is normally used according to the operation procedures, etc., within the warranty period of the product warranty.

In addition, failure products shall be returned to us.

- 1) The warranty term of the product is 12 months after the initial operation, but shall not exceed 15 months after the date of shipment of the product.
- 2) The warranty period for parts replaced during repairs shall be three months from the date of repairs.

2. Scope of Warranty

The following items, if applicable, are not covered by the free warranty even within the warranty period.

- 1) Failure or damage caused by modifications or repairs carried out by any person other than us
- 2) Failure or damage caused by natural disasters such as earthquake, typhoon, flooding, etc., and accident or fire
- 3) Failure or damage caused by use exceeding the limit of the specifications described in this instruction manual, catalog, etc., or by installation environment
- 4) Failure or damage caused by improper use or handling
- 5) Effect on products caused by external factors
(Paint peeling due to generated gas, malfunction due to electrical noise, etc.)
- 6) Failure or damage caused by use of parts other than genuine parts (oil, medium, filter, etc.)
- 7) Consumables (hoses, filters, packings, O-rings, electric magnet contactors, mechanical seals, etc.)
- 8) When the product is transferred or leased to third party
 - The scope of warranty includes up to repair or replacement of parts of our products, and does not include products manufactured by use of our products and damage to other products due to failure or use of our products. In addition, “transportation expenses,” “customs duties,” “travel expenses” and “commuting expenses” associated with the repair or replacement of parts shall be separately paid.
 - The product price does not include the following service expenses. They are separately charged.
(However, this does not apply if the contract includes the following)
 - 1) Technical guidance and technical education
 - 2) Installation adjustment guidance and trial operation attendance
 - 3) Maintenance and inspection, adjustment and repair

3. After expiration of the warranty period

If performance can be maintained by repairs, we shall repair the equipment for a fee at your request.


4. Parts supply period

Functional parts for repairs can be supplied until about eight years after the end of production of the equipment. However, some parts can be supplied even after the lapse of the period. Please contact our service division for information.

5. Others




For technical information, refer also to the maintenance and inspection procedures, and troubleshooting on our website (<http://matsui-mfg.co.jp/troubleshooting/>).





CONTENTS

Since the items marked with  are especially important, carefully read and understand these items before using the product.

Product Warranty

Contents	I – II
----------------	--------

Chapter 1	 For Your Safe Operation	
	1. Hazard symbols and meanings	1
	2. Maintaining items for safe operation	2
	3. Labels	4
Chapter 2	 Cautions on Operation	5
Chapter 3	Description of Equipment	
	1. Overview of the system	10
	2. Overview of flow	10
Chapter 4	Installation	
	1. Installation of Jet Clone (Collector) for primary conveyance	11
	2. Installation of mixing part (APH, SB type)	12
	3. Installation of blender	13
	4. Installation of conveying air source	14
	5. Connection of suction hose between each device	14
	6. Connection of conveying hose between each device	15
	7. Connection of signal line cord between each device	16
	8. Feeding operating compressed air to air kit for each device	18
	9. Power connection	20
Chapter 5	Preparations for Operation	
	1. Confirming pressure of operating compressed air	23
	2. Condition check of each unit	24
	3. Power supply	30
Chapter 6	Weighing Check	
	1. Preparation for weighing check	31
	2. Weighing check of No. 1 material	33
	3. Weighing check of No. 2 material	36
Chapter 7	Various Settings	39
Chapter 8	 Automatic Operation	
	1. Start operation for automatic operation	44
	2. Stop operation for automatic operation	49

Chapter 9	 Manual Operation	
	1. Manual operation for blender	51
	2. Manual operation for conveying related devices	52
Chapter 10	Material Removal and Cleaning for Blender	
	1. Material removal from inside of each material tank and hopper	53
	2. Cleaning the weighing hopper	56
	3. Cleaning the No. 3 hopper	57
	4. Cleaning the charge hopper (for JB)	58
	5. Cleaning the weighing screw	59
	6. Suction cleaning by a blower	60
Chapter 11	 Maintenance and Check	62
	1. Daily maintenance and check	63
	2. Weekly maintenance and check	66
	3. Monthly maintenance and check	68
	4. Every three months maintenance and check	73
	5. How to adjust each device	74
	6. How to check operation of various automatic valves for blender	76
	7. How to check operation of automatic valve for mixing part	77
Chapter 12	 Alarm Function	78
Chapter 13	 Causes of Troubles and Remedies	79
Chapter 14	Consumables List	84
Chapter 15	Specifications	85
	Attached Documents	
	1. Mass blender Operation panel	
	2. Drawing	

Chapter 1 FOR YOUR SAFE OPERATION

This chapter contains precautions for operation, maintenance, and repair to operate this equipment properly and safely. Descriptions are provided for each of the instruction symbols and labels on the products.








WARNING

Instructions for safety described in this manual should be strictly observed when operating or inspecting this product. Matsui shall not be responsible for any injury or accidents caused by failure to observe these instructions and we make no warranty against such injury or accidents.

1. Hazard symbols and meanings

This instruction manual uses the following hazard symbols depending on the hazard type.

Symbol	Meaning
 DANGER	This indication is used when failure to observe this may cause a fatal injury or major hazard. Instructions below this indication explain how to prevent them.
 WARNING	This indication is used when failure to observe this may cause physical injury and property damage. Instructions below this indication explain how to prevent the hazard.
 CAUTION	This indication is used when failure to observe this may cause minor physical injury or property damage. Instructions below this indication explain how to prevent them.
NOTE	This indication is used when special care is needed in operation procedures or descriptions, and to emphasize such information.
	This mark is used when special care must be taken in the handling process.
	This mark is used when exceptional conditions or cautions are described in tables and/or figures.

2. Maintaining Items for Safe Operation

There are general attention items for using this product safely.



1) Usage environment

- ① This equipment should be used indoors.
- ② This equipment should be used at ambient temperatures from 0°C to 40°C and an ambient humidity of 25 – 85%.

2) Electric power

Do not check or exchange without MATSUI S.D.I. or the employee in your company who has expert knowledge about electricity, because the operation includes the possibility of failure or danger.

3) Never use in gas

Never use this product with a combustible, explosive gas or vapor.
It is very dangerous.

4) Prohibition of reconstruction

Never perform reconstruction or modification without our approval. We are not responsible for trouble as a result of reconstruction.

5) Maintenance and check

Before starting maintenance and check work, make sure to stop operation and turn OFF the primary power source and the power breaker NFB-1 and the disconnect switch QS-1 of the control panel.
Then stop supplying compressed air to the air kit for each device and release the remaining pressure in the air piping by opening the air filter and drain pipe of the filter regulator.

6) Maintenance

Do not check or exchange except by an employee who has expert knowledge about the product, because the operation includes the possibility of failure or danger. Please contact the nearest MATSUI S.D.I. (refer to the back cover), when you need maintenance or repair.



1) Disposal of this product and its parts

This product and its parts are handled as industrial waste, and shall be subject to regulations by “Law concerning disposal of waste and cleaning.” Request an industrial waste disposal operator who has received an “Industrial waste collection and transportation trade license” or “Industrial waste disposal trade license” for disposal. For details, contact the environmental improvement-related department of your respective prefecture.

2) Power unit

Please use under the exact electrical voltage and frequency according to the specifications, and establish a ground securely.

3) Periodic inspection

Component device and used parts basically have a useful life. In particular, it is expected that material grain contact devices and parts are periodically inspected, and for some of these parts where replacement is deemed necessary, ask MATSUI S.D.I. Corporation to carry out inspection in advance.

NOTE

1) Wiping

Do not use petroleum based solvents. Wiping with benzene, thinner, polishing powder etc., will scratch the surface. If the labels become dirty, wipe with a soft cloth that has been soaked in water or hot water under 40°C and wring well.

3. Labels

Labels are attached to this product at a position where particular attention is required by the degree of danger. Before starting the operation be sure to fully understand the instructions with the WARNINGS and CAUTIONs.

1) Maintenance of labels

- Keep the labels legible until you dispose of this unit.
- If the labels become dirty, wipe with a soft cloth that has been soaked in water or hot water under 40°C and wring well. Do not use a petroleum based solvent and thinner in any case.

Chapter 2 CAUTIONS ON OPERATION

This chapter describes precautions specific to the product.

To prevent the occurrence of danger, precautions are described with headings (See Section 1, Chapter 1) from the most important items.

1. Precautions specific to the product



● Application


This is a blending, conveying and mixing system for planned specification material (resin pellet).

Other materials are not suitable for this system and will cause a malfunction.

Note that troubles caused by use of materials other than the planned specification are not covered under warranty.


● Screw feeder for blender

- ◎ Before taking off the motor unit at the rear of the screw feeder SF-50ST, be sure to disconnect the power connector of the motor. Do not perform maintenance and check work with the power connector connected. This is very dangerous, and it may cause an accident.
- ◎ When opening the coupling case (motor part) at the rear of the screw feeder SF-50IT1, be sure to lock the opening position fixing hook. Do not perform maintenance and check work without locking the hook. This is very dangerous, and it may cause an accident.
- ◎ Securely install the motor unit at the rear of the screw feeder. (tightening by adjustment fastener)
Operation in a state of defective installation will cause an abnormality to occur and system damage.



● Load cell and weighing hopper for blender


- ◎ Never give impact to the load cell and weighing hopper. Any load exceeding the rated value may damage the load cell.
- ◎ Do not touch the stopper bolt around the load cell.
A larger gap may not protect the load cell from shock.
- ◎ Do not put your hands into the weighing hopper. Hands and fingers will be caught by the damper, causing lacerations or fractures.



● Butterfly valve for suction cleaning installed on the blender side. (Optional)


Securely close it and fix the handle during normal operation.

Operating in the valve open status may lower the performance or cause an abnormality.




● Each auto shutter

- ◎ Do not put your hands and fingers into the moving parts (shutter part) during operation. There is a possibility of suffering lacerations and fractures.
- ◎ Never operate under a state that the material is inserted in the moving parts (shutter part). It may cause a malfunction.



MSD-22W


MSD-22WK



MSD-50SS


● Weighing part and mixing part

- ◎ Do not open the panel in front of the weighing part during operation. It may cause the system to stop and malfunction.
- ◎ Do not open the top lid for the mixing drum or aero power hopper and do not remove the hose port during operation. It may cause contamination of the system and injury due to system stop and scattering of material powder.
- ◎ Never put your fingers or hands into the moving parts (damper part) of the automatic slide damper and discharge damper during operation. There is a possibility of suffering lacerations or fractures.
- ◎ Never operate under a state that the material is inserted in the moving parts (damper part) of the automatic slide damper and discharge damper. It may cause a malfunction.
- ◎ Do not charge an amount of material larger than the specified one batch amount into the mixing drum or aero power hopper. It may cause a malfunction.




● Conveying air source unit (Jet loader)

Do not remove the filter case lid and dust hopper during operation. Material powder will scatter and cause contamination of the system and injury.



V type



VC type

● Operation panel for control panel

Touch switches are arranged on the screen so as to be directly touched by fingers, however, operate slowly and securely.

The screen is made of resin, therefore, do not operate with hard objects such as a pen and metal. The screen may be damaged and will result in breakage in a worst case.



Chapter 3 DESCRIPTION OF EQUIPMENT

1. Overview of the system


In this system, natural pellet materials and MB pellets are fed by the auto shutter, and crushed materials and MB pellets, etc., are fed by the screw feeder respectively, and then their masses are weighed at the lower weighing hopper. The material for which weighing is completed is;

- with the [APH, SB type], conveyed to the mixing part by the mixing drum, or the demand level gauge installed at the charge hopper at the lower part of the aero power hopper, and is mixed for a specified time, then the mixed material is fed to the lower charge hopper.
- with the [JB type], weighed material, is discharged to the mixing drum by the demand level gauge installed at the charge hopper at the lower part of the mixing drum, and is mixed for a specified time, then the mixed material is fed to the lower charge hopper.


The above operation is repeated until the demand level gauge issues a full signal.

2. Overview of flow

APH, SB type (Batch separation type)



JB type (Batch integrated type)



Chapter 4 INSTALLATION

This chapter describes installation work for the product in order of procedures for each device.

1. Installation of Jet Clone (Collector) for primary conveyance




Fig. 4-1

Step	Work item	Work instruction
1	Installation of No. 3 material hopper	<p>Install the No. 3 material hopper to the connection short pipe of the blender side as shown in Fig. 4-2.</p> <p>No. 3 material hopper</p> <p>Connection short pipe</p> <p>Hang on the hook</p> <p>Fig. 4-2</p>
2	Installation of 3 jet clones	<p>Install each Jet clone at the No. 1 material tank, No. 2 material tank, No. 3 material hopper of the blender as shown in Fig. 4-1.</p> <p>Tap holes for Jet clone installation are tapped on each tank lid and hopper lid, be sure to use bolts suitable for the tapped holes to securely fix the Jet clones.</p>

NOTE

- ◎ Install the Jet clone horizontally. Unless it is horizontal, full material in the hopper may not be accurately detected.
- ◎ As the damper for the Jet clone has been adjusted at shipment, do not shock it. If it is shocked, full material in the hopper may not be accurately detected.

2. Installation of mixing part (APH, SB type)







Fig. 4-3

Step	Work item	Work instruction
1	Installation of mixing part (for APH, SB type)	Install the mixing drum or aero power hopper and charge hopper at the installation part of the molding machine as shown in Fig. 4-3. (The type and shape depend on the specification.)

3. Installation of blender


Step	Work item	Work instruction
1	Installation of blender	<p data-bbox="616 376 1214 409">Install the blender according to the facility condition.</p> <div data-bbox="632 443 1366 913">  <p data-bbox="1193 790 1366 857">Adjuster bolts (4 places)</p> <p data-bbox="632 779 871 902">APH, SB type (Also install JB type in the same way)</p> </div> <p data-bbox="979 936 1075 969">Fig. 4-4</p> <p data-bbox="616 976 1437 1043">* <u>When the installing position is determined, fix the equipment by the adjuster bolts if necessary.</u></p>
2	Installation of each primary conveying suction hose (GL-IV) to blender, and connection of signal line cord	<p data-bbox="616 1111 1437 1267">Install each suction hose at the suction port of each Jet clone and each primary conveying suction port on the blender, and connect each signal line cord (with connector) to the connectors for each Jet clone as shown in Fig. 4-5.</p> <div data-bbox="632 1290 1166 1760">  <p data-bbox="632 1469 783 1525">Signal line cord (with connector)</p> <p data-bbox="647 1626 831 1682">Primary conveying suction hose</p> </div> <p data-bbox="979 1794 1075 1827">Fig. 4-5</p> <div data-bbox="963 1850 1091 1906"> <p>NOTE</p> </div> <p data-bbox="616 1917 1414 1984">Securely tighten the hose band so as to avoid excessive suction from the connecting end of the hose.</p>

4. Installation of conveying air source


Step	Work item	Work instruction
1	Installation of conveying air source unit	<p>Install the conveying air source unit near the blender (in a range in which the 5m suction hose can access).</p>  <p style="text-align: center;">Fig. 4-6</p> <p>* <u>When the installing position is determined, be sure to apply the brakes for the casters (4 pieces) to lock. When the ON side of the caster brake is lowered as shown in Fig. 4-6, the brake is applied.</u></p>

5. Connection of suction hose between each device

Securely tighten the hose bands so as to avoid excessive suction from the connecting end of the hose.


Step	Work item	Work instruction
1	Connection of conveying suction hose	<p>Install a suction hose at the filter cyclone suction port for the conveying air source unit and at the conveying suction port for the blender as shown in Fig. 4-7.</p> <p>* Securely fix the hose with the hose bands and port master for GL-IV hose.</p>  <p style="text-align: center;">Fig. 4-7</p>

5. Connection of suction hose between each device


Step	Work item	Work instruction
2	Connection of secondary conveying suction hose (for APH, SB type)	<p>Install a suction hose at the suction port of the mixing part and at the secondary conveying suction port of the blender as shown in Fig. 4-8.</p>  <p>Secondary conveying suction hose</p> <p>Suction port</p> <p>Fig. 4-8</p>

6. Connection of conveying hose between each device


Securely tighten the hose bands so as to avoid excessive suction from the connecting end of the hose.

Step	Work item	Work instruction
1	Installation of each primary conveying hose (PVC hose)	<p>Install a conveying hose at the feed pipe of each Jet clone as shown in Fig. 4-9. And install the end of each conveying hose at each conveying source tank.</p>  <p>Feed pipe</p> <p>Fig. 4-9</p>



6. Connection of conveying hose between each device

Step	Work item	Work instruction
2	Installation of secondary conveying hose (PVC hose) (for APH, SB type)	<p>Install a conveying hose at the feed port of the aero power hopper and at the secondary conveying port of the blender as shown in Fig. 4-10.</p>  <p>Fig. 4-10</p>



7. Connection of signal line cord between each device

Step	Work item	Work instruction
1	Connection of signal line cord to conveying air source unit	<p>Connect a blower cable for the blender to the terminal box for the conveying air source unit as shown in Fig. 4-11.</p>  <p>Fig. 4-11</p>



7. Connection of signal line cord between each device

Step	Work item	Work instruction
2	Connection of signal line cord in mixing part (for APH, SB type)	<p>Connect the receiver cable (with connector) for the blender to the signal line cord (with connector) for the automatic slide damper of the mixing part as shown in Fig. 4-12.</p>  <p>Fig. 4-12</p>
3	Connection of signal line cord to level gauge (for APH, SB type)	<p>Connect the signal line cord (with connector) for the level gauge in the mixing part to the cord (with connector) for the level gauge installed at the lower hopper as shown in Fig. 4-13.</p>  <p>Fig. 4-13</p>

8. Feeding operating compressed air to air kit for each device

Step	Work item	Work instruction
1	Connection of air hose to blender air kit	<p>Connect an air hose of the compressed air source from your equipment to the air kit (air supply port of the finger valve) of the blender as shown in Fig. 4-14.</p>  <p style="text-align: center;">Fig. 4-14</p>
2	Connection of air hose to mixing part air kit (for APH, SB type)	<p>Connect an air hose for the compressed air source from your equipment to the air kit (air supply port for finger valve) for the mixing part as shown in Fig. 4-15.</p>  <p style="text-align: center;">Fig. 4-15</p>

8. Feeding operating compressed air to air kit for each device

Step	Work item	Work instruction
3	Feeding operating compressed air to each air kit and pressure setting	<p>Fully open the stop valves for each air kit to feed dry compressed air of 0.6MPa or higher from the compressed air source.</p> <p style="text-align: center;">↓</p> <p>Set the secondary air pressure in a range of 0.4 to 0.5MPa with the filter regulator for each air kit.</p> <ol style="list-style-type: none"> (1) Pull up the adjusting knob for the filter regulator, and unlock the adjusting knob. (2) Turn the adjusting knob to the right and left to adjust the indicated pressure on the pressure gauge in a range of 0.4 to 0.5MPa. Turn it to right, and the indicated pressure increases, and turn it to left, and the indicated pressure decrease. (3) Press down the adjusting knob to lock. <div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p style="text-align: center;">Fig. 4-16</p> <div style="border: 1px solid black; padding: 5px; text-align: center; margin: 10px auto; width: fit-content;">NOTE</div> <p>Keep a pressure of 0.6MPa or higher for dry compressed air from the compressed air source. Use dry and clean air treated with the air dryer and air filter. In particular, sufficiently drain water in cold regions in order to prevent drainage from freezing.</p>

9. Power connection

Connect a power cable for the blender.






Fig. 4-17

Step	Work item	Work instruction
1	Connection of power cable	<p>Turn “OFF” the primary power of your equipment.</p> <p style="text-align: center;">↓</p> <p>Confirm if the power breaker is “OFF,” and then connect a power cable (5m) to the primary power of your equipment.</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">Power cable ...</div> <div style="border-left: 1px solid black; border-right: 1px solid black; padding: 0 10px;"> R phase: Red S phase: White T phase: Blue (black) E phase: Green for grounding (earth line) </div> <div style="margin-left: 10px;">For primary power</div> </div> <p style="text-align: center;">⚠ CAUTION</p> <ul style="list-style-type: none"> ⊙ Before connecting the power cable, be sure to turn “OFF” the power breaker. ⊙ Securely tighten the cable so that there is no looseness at the connecting part. Any looseness of the connecting part will cause an abnormality in single phase operation. ⊙ Be sure to connect to a ground.

9. Power connection

Step	Work item	Work instruction
2	Confirming positive phase and negative phase	<p>Turn “ON” the primary power from your equipment.</p> <p style="text-align: center;">↓</p> <p>Turn “ON” the power breaker of the blender.</p> <p style="text-align: center;">↓</p> <p>Display a “Manual convey operation window” on the operation panel of the blender shown in Fig. 4-18.</p> <p>* For the operating method of the operation panel, refer to the attached “Mass Blender Operation Panel.”</p> <div style="text-align: center;">  </div> <p style="text-align: center;">Fig. 4-18</p> <p style="text-align: center;">↓</p> <p style="text-align: center;">Continued on next page</p>

9. Power connection



Step	Work item	Work instruction
2	Confirming positive phase and negative phase	<p>Press the Blower 1 touch key on the Manual convey operation window.</p> <p>The blower in the conveying air source unit rotates.</p> <p style="text-align: center;">↓</p> <p>Put your hand on the blower exhaust port of the conveying air source unit shown in Fig. 4-19. If you feel that air is blowing out, the blower is normally rotating (positive phase).</p> <p style="text-align: center;">↓</p> <p>Connection of the power cord is completed. If air is not blowing out from the exhaust port, the blower is rotating in reverse. Then turn “OFF” the primary power to exchange the R phase and T phase among the three power cords.</p> <p style="text-align: center;">↓</p> <p>Turn “ON” the primary power again to check whether air is blowing out from the exhaust port.</p> <div style="text-align: center;">  <p>Blower exhaust port</p> </div> <p style="text-align: center;">Fig. 4-19</p>

Chapter 5 PREPARATIONS FOR OPERATION

This chapter describes necessary preparation work before operating this unit.


1. Confirming pressure of operating compressed air

* For the pressure adjusting method for filter regulator, refer to page 19 in [Chapter 4 Installation](#).

Work item	Work instruction
Confirming pressure of blender air kit	<p>Make sure that the finger valve (air feed port) for the air kit shown in Fig. 5-1 is fully opened and the pressure gauge for the filter regulator is set in a range of 0.4 to 0.5 MPa.</p>  <p>The diagram shows a detailed view of a finger valve and a filter regulator on the left, and a smaller view of the entire blender unit on the right. The finger valve is labeled 'Finger valve' and the filter regulator is labeled 'Filter regulator'.</p> <p>Fig. 5-1</p>
Confirming pressure of mixing part air kit	<p>Make sure that the finger valve (air feed port) for the air kit shown in Fig. 5-2 is fully opened and the pressure gauge for the filter regulator is set in a range of 0.4 to 0.5 MPa.</p>  <p>The diagram shows a detailed view of a finger valve and a filter regulator on the right, and a smaller view of the entire mixing part unit on the left. The finger valve is labeled 'Finger valve' and the filter regulator is labeled 'Filter regulator'.</p> <p>Fig. 5-2</p>



2. Condition check of each unit

2-1. Condition check of blender





Check items	Check contents
No. 1 materials Jet clone No. 2 materials Jet clone No. 3 materials Jet clone	<p>Make sure that there is no foreign matter inside, and the packing and filter are correctly set.</p> <p>After confirming, securely fix the lid with catch clips (3 pieces).</p> <div style="text-align: center;"> <p>Fig. 5-4</p> </div>
No. 1 materials tank No. 2 materials tank	<p>Open the tank lid to make sure that there is no foreign matter inside.</p> <p>After confirming, securely close the tank lid.</p>



2-1. Condition check of blender

Check items	Check contents
No. 3 material hopper	<p>◇ Remove the hopper lid and confirm there is no foreign matter inside it. After confirming, securely attach the hopper lid.</p> <p>◇ Make sure that the discharge damper is fully open and fixed with the wing bolt. (If the No. 3 material is not used, make sure that it is fully closed and fixed.)</p>  <p style="text-align: center;">Fig. 5-5</p>
No. 1 material weighing screw feeder	<p>◇ Make sure that the motor unit at the rear of the screw feeder is securely installed. (Confirm installation with adjustment fastener.)</p> <p>* If the motor unit is not securely installed (setting confirmation proximity switch is OFF), operation cannot be performed, and an alarm of “No. 1 motor setting error” occurs.</p> <p>◇ Make sure that the material removal damper is fully opened and fixed with wing bolts.</p>  <p style="text-align: center;">Fig. 5-6</p>

2-1. Condition check of blender

Check items	Check contents
Weighing hopper	<p>◇ Make sure that the weighing hopper is correctly installed as shown in Fig. 5-7.</p> <p>◇ Make sure that the load cell is unlocked as shown in Fig. 5-7.</p> <p>◇ Make sure that abnormal weight is not applied on the weighing hopper.</p>  <p style="text-align: center;">Fig. 5-7</p>
Suction hopper	<p>◇ Make sure that the suction hopper is installed in the specified position.</p> <p>◇ Make sure that the connection pipe is securely installed and fixed with the wing bolt as shown in Fig. 5-8.</p> <p>◇ Make sure that the secondary air adjusting tube is properly adjusted. (Confirm adjustment of secondary air intake quantity in secondary conveying)</p>  <p style="text-align: center;">Fig. 5-8</p>

2-1. Condition check of blender

Check items	Check contents
Charge hopper (For JB)	<p>◇ Make sure that the secondary conveying pipe of the charge hopper is installed at the specified position as shown in Fig. 5-9.</p> <p>◇ Make sure that the secondary air adjusting tube is properly adjusted. (Confirm adjustment of secondary air intake quantity in secondary conveying)</p>  <p>Fig. 5-9</p>
Suction piping for conveying	<p>Make sure that the butterfly valve for suction cleaning is securely closed as shown in the Fig. 5-10. And also make sure that the handle is fixed with the wing bolt. (Only for optional specifications)</p>  <p>Fig. 5-10</p>

2-2. Condition check of conveying air source unit




Fig. 5-11

Check items	Check contents
Filter case	Make sure that the cartridge filter is correctly set in the filter case. After confirming, securely fix the lid of the filter case with the catch clip.
Dust hopper (VC type only)	Make sure that the dust hopper is installed at the lower part of the filter cyclone.

2-3. Condition check of mixing part




Fig. 5-12

Check items	Check contents
Inside of hopper and drum	<p data-bbox="568 1193 1428 1279">Make sure that there is no foreign matter inside, and the top lid packing and filter are correctly set.</p> <p data-bbox="568 1290 1394 1375">After confirming, securely fix the top lid with the catch clip (3 places) or knob.</p> <div data-bbox="635 1391 1278 1682"> <p>This diagram shows the top lid assembly. It is a circular lid with a handle in the center. The 'Top lid packing' is indicated by an arrow pointing to the inner ring of the lid. The 'Filter' is indicated by an arrow pointing to a small circular component in the center of the lid. The lid is shown being secured with two catch clips on opposite sides.</p> </div> <p data-bbox="951 1771 1062 1803">Fig. 5-13</p>

3. Power supply

Step	Operating procedure/Confirmation
1	Feed primary power (200V AC, 50/60Hz, 3 phase) to the control panel of the blender from your equipment.
2	Turn “ON” the power breaker NFB-1 and the disconnect switch QS-1 of the blender. The main screen is displayed on the operation panel.




Fig. 5-14

Main screen on operation panel



Chapter 6 WEIGHING CHECK

This chapter describes weighing check instructions for material used in this product in order of the procedures. Prepare a container (such as a vinyl bag) for weighing material collection and a balance for mass measurement.

For procedures of the operation panel, refer to the attached "Mass Blender Operation Panel."


NOTE

In this machine, values of overrun, Slow 1 and Slow 2 follow optimum values by automatic correction function by inputting values in advance which assume general materials for parameters (such as overrun, Slow 1, Slow 2, high and low speed) necessary for weighing. Remarkable change in apparent specific gravity and shape of material may affect weighing value. In this case, carry out weighing check if necessary.


1. Preparation for weighing check

As the load cell is required to indicate correct value for weighing check, carry out the following preparation.


The weighing material is collected in the status that the suction hopper is removed, so carry out preparation as shown below.

Step	Work item	Work instruction
1	Checking load cell indicating value	<p>Remove the load cell cover shown in Fig. 6-1, place a weight whose mass value is precise, and check the mass value displayed on the main screen. If the indicated value is different from the real value, it is necessary to re-perform span adjustment of the load cell. (Refer to the Mass Blender Operation Panel on page 33)</p>  <p>The diagram shows a mechanical assembly with a horizontal platform. A weight, represented by a small rectangle, is being lowered towards the platform by a dashed arrow. A solid arrow points from the text 'Weight' to the weight. Below the platform is a vertical support structure with various components like a load cell and a hopper.</p> <p>Fig. 6-1</p>

1. Preparation for weighing check


Step	Work item	Work instruction
1	Removal of connection pipe	<p>Remove the connection pipe of the secondary conveying pipe installed at the suction hopper discharge port.</p> <p>Loosen the wing bolt shown in the Fig. 6-2 and slide to move the connection pipe in the arrow direction to make the status of Fig. 6-3.</p>  <p>Fig. 6-2</p> <p>Fig. 6-3</p>
2	Removal of suction hopper and bracket	After removing the suction hopper remove the bracket.

2. Weighing check of No. 1 material




Step	Work item	Work instruction
1	Preparing material	Feed material to be actually used into the No. 1 material tank. To carry out primary conveying of No. 1 material, select direction from the [Pri. BL] on the main screen, and press the [Start] touch key. Refer to the Mass Blender Operation Panel on page 11.
2	Selecting Job No.	Press the Job No. display part on the main screen to display the "Job No. change window," and select Job No. ◇ Set the No. 1 material overrun on the "Overrun/SV setup screen" to zero. Check the reference value table on the overrun/SV preset screen to set Slow 1 and Slow 2. Refer to the Mass Blender Operation Panel on pages 14 and 18.
3	Displaying manual weighing operation window	Press the "Feed" → "Manual" touch key on the main screen to display the "Manual weighing operation window."
4	Manual weighing of No. 1 material	Press the [Feed 1] touch key on the "Manual weighing operation window." Weighing of No. 1 material is started (No.1 material screw feeder starts). Continued on next page

2. Weighing check of No. 1 material


Step	Work item	Work instruction
4	Manual weighing of No. 1 material	<p>When weighing (1 batch SV) of 1 weighing set value of the presently selected Job No. is completed, the weighing is automatically stopped (No.1 material screw feeder stops). Refer to the Mass Blender Operation Panel on page 11.</p> <p>NOTE</p> <p>When the weighing hopper is not near zero, or the weighing hopper damper opens, weighing cannot be performed.</p>
5	Recording No. 1 material weighing result	Record the weighing result value of the No. 1 material displayed on the weighing result display part on the main screen.
6	Discharging weighing completed material	<p>Press the Scale gate touch key on the “Manual weighing operation window” to open the weighing hopper damper, and discharge weighing material in the weighing hopper.</p> <p></p> <p>After confirming that all of the weighing material is discharged, press the Scale gate touch key again to close the weighing hopper damper.</p>
7	Collecting weighing material	Collect the weighing material into a vinyl bag at the charge hopper part at the lower part of the weighing hopper.
8	Measuring weighing material	<p>Measure mass of the collected weighing material with a balance if necessary, and check if it matches the weighing value (result value) recorded in procedure 5.</p> <p>* When the indicated value of the load cell matches the mass of the weight, the weighing value is judged to be correct. If you want to know the numerical value of 1g or less by weighing a small amount, check the value using a balance whose minimum scale is 1g or less.</p>

2. Weighing check of No. 1 material

Step	Work item	Work instruction
9	Variation check of weighing value	<p>Perform work in procedures 4, 5 and 6 five to ten times to check that there is no variation in weighing value (result value).</p> <ul style="list-style-type: none"> ◇ If feed time is short, and there are some variations, Increase the Slow 1 and SV2 set values of the No. 1 material on the “Overrun/SV setup screen.” (When manually setting) ◇ If there is no variation, but feed time is long (insufficient capacity), Decrease the Slow 1 and Slow 2 set values. (When manually setting) <p>Perform the above adjustment to eliminate variation (within weighing accuracy).</p>
10	Calculation of overrun value	<p>After eliminating variation in procedure 9, perform re-weighing checks about five to ten times (procedures 4, 5, 6, 7 and 8) to obtain the average weighing value.</p> <p style="text-align: center;"></p> <p>Calculate overrun value from the average weighing value.</p> <p style="text-align: center;">Average weighing value — SV set value = Overrun value</p> <p>When weighing by setting the overrun value to zero, weighing result for which overrun is added to the SV set value is always obtained.</p>
11	Weighing value check by setting overrun value	<p>Set the overrun value obtained in procedure 10 to an overrun of the No.1 material on the “Overrun/SV setup screen,” perform procedures 4, 5, 6, 7 and 8 and check that the SV set value matches the weighing value (result value).</p> <p>The above completes weighing check of No. 1 material.</p>


3. Weighing check of No. 2 material

Also perform weighing check of No. 3, 4 material by the same procedure.




Step	Work item	Work instruction
1	Preparing material	Feed material to be actually used into the No. 2 material tank. To carry out primary conveying of No. 2 material, select direction from Pri. BL on the main screen, and press the Start touch key. Refer to the Mass Blender Operation Panel on page 11.
2	Selecting Job No.	Press the Job No. display part on the main screen to display the "Job No. change window," and select Job No. <div style="text-align: center;">↓</div> <ul style="list-style-type: none"> ◇ Set the No. 2 material overrun on the "Overrun/SV setup screen" to zero. ◇ Set the over amount on the "Over/Short setup screen" to a value which does not issue any alarm (SV set value or more). Refer to the Mass Blender Operation Panel on pages 14, 18, 19.
3	Displaying manual weighing operation window	Press the "Manual" touch key on the main screen to display the "Manual weighing operation window." Refer to the Mass Blender Operation Panel on page 11.
4	Manual weighing of No. 2 material	Press the Feed 2 touch key on the "Manual weighing operation window." Weighing of No. 2 material is started (No.4 material weighing auto shutter opens). <div style="text-align: center;">↓</div> Continued on next page

3. Weighing check of No. 2 material

Step	Work item	Work instruction
4	Manual weighing of No. 2 material	<p>When weighing (1 batch SV value) 2 weighing set value of the presently selected Job No. is completed, the weighing is automatically stopped (No. 2 material weighing auto shutter closes).</p> <p>Refer to the Mass Blender Operation Panel on page 11.</p> <div style="border: 1px solid black; padding: 5px; text-align: center; margin: 10px 0;">NOTE</div> <p>When the weighing hopper is not near zero, or the weighing hopper damper opens, weighing cannot be performed.</p>
5	Recording No. 4 material weighing result	Record the weighing result value of the No. 4 material displayed on the weighing result display part on the main screen.
6	Discharging weighing completed material	<p>Press the Scale gate touch key on the “Manual weighing operation window” to open the weighing hopper damper, and discharge weighing material in the weighing hopper.</p> <div style="text-align: center; margin: 10px 0;">  </div> <p>After confirming that all of the weighing material is discharged, press the Scale gate touch key again to close the weighing hopper damper.</p> <p>Refer to the Mass Blender Operation Panel on page 11.</p>
7	Collecting weighing material	Collect the weighing material into a vinyl bag at the charge hopper part at the lower part of the weighing hopper.
8	Measuring weighing material	<p>Measure mass of the collected weighing material with a balance if necessary, and check if it matches the weighing value (result value) recorded in procedure 5.</p> <p>* When the indicated value of the load cell matches the mass of the weight, the weighing value is judged to be correct. If you want to know the numerical value of 1g or less by weighing a small amount, check the value using a balance whose minimum scale is 1g or less.</p>

3. Weighing check of No. 2 material

Step	Work item	Work instruction
9	Variation check of weighing value	<p>Perform work in procedures 4, 5, 6, 7 and 8 five to ten times to check that there is no variation in weighing value (result value).</p> <ul style="list-style-type: none"> ◇ If there are some variations, Increase the Slow 1 and SV2 set values of the No. 2 material on the “Overrun/SV setup screen.” (When manually setting) ◇ If there is no variation, but feed time is long (insufficient capacity), Decrease the Slow 1 and Slow 2 set values. (When manually setting) <p>Perform the above adjustment to eliminate variation (within weighing accuracy).</p>
10	Calculation of overrun value	<p>After eliminating variation in procedure 9, perform re-weighing checks about five to ten times (procedures 4, 5, 6, 7 and 8) to obtain the average weighing value.</p> <p style="text-align: center;"></p> <p>Calculate overrun value from the average weighing value.</p> <p style="text-align: center;">Average weighing value — SV set value = Overrun value</p> <p>When weighing by setting the overrun value to zero, weighing result for which overrun is added to the SV set value is always obtained.</p>
11	Weighing value check by setting overrun value	<p>Set the overrun value obtained in procedure 10 to an overrun of the No. 2 material on the “Overrun/SV setup screen,” perform procedures 4, 5, 6, 7 and 8 and check that the SV set value matches the weighing value (result value).</p> <p>The above completes weighing check of No. 2 material.</p>

Chapter 7 VARIOUS SETTINGS

This chapter describes data setting of various setup screens on the operation panel necessary for operation of this product. Be sure to set up before operation.

For setting content of various setup screens and their operations, refer to the attached “Mass Blender Operation Panel.”

1. Parameter setup screen

⇒ Refer to page 15 in the Mass Blender Operation Panel.

Set the following various weighing data, use selection of weighing correction function and use selection of granulation recycle function.



2. Over/Short setup screen

⇒ Refer to page 19 in the Mass Blender Operation Panel.


Set over amount and short amount allowable to SV set values of weighing for each material. If the weighing result value becomes larger than the over amount set value, “Over error” alarm occurs, and if the weighing result value becomes smaller than the short set value, “Short error” alarm occurs.



3. Feed time setup screen

⇒ Refer to page 19 in the Mass Blender Operation Panel.

- ◇ Set a time to monitor one batch weighing operation for each material. Unless one batch weighing operation is completed within the feed time, “Feed time alarm” occurs.
- ◇ Set use selection of weighing pass function for each material.



4. Primary convey setup screen

⇒ Refer to page 20 in the Mass Blender Operation Panel.


Set one batch convey time and discharge time of primary conveying.



5. Mixer gate, secondary convey setup screen

⇒ Refer to page 21 in the Mass Blender Operation Panel.

Set scale gate, purge, mixing time, gate delay, mixer gate, recycle convey time and side convey time, demand delay.



6. Overrun/SV setup screen

⇒ Refer to page 18 in the Mass Blender Operation Panel.

- ◇ Set overrun value for each material. The overrun value fluctuates with the apparent specific gravity of material.
- ◇ In order to improve weighing accuracy, set the mass value to switch feed capacity of the weighing machine from large weighing to medium weighing (Slow 2), and medium feed to small weighing (Slow 1).




- * When changing the set value on the screen, be sure to perform a weighing check.

7. Measure setting screen

⇒ Refer to page 37 in the Mass Blender Operation Panel.

Set feed capacity (rotation speed) in unit of % at large weighing, medium weighing and low speed weighing for every weighing machine.


- * High speed, medium speed and low speed function for weighing screw feeder.
- * When changing the set value on the screen, be sure to perform a weighing check.



8. Weigh sequence setup screen

⇒ Refer to page 37 in the Mass Blender Operation Panel.

- ◇ Set sequence to weigh in one batch weighing operation. Weighing correction calculates target values of the other materials based on the value of weighing result of the first set material.
- ◇ Set Max batch amount (allowable maximum batch amount). If the result value of the one batch amount exceeds the set value of the Max batch amount, “Weighing correction alarm” occurs.



9. Material lower limit monitor setup screen

⇒ Refer to page 37 in the Mass Blender Operation Panel.

Set monitor time (seconds) of material lower limit status for each material tank of the blender and weigh mixed material (secondary receiver equipment). Unless the tank is filled with material within this set time, “Material decrease alarm” occurs.

For number of times of “Scale Gate” and “Mixer Gate,” set number of times to open and close the damper from a time when each has completed discharge.



10. Job name setup screen

⇒ Refer to page 17 in the Mass Blender Operation Panel.

Set name of various Job No. selected and set on the main screen in automatic operation and name of each job material.

When **LIST** touch key is pressed, a list of job names is displayed.




11. Time setting screen

⇒ Refer to page 40 in the Mass Blender Operation Panel.

This screen changes and adjusts the date and time displayed on the operation panel.

Adjust the date and time if they are different from the present ones.



Chapter 8 AUTOMATIC OPERATION


This chapter describes start operation and stop operation of automatic operation of this product.

For various screen operations on the operation panel, refer to the attached “Mass Blender Operation Panel.”


NOTE

Before starting operation, perform work described in Chapter 5. Preparation for Operation and Chapter 7. Various Settings.



1. Start operation for automatic operation

Step	Work item	Work instruction
1	Starting primary conveying	<p>Display the “Main screen” on the operation panel, start primary conveying of material to be used, and convey material to each material tank of the blender.</p>  <p>Press the direction select touch key on part A to make it blue, then the primary conveying in that direction is selected. Press the Start touch key to display the “Pri. BL” in green, then primary conveying is started.</p> <p style="text-align: center;">↓</p> <p>When the Jet clone on the upper part of the material tank detects full, the primary conveying of the material moves into standby status.</p> <div style="text-align: center;"> <h2>NOTE</h2> </div> <p>Before starting automatic weighing, be sure to start primary conveying of the material to be used, and feed material to each material tank of the blender.</p>


1. Start operation for automatic operation

Step	Work item	Work instruction
2	Selecting Job No.	<p>Display Job No. to be operated on the <u>Job No. display part</u> on the “Main screen.”</p> <p>Job No. display part</p> <p>Job No. change window</p>  <p>Step 1: Press the <u>Job No. display part</u> on the “Main screen” to display the “Job No. change window.”</p> <p>Step 2: Press the <u>0</u> – <u>9</u> touch keys on the “Job No. change window” to input Job No.</p> <p>Step 3: Press the <u>Enter</u> touch key on the “Job No. change window” to write the input numerical value.</p> <p>Step 4: Press the <u>X</u> touch key on the “Job No. change window” to close the window.</p> <p>Changing Job No.</p> <p>If Job No. is changed during automatic operation, the presently operating Job No. and changed Job No. are alternately invert-displayed. When the present operating cycle is ended, operation starts with the changed Job No. from the next time.</p>

1. Start operation for automatic operation

Step	Work item	Work instruction
3	Setting usage stop function	<p>◇ If you want to automatically stop the automatic weighing operation at a specific feed amount (total usage value), display a “Usage DATA screen” on the operation panel to set the total usage value.</p> <p>◇ When not using the usage stop function, set the total usage value on the “Usage DATA screen” to zero.</p> <p>Display part of total usage set value</p>  <p style="text-align: center;">↓</p>  <p>Step 1: Press the Stop Amount touch key on the “Usage DATA screen” to display the “Usage Amt. setting window.”</p> <p>Step 2: Press the 0–9, . touch keys on the “Usage Amt. setting window” to input integrated value.</p> <p>Step 3: Press the Enter touch key on the “Usage Amt. setting window” to write input numerical value.</p> <p>Step 4: Press the ✕ touch key on the “Usage Amt. setting window” to close the window.</p>

1. Start operation for automatic operation

Step	Work item	Work instruction
4	Starting automatic weighing	<p>Display a “Start Auto Mode window” on the “Main screen” to start automatic weighing.</p> <p>Start Auto Mode window</p>  <p>Step 1: Press a Feed touch key on the “Main screen” to display a “Select Mode window.” When the Auto touch key is pressed, the “Start Auto Mode window” is displayed.</p> <p>* <u>If the “Usage stop window” is displayed, refer to the next page.</u></p> <p>Step 2: Press the YES touch key on the “Start Auto Mode window.” The “Start Auto Mode window” closes and automatic weighing is started.</p> <p>[Operation]</p> <p>Material suitable for weighing data of the Job No. is weighed depending on weighing hopper empty status on the blender.</p> <p>↓</p> <p>Weigh mixed material is charged into the mixing part according to the demand signal from the receiver level gauge after weighing is completed.</p> <p>Operating status is displayed on a “Graphic display part” on the “Main screen.”</p> <p>For content to be displayed, refer to “Chapter 1 Main Screen” in the “Mass Blender Operation Panel.”</p>


1. Start operation for automatic operation

Step	Work item	Work instruction
5	When the “Usage stop window” is displayed	<p>If the “Usage stop window” is displayed when the Auto touch key on the “Main screen” is pressed in the operation of procedure 4 on the previous page, start automatic weighing after changing or clearing the integrated value on the “Usage DATA screen.”</p> <div data-bbox="815 627 1396 990" data-label="Image"> </div> <p>Step 1: Press a Change touch key on the “Usage stop window.” The screen changes to the “Usage DATA screen.”</p> <p>Step 2: Change or clear the integrated value on the “Usage DATA screen.” (Return to procedure 3.)</p> <p>Step 3: Perform start operation of the automatic weighing in procedure 4.</p> <p>For the “Usage stop window,” refer to the attached “Mass Blender Operation Panel.”</p>

2. Stop operation for automatic operation

Step	Work item	Work instruction
1	Immediate stop of automatic weighing	<p>Display a “Stop Auto Mode window” on the “Main screen” to immediately stop automatic operation.</p> <p>Step 1: Press the Auto touch key on the “Main screen” to display the “Stop Auto Mode window.”</p> <p>Step 2: Press an Emergency touch key on the “Stop Auto Mode window.” The “Stop Auto Mode window” closes and automatic operation is immediately stopped.</p> <p>↓</p> <ul style="list-style-type: none"> ◇ When restarting the operation continuously, perform operations in “Procedure 4 – Starting automatic weighing” of the “1. Start operation of automatic operation” in this chapter. ◇ If not continuing the operation, press the Scale Gate touch key on the “Manual weighing operation window” and open the weighing hopper damper, then the operation data is reset. <u>If this operation is performed, be sure to completely remove material in each device (inside of weighing hopper, secondary conveying piping, mixing part) by manual operation.</u>

2. Stop operation for automatic operation

Step	Work item	Work instruction
2	<p>Cycle stop of automatic weighing</p> <p>* When not using the "Usage stop function," stop operation for automatic operation.</p>	<p>Display the "Stop Auto Mode window" on the "Main screen" to stop cycle of automatic operation.</p>  <p>Step 1: Press the Auto touch key on the "Main screen" to display the "Stop Auto Mode window."</p> <p>Step 2: Press the Cycle touch key on the "Stop Auto Mode window." The "Stop Auto Mode window" closes and the cycle of the automatic operation is stopped.</p> <p><JB specification> The cycle automatically stops at a time when the mixing drum at the lower part of the weighing hopper completes mixer gate operation.</p> <p><APH, SB specification> The cycle automatically stops at a time when the secondary receiver collector (aero hopper or mixing drum) completes mixer gate operation.</p> <p>At this time, the weighing hopper of the blender stops in empty status.</p> <p>The Auto touch key on the screen flashes during cycle stop operation.</p>

Chapter 9 MANUAL OPERATION

This chapter describes manual operation of the blender and conveying related devices in this product in order of the procedures.

For various screen operations on the operation panel, refer to the attached “Mass Blender Operation Panel.”


NOTE

Before starting operation, perform work described in [Chapter 5.](#)

[Preparation for Operation](#) and [Chapter 7. Various Settings.](#)

1. Manual operation for blender

Press the **Feed** touch key on the “Main screen,” then a “Select Mode” window is displayed. Further press the **Manual** touch key, a “Purge port window” is displayed, and press the **Feed** touch key at the lower part of the window, then a “Weigh window” is displayed. Perform manual operation by each device name touch key.



1 Manual feed touch key for each material

When this is pressed, material of the No. is started to be weighed (the screw feeder starts or the auto shutter opens).

When the weighing of the weigh set value of the presently selected Job No. is completed (one batch SV value), it automatically stops (the screw feeder stops or the auto shutter closes).

* When the weighing hopper is not near zero (empty status), or the weighing hopper damper opens, weighing cannot be performed.

2 Manual operation touch key for scale gate, mixing and mixer gate

When this is pressed, the weighing hopper damper opens.

If this is re-pressed again, the weighing hopper damper closes. Also perform operation of mixing drum start and mixer gate in the same way.


3 Residual material removal operation by touch key

When each Purge touch key is pressed, residual material in that material tank is started to be purged (the screw feeder starts or the auto shutter opens).

When the touch key is re-pressed, the purge stops (the screw feeder stops or the auto shutter closes).

2. Manual operation for conveying related devices

When the **Blower** touch key on the “Manual weighing operation window” is pressed, a “Manual convey operation window” is displayed. Perform manual operation by each device name touch key on the “Manual convey operation window.”



1 Manual operation touch key for primary conveying direction valve for each material

When any one of these keys are pressed, the primary conveying direction valve for the material No. opens. When the touch key is re-pressed, the valve closes.

2 Manual operation touch key for side valve, recycle valve

When these keys are pressed, the auto shutter for recycle conveying switches branching direction. When it is re-pressed, the auto shutter returns in the straight advancing direction.
(for APH, SB specification)

3 Manual operation touch key for conveying blower

When this is pressed, the conveying blower starts. When it is re-pressed, the blower stops.
(for SB specification)



For APH, SB specification, unless the discharge damper for the mixing part is opened and material in the mixing part is discharged, the blower cannot be restarted after secondary convey operation.

There is no interlock function in manual operations other than the above.

Note that abnormality and failure are caused if the blower is started with the conveying direction valves closed.

Chapter 10

MATERIAL REMOVAL AND CLEANING FOR BLENDER

This chapter describes how to remove residual material in each material tank and hopper, and how to clean by removing each device in order of the procedures.





Fig. 10-1

1. Material removal from inside of each material tank and hopper

Step	Work item	Work instruction
1	Removing the suction hopper (for APH, SB)	<p>Loosen the wing bolt shown in the Fig 10-2 and slide to move the connection pipe in the arrow direction to make the status of Fig. 10-3, and then remove the suction hopper.</p> <div style="text-align: center;"> <p>Fig. 10-2</p> <p>Fig. 10-3</p> </div>


1. Material removal from inside of each material tank and hopper

Step	Work item	Work instruction
2	Setting a residual material collecting container	<p>Set a container to collect residual material at the lower part of each discharge port shown in Fig. 10-4.</p>  <p>Fig. 10-4</p>

1. Material removal from inside of each material tank and hopper

Step	Work item	Work instruction
3	Removing residual material from the screw feeder	<p>There is a material removal damper at the lower part of the screw feeder. Set a container under this, and open the damper to remove material.</p> <p>When the Purge touch key on the “Purge port operation window” is pressed, the screw feeder starts and material remaining in the trough is purged to the weighing hopper. When the touch key is pressed again, the purge stops.</p>
4	Removing residual material from the auto shutter	<p>When the Purge touch key on the “Purge port operation window” is pressed, the auto shutter opens, and material in the tank is purged. When the touch key is pressed again, the purge stops.</p>
5	Purge from mixing drum	<p>Shut off the primary supply air and set the air pressure to zero. Directly open the damper by hand.</p>
6	Assembly after operation is ended	<p>Press the Purge touch key for each material to stop each feed device, press the Scale Gate touch key to close the purge damper, then assemble the receiving chute to its original status.</p>

2. Cleaning the weighing hopper



Step	Work item	Work instruction
1	Removing the weighing hopper	<p>Remove the front lifting hook shown in Fig. 10-5, use the rear lifting hook as a load cell.</p>  <p>Fig. 10-5</p>
2	Cleaning in the weighing hopper	<p>Remove fine particles of material adhered to the inside of the weighing hopper and damper.</p> <div style="border: 1px solid black; padding: 5px; text-align: center; margin: 10px 0;">NOTE</div> <p>Since cleaning by blowing air is not preferable for the working environment and hygiene because fine particles fly, it is recommended to use a suction cleaner.</p>
3	Assembling the weighing hopper	Assemble the weighing hopper in a status shown in Fig. 10-5.

CAUTION

When disassembling and assembling the weighing hopper, carefully perform operation so as not to give shock to the lifting hook of the load cell shown in Fig. 10-6.

Shock may cause failure or damage to the devices.



3. Cleaning the receiving chute and charge hopper

Step	Work item	Work instruction
1	Preparation before removal	<p>Securely close the slide damper and fix with the wing bolt, and remove the hopper lid (with Jet clone) shown in Fig. 10-6.</p>  <p>Fig. 10-6</p>
2	Removing the No. 3 material hopper	<p>Lift to remove the No. 3 material hopper as shown in Fig. 10-7.</p>  <p>Fig. 10-7</p>
3	Cleaning inside the No. 3 material hopper	<p>Remove fine particles of material adhered to the inside of the hopper.</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> <p>NOTE</p> </div> <p>Since cleaning by blowing air is not preferable for the working environment and hygiene because fine particles fly, it is recommended to use a suction cleaner.</p>
4	Assembling the No. 3 material hopper	<p>Assemble the No. 3 material hopper in the status shown in Fig. 10-7, and assemble the hopper lid (with Jet clone).</p>

4. Cleaning charge hopper (for JB)




Step	Work item	Work instruction
1	Removing the charge hopper	<p>Remove the hopper lid shown in Fig. 10-8.</p> <div data-bbox="783 598 1324 880" data-label="Image"> <p>The diagram illustrates the process of removing the hopper lid. On the right, a hopper unit is shown with its lid open. An arrow points from the lid to the hopper. To the left of the hopper, the lid is shown as a separate rectangular component, indicating it has been removed.</p> </div> <p>Fig. 10-8</p>
2	Cleaning inside the charge hopper	<p>Remove fine particles of material adhered to the inside of the hopper.</p> <div data-bbox="999 1279 1125 1330" data-label="Text"> <p>NOTE</p> </div> <p>Since cleaning by blowing air is not preferable for the working environment and hygiene because fine particles fly, it is recommended to use a suction cleaner.</p>


5. Cleaning the weighing screw

Step	Work item	Work instruction
1	Preparation before removal	<p>Turn “OFF” the disconnect switch and primary power source.</p> <p style="text-align: center;">↓</p> <p>Disconnect the power connector of the motor shown in the Fig. 10-9.</p>  <p style="text-align: center;">Fig. 10-9</p>
2	Removing the motor unit	<p>Remove the adjustment fastener shown in Fig. 10-10 to open the motor unit. The screw can be removed.</p>  <p style="text-align: center;">Fig. 10-10</p>
3	Cleaning the screw	<p>Remove fine particles of material adhered to the screw.</p> <div style="border: 1px solid black; padding: 5px; text-align: center; margin: 10px 0;">NOTE</div> <p>Since cleaning by blowing air is not preferable for the working environment and hygiene because fine particles fly, it is recommended to use a suction cleaner.</p>
4	Assembling the motor unit	<p>Assemble the motor unit in a status shown in Fig. 10-10, and fix it with an adjustment fastener.</p> <p style="text-align: center;">↓</p> <p>Connect the power connector of the motor in the status shown in Fig. 10-10.</p>

6. Suction cleaning by a blower

* This is optional specifications equipment. This is Only Used in the case (for VC type) in which a filter cyclone is attached to the conveying air source unit.

Step	Work item	Work instruction
1	Assembling a hose for suction cleaning	<p>Attach the hose for suction cleaning to the suction port shown in Fig. 10-11, and open the butterfly valve for suction cleaning.</p>  <p>Fig. 10-11</p>
2	Cleaning by start-up of blower	<p>Press the Feed touch key on the “Main screen” of the operation panel to display the “Select Mode window.”</p> <p style="text-align: center;">↓</p> <p>Press the Manual touch of the “Select Mode window” to display the “Purge port window.”</p> <p style="text-align: center;">↓</p> <p>Press the Blower touch key of the “Purge port window” to display the “Manual convey operation window.”</p> <p style="text-align: center;">↓</p> <p>Press the Blower 1 to start-up the blower and carry out suction cleaning with the hose.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Purge port window</p>  </div> <div style="text-align: center;"> <p>Manual convey operation window</p>  </div> </div>

Step	Work item	Work instruction
3	Treatment after suction cleaning completion	<p>After the blower stops, securely close the butterfly valve for suction cleaning, and fix the handle.</p> <p style="text-align: center;">↓</p> <p>Remove the dust hopper of the conveying air source unit shown in Fig. 10-12, and remove the substances accumulating inside.</p> <p>After the work end, securely attach the dust hopper</p> <div style="text-align: center;">  <p>Dust hopper</p> </div> <p style="text-align: center;">Fig. 10-12</p>

CAUTION

Do not suck up other items than material and fine particles. If large quantities of material or substances containing water or moisture are sucked, it may break or damage the equipment.

Chapter 11 MAINTENANCE AND CHECK

We recommend that you thoroughly read this chapter before performing routine checks in order to maintain long-time product performance and safe use, and further to prevent accidents. The following diagrams show primary portions which require maintenance and check.

Blender – Explanatory diagram for maintenance and primary check portions




Fig. 11-1

Conveying air source unit Explanatory diagram for maintenance and primary check portions




Fig. 11-2

Mixing part Explanatory diagram for maintenance and primary check portions










Fig. 11-3



1. Daily maintenance and check

Inspection items	Work instruction
◇ Screw feeder in blender ◇ Blower for conveying air source unit ◇ Mixing part in blender	Check whether noise (particularly metallic noise) occurs when operating. * If noise is identified, stop operation immediately and find the cause of the noise. <div style="text-align: center;">  CAUTION </div> Do not operate Jet Color when noise is identified.
	Check whether abnormal vibration occurs when operating. * If abnormal vibration is identified, stop operation immediately and find the cause of the vibration. <div style="text-align: center;">  CAUTION </div> Do not operate Jet Color when vibration is identified.
	Check whether unit body and motor have abnormally high temperatures. * If they have abnormally high temperatures, stop operation immediately and find the cause of the high heat. <div style="text-align: center;">  CAUTION </div> Do not operate Jet Color when they have high heat.
	Measure the load current value under operation, and make sure that it is in the rated value range. The rated value is noted on the nameplate of the motor.



1. Daily maintenance and check

Inspection items	Work instruction
<p data-bbox="153 383 517 461">Cartridge filter in filter case for conveying air source unit</p>  <p data-bbox="300 1196 383 1229"><u>V type</u></p> <p data-bbox="284 1258 399 1292">Fig. 11-4</p>	<ol style="list-style-type: none"> <li data-bbox="539 383 1441 461">1. Remove the catch clip at the upper part of the filter case to remove the filter case lid. [① → ②] <li data-bbox="539 479 1441 557">2. Remove the filter clip, and remove the cartridge filter from the filter case lid to clean. [③ → ④ → ⑤] <li data-bbox="539 575 1441 609">3. Remove powdered dust adhered to the filter by a vacuum cleaner. <li data-bbox="539 618 1441 651">4. Securely return them to their original status.  <p data-bbox="927 1415 1042 1449">Fig. 11-5</p> <div data-bbox="858 1491 1118 1563">  CAUTION </div> <ol style="list-style-type: none"> <li data-bbox="539 1615 1441 1693">1. Install the cartridge filter so that the opening side with a packing is on the filter lid case side. <li data-bbox="539 1697 1441 1809">2. If the device is used in a status that the packing of the cartridge filter does not securely contact the filter case lid, powdered dust intrudes into the blower, which may cause a malfunction. <li data-bbox="539 1814 1441 2000">3. Replace a broken cartridge filter, severely deteriorated and deformed filter from which adherents cannot be removed with a new cartridge filter. Powdered dust may intrude into the blower, and material may not be conveyed due to clogging of the filter, which may cause a malfunction of the blower.



1. Daily maintenance and check

Inspection items	Work instruction
<p>Dust discharge for conveying air source unit</p>  <p><u>VC type</u></p> <p>Fig. 11-6</p>	<p>V type</p> <p>Remove the cap at the lower part of the filter case to discharge accumulated dust. Return to its original state after discharge without fail.</p> <p>VC type</p> <p>Remove the catch clip at the upper part of the dust box to discharge accumulated dust. Return to the original state after discharge without fail.</p> <p>* If the U type packing for the dust box is severely deteriorated, deformed, discolored or hardened, replace it with a new one.</p>
<p>◇ Air kit for blender</p> <p>◇ Air kit for mixing part</p>	<p>Pull up the adjusting knob for the regulator filter shown in Fig. 11-7 to remove the lock, turn the adjusting knob to the left and confirm that the indicated value on the pressure gauge reaches “0 (zero),” then discharge drainage accumulated in the bowl. It can be discharged by opening the drain valve at the lower part of the bowl. Receive drainage by a empty can or the like.</p>  <p>Fig. 11-7</p>

2. Weekly maintenance and check

Inspection items	Work instruction
Secondary air adjusting tube of suction hopper of blender (For APH, SB)	<p data-bbox="536 389 1326 517"> Check that the air suction port (metal mesh part) for the secondary air adjusting tube shown in Fig. 11-8 is not clogged. If it is clogged, remove adherents with a vacuum cleaner or the like. </p> <div data-bbox="687 562 1422 741">  <p data-bbox="1214 562 1422 674">Suction port (metal mesh part) for secondary air adjusting tube</p> </div> <p data-bbox="927 824 1038 857">Fig. 11-8</p> <p data-bbox="536 925 1385 1048"> When severely contaminated, remove the suction port for cleaning. Loosen the wing bolt shown in Fig. 11-9, and move the suction port in the arrow direction by sliding to remove. </p> <div data-bbox="687 1048 1414 1249">  <p data-bbox="1230 1093 1337 1126">Wing bolt</p> <p data-bbox="1230 1216 1414 1249">Connection pipe</p> </div> <p data-bbox="927 1317 1038 1350">Fig. 11-9</p> <div data-bbox="922 1395 1050 1447" style="border: 1px solid black; padding: 2px; text-align: center;"> NOTE </div> <p data-bbox="536 1462 1246 1496"> Completely dry the cleaned suction port and assemble it. </p>

2. Weekly maintenance and check

Inspection items	Work instruction
Secondary air adjusting tube of charge hopper of blender (For JB)	<p data-bbox="537 383 1326 510"> Check that the air suction port (metal mesh part) for the secondary air adjusting tube shown in Fig. 11-10 is not clogged. If it is clogged, remove adherents with a vacuum cleaner or the like. </p> <div data-bbox="831 562 1422 719">  <p data-bbox="1214 562 1422 674">Suction port (metal mesh part) for secondary air adjusting tube</p> </div> <p data-bbox="922 779 1050 808">Fig. 11-10</p> <p data-bbox="537 875 1401 1003"> When severely contaminated, remove the suction port for cleaning. Loosen the wing bolt shown in Fig. 11-11, and move the suction port in the arrow direction by sliding to remove. </p> <div data-bbox="863 1055 1366 1245">  <p data-bbox="1230 1093 1337 1122">Wing bolt</p> <p data-bbox="1222 1171 1366 1200">Suction port</p> </div> <p data-bbox="922 1317 1050 1346">Fig. 11-11</p> <div data-bbox="922 1391 1050 1447"> <p>NOTE</p> </div> <p data-bbox="537 1464 1246 1494">Completely dry the cleaned suction port and assemble it.</p>


3. Monthly maintenance and check

Inspection items	Work instruction
Jet clone, filter for blender	<p>Open the lid on the collector to take out the filter, and check that it is not clogged.</p> <p>When the filter is clogged, remove the adherents by spraying clean dry air.</p> <div data-bbox="715 607 1182 947" data-label="Image"> <p>The diagram illustrates the components of the filter assembly. It shows a top view of the lid being lifted off a base. A packing ring is located between the lid and the base. A filter is positioned in the center of the base. Two catch clips are used to hold the filter in place. Arrows point from the labels to their respective parts: Lid, Packing, Filter, and Catch clip.</p> </div> <ul style="list-style-type: none"> * When the adherents cannot be removed by the above work, use a pointed end wire to clean. * When deterioration of the packing is extreme, or it deforms, discolors, or hardens, replace it with a new packing <div data-bbox="890 1245 1083 1296" data-label="Image"> <p>A rectangular box containing a triangle with an exclamation mark and the word CAUTION in bold capital letters.</p> </div> <p>Be very careful not to deform the filter. It may cause a failure due to leakage of air. In case of deformation, stretch it out by tapping with a soft substance, such as a wooden hammer or a rubber hammer. If it cannot be fixed, then replace with a new filter.</p>
Conveying hose (PVC hose) Suction hose (GL-IV hose)	<p>Check that leakage of suction does not occur at each connecting part of the hose, and additionally tighten the hose band.</p> <ul style="list-style-type: none"> * If deterioration of the hose is extreme, the hose hardens, or the hose is worn and torn, replace it with a new one.


3. Monthly maintenance and check

Inspection items	Work instruction
Check of each part of Jet clone	<p>A: Check that the stoppers (M6) at the upper and lower two locations are not loosened.</p> <p>* If they are loosened, retighten them with reference to the “Stopper adjusting diagram” on the next page.</p> <p>B: Remove the cover to check that the hexagon socket head set screws for the cam are not loosened. At the same time, open/close the damper to check that there is no abnormality with the limit switch.</p> <p>* If they are loosened, retighten them with reference to the “Stopper adjusting diagram” on the next page.</p> <p>C: Check that the hexagon socket head set screws fixing the balance weight are not loosened.</p> <p>* If they are loosened, retighten them and fix the balance weight .</p> <p>D: Check that there is no abnormality with the spring, bolt, nut and split pin.</p> <p>* If any abnormality is identified, replace with new ones.</p> <div data-bbox="544 1205 1390 1727"> </div>

3. Monthly maintenance and check

Inspection items	Work instruction
Check of each part of Jet clone	<p data-bbox="596 416 938 448">Upper stopper adjusting position</p> <p data-bbox="539 584 794 616">Limit switch ON position</p> <p data-bbox="683 656 778 705">Approx. 85°</p> <p data-bbox="730 712 826 761">Approx. 70°</p> <p data-bbox="1305 862 1353 893">6mm</p> <p data-bbox="1091 1014 1439 1064">Lower stopper adjusting position (clearance 6mm)</p> <p data-bbox="823 1196 1152 1227">Stopper adjusting diagram</p> 

3. Monthly maintenance and check

Inspection items	Work instruction
Aero power hopper	<p data-bbox="539 383 1436 465">Open the lid of the aero power hopper to take out the filter as shown in Fig. 11-12, and check that it is not clogged.</p> <p data-bbox="539 479 1206 510">If it is clogged, blow clean dry air to remove the adherents.</p> <div data-bbox="807 595 1385 909">  <p data-bbox="922 880 1050 909">Fig. 11-12</p> </div> <ul style="list-style-type: none"> <li data-bbox="539 943 1390 1025">* If adherents are not removed even by blowing dry air, use a pointed end wire to clean. <li data-bbox="539 1039 1422 1122">* If the packing for the top lid is severely deteriorated, deformed, discolored or hardened, replace it with a new one. <div data-bbox="890 1164 1082 1216"> <p>CAUTION</p> </div> <p data-bbox="539 1236 1436 1458">Carefully handle the filter so as not to deform it. Otherwise, defective conveying may be caused due to leakage of air. If it has been deformed, tap it with soft object such as a wooden hammer or rubber hammer to stretch it. If it cannot be fixed, replace it with a new one.</p> <div data-bbox="922 1458 1050 1509"> <p>NOTE</p> </div> <ul style="list-style-type: none"> <li data-bbox="539 1529 1385 1610">◎ Wear a mask when cleaning and spraying the dry air so as not to breath in the adherents in the air. <li data-bbox="539 1624 1358 1706">◎ Note that clogging of the filter causes overload operation of the blower and a decrease in conveying capacity.

3. Monthly maintenance and check

Inspection items	Work instruction
Screw feeder in blender	<p>Check that the set check proximity sensor for the motor unit shown in Fig. 11-13 correctly functions according to the following procedure.</p> <p>Step 1: Turn “OFF” the disconnect switch for the blender and the primary power source to remove.</p> <p>Step 2: Remove the adjustment fastener to open the motor unit.</p> <p>Step 3: Turn “ON” the primary power and disconnect switch and display an “Alarm screen” on the operation panel. If “No.* motor set error” occurs, the proximity sensor correctly functions.</p> <p>Step 4: Install the motor unit correctly after turning “OFF” the disconnect switch and primary power.</p> <div data-bbox="544 898 1362 1285"> <p>Proximity sensor</p> <p>Adjustment fastener</p> <p>Motor unit</p> <p>Proximity sensor (in motor unit)</p> <p>Adjustment fastener</p> <p>Motor unit</p> </div> <p>Fig. 11-13</p> <div data-bbox="890 1368 1082 1424"> <p>CAUTION</p> </div> <p>Do not perform operation in a state that the proximity sensor for setting check is in failure.</p>
Conveying hoses and suction hoses for each part	<p>Check that excessive suction does not occur at each connecting part of the hoses, and additionally tighten the hose bands.</p> <p>* If the hoses and packing are severely deteriorated, hardened or damaged, replace them with new ones.</p>

4. Every three months maintenance and check


Inspection items	Work instruction
Load cell for bender	<p>Place a weight of a specific weight to perform span adjustment and zero adjustment of the load cell by the operation panel.</p> <p>* For how to work, refer to the attached “Mass Blender Operation Panel.”</p>
Each automatic valve	<p>Check that the following respective automatic valves operate at the normal speed.</p> <ul style="list-style-type: none"> ◇ Air selector valve for blender ◇ Weighing discharge damper for blender ◇ Automatic damper for mixing part <p>For operation check method, refer to “6. How to check operation of various automatic valves for blender” and “7. How to check operation of automatic valve for mixing part.”</p>
Bolts and nuts	<p>Check that bolts and nuts on each device are not loosened, and additionally tighten.</p>
Instrumental air tubes	<p>Check deterioration of air tubes for each part and check that there is no damage to air tubes.</p> <p>* If the air tubes are severely deteriorated, hardened or damaged, replace with new air tubes.</p>

5. How to adjust each device

This section describes the adjusting method of each full detecting device.

1) Damper cam for Jet clone


When "Full" is not detected even if material is full, adjust the damper cam by the following procedure.



Step	Work instruction
1	Loosen the set screw with a hexagon bar wrench (2.5mm).
2	Adjust the damper cam position so that the limit switch is turned "ON" in a state that the damper is lowered by approximately 70° from the horizon.
3	When ending the adjustment, tighten the set screw to fix.

2) Balance weight for Jet clone

When material adheres to the damper due to static electricity, a status as shown in the drawing at the right occurs in a few cases. In this case, loosen the two set screws for the balance weight, shift the weight by approximately every 5mm to the rear, and make adjustment until the damper becomes horizontal. When ending the adjustment, tighten the screws to fix.



3) Level gauge for material receiver

If material full is not accurately detected, adjust sensitivity of the level gauge by the following procedure.	
Step	Work instruction
1	Turn "ON" the disconnect switch for the blender.
2	Remove the lid for the level gauge.
3	<p>Change the spring mounting position. The sensitivity is increased by moving the spring to the LOW side, and the sensitivity is decreased by moving the spring to the high side.</p> <p>[Check method]</p> <p>Step 1: Set the spring of the level gauge to the highest.</p> <p>Step 2: Gradually feed material until the blade of the level gauge is embedded with material.</p> <p>Step 3: Move the spring from the HIGH toward the LOW side step by step in this state. Adjustment is completed at a position where the blade securely stops rotating.</p>






Fig. 11-14



6. How to check operation of various automatic valves for blender

This section describes how to check operation by manually operating each automatic valve in order of the procedure.

Step	Work instruction
1	Turn “OFF” the disconnect switch for the blender.
2	Feed dry compressed air of 0.6MPa or higher to the air kit for the blender, and set the pressure adjustment for the filter regulator in a range of 0.4MPa to 0.5 MPa.
3	<p>Press the manual button on the solenoid valve. The automatic valve (air cylinder) operates.</p>  <p style="text-align: center;">Fig. 11-15</p>
<div style="text-align: center;">  WARNING </div> <ul style="list-style-type: none"> ◎ Do not put your hands and fingers into the moving parts (damper part) during operation. There is a possibility of suffering lacerations or fractures. ◎ Never operate with the cover for the moving parts removed. ◎ Never operate under a state that the material is inserted in the damper parts. It may cause a malfunction. 	

7. How to check operation of automatic valve for mixing part

This section describes how to check operation by manually operating the discharge damper for the mixing part in order of the procedure.


Step	Work instruction
1	Turn "OFF" the disconnect switch for the blender.
2	Feed compressed dry air of 0.6MPa or higher to the air kit of the mixing part, and set the pressure adjustment for the filter regulator in a range of 0.4MPa to 0.5Mpa.
3	<p>Press the manual button on the solenoid valve. The automatic slide damper (air cylinder) operates.</p>  <p style="text-align: center;">Fig. 10-14</p>
<div style="text-align: center;">  WARNING </div> <ul style="list-style-type: none"> ◎ Do not put your hands and fingers into the moving parts (damper part) during operation. There is a possibility of suffering lacerations or fractures. ◎ Never operate with the cover for the moving parts removed. ◎ Never operate under a state that the material is inserted in the damper parts. It may cause a malfunction. 	

Chapter 12 ALARM FUNCTION

This chapter describes the equipped alarm functions on the unit and the restoring method for the alarm.

When the unit operates abnormally, the unit name display part on the operation panel changes to an “Alarm” display, and at the same time, the alarm buzzer sounds.

Confirm the alarm contents that occur according to the following procedure and repair the cause.

Step	Operation items	Operation Contents/Description
1	Buzzer stop and display of “Alarm screen”	<p>Press the “Alarm” displaying part on the screen. The “Alarm screen” is displayed, and at the same time, the buzzer sound stops.</p> <p>Confirm content of the occurred alarm and how to recover on the “Alarm screen.”</p>  <p>* For how to operate the “Alarm screen,” refer to the attached “Mass Blender Operation Panel.”</p>
2	Alarm reset	<p>Eliminate the cause of the alarm, then press the “RESET” touch key on the “Alarm screen.” Alarm message display is reset and recovery can be made.</p> <p>Alarm is automatically reset at a time when the cause of the alarm is eliminated depending on the content of the alarm.</p> <p>* For the cause of the alarm and remedies, refer to <u>Chapter 12 Causes of Troubles and Remedies</u>.</p>

Chapter 13 CAUSES OF TROUBLES AND REMEDIES

This chapter describes abnormal causes and remedies of the unit.
Please check before requesting repair.



Stop the operation and turn “OFF” the disconnect switch in the control panel and primary power before checking work.

Alarm name	Alarm content/cause	Remedies
PC battery voltage drop	Voltage of battery for Programmable controllers unit dropped.	Replace battery.
Primary blower 1 alarm Primary blower 2 alarm Secondary blower alarm	Thermal trip in each conveying blower occurred. <ul style="list-style-type: none">- Batch amount is large.- Filters for air source and suction hopper are clogged.- Failure of the blower motor.- Foreign matter is inserted into the blower moving part.- Failure of the switch.- The thermal set value is improper.- Disconnection of the power cord, looseness of the terminal.	Stop the unit, turn “OFF” the primary power and the disconnect switch for the control panel, then perform check work. <ul style="list-style-type: none">- Change the conveying timer, batch amount to the proper values.- Clean or replace the filter.- Repair or replace the blower.- Remove foreign matter in the blower moving part.- Repair or replace the switch.- Change the thermal set value to a proper value.- Replace the power cord, additionally tighten the terminal. Re-turn on the power, push the thermal reset rod, then reset with the RESET key on the operation surface.
Inverter 1 alarm	Alarm occurred in the main body of the inverter 1 <ul style="list-style-type: none">- Input power voltage dropped.- Momentary power failure occurred.- Foreign matter is inserted into the screw moving part.	After confirming alarm indication for the inverter body in the panel, stop the unit, and turn “OFF” the primary power and the disconnect switch for the control panel, then perform check work. <ul style="list-style-type: none">- Check the power line.- Remove foreign matter in the screw moving part. Re-turn on the power, and then reset with the RESET key on the operation surface.
Feeder 1 setting alarm	The motor coupling for the screw feeder is not correctly set. <ul style="list-style-type: none">- The proximity switch defectively contacts.- Failure of the proximity switch.	Stop the unit, turn “OFF” the primary power and the disconnect switch for the control panel, then perform check work. <ul style="list-style-type: none">- Check the tightening status of the coupling part adjustment fastener.- Adjust or replace the proximity switch. Re-turn on the power, and then reset with the RESET key on the operation surface.

Alarm name	Alarm content/cause	Remedies
Weighing and Mixing part door alarm	<p>The weighing part door is not correctly set.</p> <p>The mixing part door is not correctly set.</p> <p>The charge hopper lid is not correctly set.</p> <ul style="list-style-type: none"> - The limit switch defectively contacts. - Failure of the limit switch. 	<p>Stop the unit, turn “OFF” the primary power and the disconnect switch for the control panel, then perform check work.</p> <ul style="list-style-type: none"> - Check the tightening status of the door knob. - Adjust the limit switch contact or replace. <p>Re-turn on the power, and then reset with the RESET key on the operation surface.</p>
AMP1, 2 alarm	<p>Alarm occurred in communication between the load cell amplifier and sequencer.</p> <ul style="list-style-type: none"> - The communication cable is defectively set or the wire is broken. - Failure of the AMP board. - Influence of noise. 	<p>Stop the unit, turn “OFF” the primary power and the disconnect switch for the control panel, then perform check work.</p> <ul style="list-style-type: none"> - Check setting of the communication cable or replace. - Replace the ANP board. - Eliminate cause of noise. <p>Re-turn on the power, and then reset with the RESET key on the operation surface.</p>
Scale gate 1, 2 alarm	<p>The weighing discharge damper does not properly “open” or “close.”</p> <ul style="list-style-type: none"> - Air pressure is insufficient, or air is not supplied. - Defective position of the lead switch. - Failure of the lead switch. - Material is inserted. - Malfunction of the solenoid valve. 	<p>Stop the unit, turn “OFF” the primary power and the disconnect switch for the control panel, then perform check work.</p> <ul style="list-style-type: none"> - Adjust the air pressure. - Adjust the position of the lead switch, or replace. - Remove material insertion. - Repair or replace the solenoid valve. <p>Re-turn on the power, and then reset with the RESET key on the operation surface.</p>

Alarm name	Alarm content/cause	Remedies
Weigh zero band alarm	<p>Weighing discharge was performed, but material remains in the weighing hopper.</p> <ul style="list-style-type: none"> - The zero set range is small. - Material adherence in the weighing hopper. - Material bridge in the weighing hopper. - Zero and span value fluctuates. - Malfunction of the solenoid valve. - Failure of the load cell. 	<p>Stop the unit, turn "OFF" the primary power and the disconnect switch for the control panel, then perform check work.</p> <ul style="list-style-type: none"> - Set the zero range set value to a proper value. - Remove material adherence and bridge. - Readjustment of zero/span. - Repair or replace the solenoid valve. - Repair or replace the load cell. <p>Re-turn on the power, and then reset with the RESET key on the operation surface.</p>
Mixer gate alarm	<p>The mixer gate does not properly "open" or "close."</p> <ul style="list-style-type: none"> - Air pressure is insufficient, or air is not supplied. - Defective position of the lead switch. - Failure of the lead switch. - Material is inserted. - Malfunction of the solenoid valve. 	<p>Stop the unit, turn "OFF" the primary power and the disconnect switch for the control panel, then perform check work.</p> <ul style="list-style-type: none"> - Adjust the air pressure. - Adjust the position of the lead switch, or replace. - Remove material insertion. - Repair or replace the solenoid valve. <p>Re-turn on the power, and then reset with the RESET key on the operation surface.</p>
Weighing set value alarm	<p>The SV set value is smaller than the overrun set value, and weighing cannot be performed.</p> <ul style="list-style-type: none"> - Job ratio set value is not proper. - Batch amount set value is not proper. - The overrun set value is not proper. 	<p>Stop the unit to perform check work.</p> <ul style="list-style-type: none"> - Set the job ratio set value to a proper value. - Set the batch amount set value to a proper value. - Set the overrun set value to a proper set value. <p>Reset with the RESET key on the operation surface.</p>
Weighing batch amount alarm	<p>The set batch amount is larger than the MAX batch amount, and weighing cannot be performed.</p> <ul style="list-style-type: none"> - The set batch amount is not proper. - The weighing values fluctuated due to disturbance, and the batch amount after correction exceeded MAX batch amount. 	<p>Stop the unit to perform check work.</p> <ul style="list-style-type: none"> - Set the set batch amount to a proper value. - Set the MAX batch amount to a proper value. - Eliminate factors such as disturbance which influences weighing value. - Manually remove the material in the weighing hopper. <p>Reset with the RESET key on the operation surface.</p>

Alarm name	Alarm content/cause	Remedies
No.1 to 3 time alarm	<p>Weighing is not completed within the weighing monitor time.</p> <ul style="list-style-type: none"> - Material in the tank is short. - Material bridge occurred in the tank. - Monitor time, Slow 1, 2 settings are not proper. - Failure of the load cell. 	<p>Stop the unit to perform check work.</p> <ul style="list-style-type: none"> - Feed material to the tank. Check the primary conveying. - Release the bridge. - Set the set values of the monitor time, Slow 1, 2 to proper values. - Repair or replace the load cell. <p>Reset with the RESET key on the operation surface.</p> <p>If the present weighing value is not a problem, continue operation with the compulsory continue key on the operation surface.</p>
No.1 to 3 over alarm	<p>The weighing value fluctuated due to disturbance and exceeded the over set value.</p> <ul style="list-style-type: none"> - The over set value is not proper. - The overrun value is not proper. - The Slow 1, 2 setting is not proper. - The weighing hopper is influenced by vibration. - Failure of the load cell. 	<p>Stop the unit to perform check work.</p> <ul style="list-style-type: none"> - If the weighing completed value is a problem, manually remove material. - Set the over set value, overrun, Slow 1, 2 to proper set values. - Eliminate influence of vibration. - Repair or replace the load cell. <p>If the weighing value is not a problem, continue operation with the compulsory continue key on the operation surface.</p>
No.1 to 3 short alarm	<p>The weighing value fluctuated due to disturbance and exceeded the short set value.</p> <ul style="list-style-type: none"> - The short set value is not proper. - The overrun value is not proper. - The Slow 1, 2 setting is not proper. - The weighing hopper is influenced by vibration. - Failure of the load cell. 	<p>Stop the unit to perform check work.</p> <ul style="list-style-type: none"> - If the weighing completed value has a problem, manually remove material. - Set the short set value, overrun, Slow 1, 2 to proper set values. - Eliminate influence of vibration. - Repair or replace the load cell. <p>If the weighing completed value has no problem, continue operation with compulsory continue key on the operation surface.</p>
Job material decrease	<p>The full level is not reached within the weighing and mixing material monitor set time due to insufficient capacity.</p> <ul style="list-style-type: none"> - The weighing and mixing material monitor set time is not proper. - The purge set time is not proper. - The weighing capacity is insufficient. 	<p>Stop the unit to perform check work.</p> <ul style="list-style-type: none"> - Set the weighing and mixing material monitor set time to a proper time. - Set the purge time to a proper time. - Check the weighing capacity. Check the set values related to weighing. <p>Reset with the RESET key on the operation surface.</p>

Alarm name	Alarm content/cause	Remedies
Complete conveying alarm	<p>Weighing material remains in the receiving chute after secondary conveying was completed, and the level gauge detected.</p> <ul style="list-style-type: none"> - The purge set time is not proper. - Air leak due to hose breakage in the conveying line. - The filter is clogged. 	<p>Stop the unit to perform check work.</p> <ul style="list-style-type: none"> - Set the purge set time to a proper time. - Replace the hose, check air leak location, repair. - Check, clean or replace the filter. - Manually convey the material, and discharge after manual mixing, or remove all job material for one batch. <p>Reset with the RESET key on the operation surface.</p>
No. 1 to 3 material decrease	<p>The full level is not reached within the primary material monitor set time due to insufficient capacity. The material is less than the lower limit level gauge of the tank.</p> <ul style="list-style-type: none"> - The primary material monitor set time is not proper. - The primary conveying set time is not proper. - Insufficient material in conveying source tank. 	<p>Stop the unit to perform check work.</p> <ul style="list-style-type: none"> - Set the primary material monitor set time to a proper time. - Set the primary material monitor set time to a proper time. - Refill material into the conveying source tank. <p>Reset with the RESET key on the operation surface.</p>

Chapter 14 Consumables List

No,	Parts code/ Drawing number-Item No.	Parts name	Qty	Recommended replacement cycle
Machine				
1	CODE:02073	Bearing (JCW2-10)	2	1 Year
2	CODE:22257	Oilesbush (JCW2-10)	1	1 Year
3	CODE:02072	Bearing (JCW2-20)	2	1 Year
4	CODE:25291	Sealring (JCW2-20)	1	1 Year
5	CODE:00427	Conveyance	As required	1 Year
6	CODE:00428	hose (PVC)		
7	CODE:12735	Suction hose	As required	1 Year
8	CODE:12736	(GL)		
9	CODE:00552	Packing (For filter casing)	1	1 Year
1 0	CODE:00552	Packing (For dust hopper)	1	1 Year
1 1	CODE:21614	Cartridge filter	1	1 Year
Electric				
1	CODE: 20880	Magnetic switch (For 5V)	1	1 Year
2	CODE: 20885	Magnetic switch (For 6V)	1	1 Year
3	CODE: 26223	Programmable controllers unit Battery	1	5 Year
4	CODE: 28381	Operation panel Battery	1	5 Year
5	DWG.No.B88323-22	Relay	4	1 Year
6	CODE: 19312	Magnetic contractor (For SB,JB)	1	1 Year
7	DWG.No.B88323-21	Relay (For SB)	1	1 Year



1. The recommended replacement cycle is use environment, it will vary depending on usage.

Chapter 15 SPECIFICATIONS

Model			<div>Capacity indication</div> <div>Number of feeding points</div>			Capacity indication : 10 (100 kg/h) : 20 (300 kg/h)		
			J C W 2 – □□□ J B – □ Batch integrated type			Number of feeding points: : 2 – 3 points (4 points optional)		
			J C W 2 – □□□ S B – □□ Batch separation type			Number of primary conveying points: : 2 – 3 points (4 points optional)		
			J C W 2 – □□□ A P H – □□ Batch separation type			Number of secondary conveying points: : None or 1 point (none for JB)		
			JCW2-10			JCW2-20		
			JB	SB	APH	JB	SB	APH
General capacity (Note)	Number of feeding points	2 points	~ 150kg/h	~ 100kg/h	~ 100kg/h	~ 400kg/h	~ 300kg/h	~ 300kg/h
		3 points	~ 100kg/h	~ 100kg/h	~ 100kg/h	~ 350kg/h	~ 300kg/h	~ 300kg/h
		4 points	~ 70kg/h	~ 70kg/h	~ 70kg/h	~ 300kg/h	~ 300kg/h	~ 300kg/h
Number of weighing points			2 – 3 points (4 points optional)					
Weighing type			Mass measurement type (Load cell method accumulation measurement)					
Control method			Weighing correction, automatic overrun correction, automatic SV correction					
Weighing range (Note 2)			0.015~3kg			0.015~6kg		
Weighing accuracy			±0.5%(F,S,)					
Batch amount			3kg(Max)			6kg(Max)		
Feeding part	Tank effective volume	№1	60L					
		№2	60L					
		№3	8.5L					
		№4	8.5L (Option)					
	Feeder to be used (Note 3)	№1	Screw feeder SF-50ST			Screw feeder SF-50IT1 SF-80IT1, 90IT1		
		№2	Auto shutter MSD-22W MSD-35S (Option)			Auto shutter MSD-50SS MSD-35S (Option)		
		№3	Auto shutter MSD-22WK			Auto shutter MSD-22WK		
		№4	Auto shutter MSD-22W (Option) MSD-35S (Option)			Auto shutter MSD-22W(Option) MSD-35S (Option)		
		MSD-22W		: 1 step switch control by air cylinder				
		MSD-22WK		: 1 step switch or by air cylinder, or count control.				
		MSD-50SS		: 2 step opening control by double air cylinder				
	Applicable material (Note 4)	SF-50ST SF-50IT1 : Pellet (MB material), crushed material						
		SF-80IT1 SF-90IT1 : Pellet, crushed material						
MSD-22W : Pellet								
MSD-22WK : Pellet (MB material)								
MSD-50SS : Pellet								

Model		JCW2-10			JCW2-20		
		JB	SB	APH	JB	SB	APH
Weighing part	Hopper effective volume	11L			18L		
	Discharge method	Conic damper					
Mixing part	Effective volume	8L	8L	8L	14	14L	18L
	Drive motor	0.1kW 1/20			0.2kW 1/20		
	Discharge method	Flap damper		Slide damper	Flap damper		Slide damper
Charge hopper part effective volume		17L	(Note 5)		20L	(Note 5)	
Selector valve	Selector valve body	4VN-38					
	Suction side caliber	φ38					
	Selector side caliber	φ38 2 - 3 directions 【4 directions(For JB), 5 directions(For APH・SB) optional】					
Control panel	Operation panel	Color touch panel operation indicator					
	Control panel	Blender built-in control panel (Microcomputer control) (Note 8)					
	Power supply	200V AC 50/60Hz (220V AC 60Hz) 3 phase					
	Breaker rated current	15A (Note 6)			20A (Note 6)		
Air feed amount		1.0NL/min					
Conveying blower (Note 7)		JCL4-5VC			JCL4-6VC		

Note 1. The general capacity varies with type of material and job ratio. In particular, in case of SB (batch separation type), total capacity depends on the conveying and mixing capacity. The above capacity is obtained by considering conveying distance and blower capacity.

Note 2. The weighing range depends on the shape of the material, apparent specific gravity, feeder to be used. Confirm the range by weighing test if necessary.

Note 3. The feeder can be selected from the screw feeder or auto shutter. However, the No. 1 uses the screw feeder only, and the No. 2 and No. 3 use auto shutter only. The No. 4 (optional) uses auto shutter only.

Note 4. Pellet: Strand cut φ1.5mm to 4mm, Length approximately 4mm

Square pellet □1.5mm to 4mm approximately

Flow rate of auto shutter shall be stabilized.

Crushed material: Material which is not bridged on safety measure fence (opening 30mm × 57mm) and does not include improper cut of apparent specific gravity 0.3 to 0.5. Confirm it by weighing test if necessary.

Note 5. The charge hopper part of the SB type is designed according to the specification.

Note 6. The rated current described in the table is a reference value. It depends on selection of the blower.

Note 7. The blower model described in the table is a reference value. The models of the primary conveying blower and secondary conveying blower may be changed according to the capacity. For APH, SB, secondary conveying can be controlled by a separate blower.

Note 8. Life and about the replacement period of data retention for backup battery.

CPU module battery is implemented as a data backup, we have adopted a lithium battery. It has a useful life of more than continuous backup capacity, but you must be replaced periodically. It also depends on usage and the environment of use, but we recommend the exchange of useful life (5 years).

Please contact the nearest MATSUI S.D.I. (refer to the back cover) concerning the replacement work.